


Wiser Room Thermostat

Device user guide

Information about features and functionality of the device.

10/2024



Legal Information

The information provided in this document contains general descriptions, technical characteristics and/or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.

Table of Contents

Safety Information.....	4
Wiser Room Thermostat.....	5
For your safety	5
About the device.....	6
Installing the device	7
Pairing the device with Wiser HubR.....	8
Pairing the device with Wiser Hub	10
Configuring the device	12
Setting the device location	12
User interface lock settings.....	13
Identifying the device	14
Using the device.....	15
Setting the room temperature	15
Wake up the Device	16
Voice control.....	17
Creating a moment	18
Creating an automation	21
Removing the device	29
Resetting the device	29
Replacing the batteries	31
LED indications	31
Troubleshooting	31
Technical Data	33
Compliance.....	34
Compliance information for Green Premium products.....	34
EU Declaration of Conformity	35
Trademarks.....	35

Safety Information

Important Information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that accompany this symbol to avoid possible injury or death.

⚡⚠ DANGER
DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury. Failure to follow these instructions will result in death or serious injury.
⚠ WARNING
WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
⚠ CAUTION
CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE
NOTICE is used to address practices not related to physical injury.

Wiser Room Thermostat



CCTFR6400
WN704R0S0901



CCTFR6401
WN704R0S0902

For your safety


<i>NOTICE</i>
RISK OF DAMAGE TO DEVICE Always operate the product in compliance with the specified technical data. Failure to follow these instructions can result in equipment damage.

About the device

The Wiser Room Thermostat (hereinafter referred to as **Room Thermostat**) is a wireless, battery-powered, colorful touch-button display where the end-user can increase, decrease, boost, and set the room temperature.

The Room Thermostat display shows information such as (room temperature, relative humidity, battery level, boost status, heating symbol, and signal status).

NOTE: On the Room Thermostat screen,  icon changes and appears  when the room is in Comfort Mode and  when the room is in ECO Mode. For more information, refer to the System User Guide.



Advantage of using the Room Thermostat:


- Easy to control all heating appliances in the room from one place.
- Control locally or remotely using the wiser app

Features of the Room Thermostat:

- Works with Amazon Alexa & the Google Assistant
- Boost, and set the room temperature
- Configure several time schedules for heating
- To check humidity of the room
- Device user interface lock

Diagram of operating elements

- A. Reduce temperature
- B. Increase temperature
- C. Boost
- D. LED



Installing the device

Refer to the installation instruction supplied with this product.


Pairing the device with Wiser HubR

Using the Wiser Home app, pair your Room Thermostat with the **Wiser HubR** to access and control the Room Thermostat.

IMPORTANT: Insert the batteries before pairing and follow the Room Thermostat on-screen instructions.

1. On the Home page, tap .
2. Tap **Devices** >  icon and tap **Climate (tab) > Room Thermostat**.
TIP: The next screen shows the joining process of the Room Thermostat.
3. Wait for a few seconds.


In the app, you can see the Room Thermostat is successfully joined.



4. Tap **Next** to enter Room Thermostat name and assign it to an existing room or a new room, then tap **Submit**.
5. Tap **Heating Type** and select one of the following and tap **Done**:
 - **None:** In case Underfloor Heating (UFH) hasn't been installed or if you prefer not to use a room thermostat with UFH, select **None** and proceed to **Step 7**.
 - **Underfloor Heating:** If Underfloor Heating is installed and you wish to use room thermostat along with UFH, select **Underfloor Heating** and proceed to **Step 6**.

6. Update following details:

- **UFH Channels:** Select the channel which is assigned to the same room as room thermostat in **Step 4**.
- **Assign Floor Sensor:** Turn on the toggle switch if you want to use the UFH floor sensor which is assigned to the same room as room thermostat.




NOTE:

- To change the UFH channel room refer *Assigning a channel to the room*.
- Only one UFH floor sensor can be assigned to a room if you want to update refer *Setting Floor Sensor Location*.

7. Tap **Submit** to complete the pairing process.

You can see the added Room Thermostat on the Home page under the room tab or under **ALL** devices.

IMPORTANT: If cooling input is enabled in UFH make sure in **Room Setting > Excluded From Cooling** toggle switch is On. This can be useful if there are areas in a building that do not require cooling, such as storage rooms or unoccupied spaces. Refer *UFH Cooling input*.




Pairing the device with Wiser Hub

Using the Wiser Home app, pair your Room Thermostat with the **Wiser Hub** to access and control the Room Thermostat.

IMPORTANT: Insert the batteries before pairing and follow the Room Thermostat on-screen instructions.


1. On the Home page, tap .
2. Tap **Devices** >  icon and tap **Climate** (tab) > **Room Thermostat**.
TIP: The next screen shows the joining process of the Room Thermostat.
3. Wait for a few seconds.

In the app, you can see the Room Thermostat is successfully joined.



4. Tap **Next** to enter Room Thermostat name and assign it to an existing room or a new room, then tap **Submit**.

5. If Underfloor Heating (UFH) is already paired with Wiser Hub, turn on the toggle switch for better performance and update below details:
 - **Device:** If you have more than one UFH installed, select one.
 - **Channels:** Select the channel which is assigned to the same room as room thermostat in **Step 4**.
 - **Floor sensor is in this room?:** Turn on the toggle switch if you want to use the UFH floor sensor which is assigned to the same room as room thermostat.




NOTE:

- To change the UFH channel room refer *Assigning a channel to the room*.
- Only one UFH floor sensor can be assigned to a room if you want to update refer *Setting Floor Sensor Location*.

6. Tap **Submit** to complete the pairing process.

You can see the added Room Thermostat on the Home page under the room tab or under **ALL** devices.

IMPORTANT: If cooling input is enabled in UFH make sure in **Room Setting > Excluded From Cooling** toggle switch is On. This can be useful if there are areas in a building that do not require cooling, such as storage rooms or unoccupied spaces. Refer *UFH Cooling input*.




Configuring the device

Setting the device location

You can change the device location using Wiser Home app (such as bedroom, living room, dining room etc.).

1. On the Home page, tap .
2. Tap **Devices**, select the device from the list for which you wish to change the location.
3. Tap **Location**  to open setup page.
4. On setup page, you can enter **New room name** (A) or select an existing room from the list (B).



TIP: If the device is already assigned, you can remove it from the existing room. Tap **Remove from Room** (C).

5. Once changes are done, tap **Submit** (D).


User interface lock settings

Using the Wiser Home app, you can lock the Room Thermostat controls. This prevents children from changing the temperatures in your room when playing with the Room Thermostat.

To lock or unlock the Room Thermostat control:

1. On the Home page, tap .
2. Tap **Devices > Room Thermostat > Device lock (A)**.

TIP: When the Room Thermostat lock is active,  will appear next to the Room Thermostat.



Identifying the device


Using the Wiser Home app, you can identify a Room Thermostat from the other available devices in the room.

To identify the Room Thermostat:

1. On the Home page, tap .
2. Tap **Devices > Room Thermostat > Identify (A)**.

NOTE:

- This feature displays an exclamation mark on the Room Thermostat screen, so you can identify the actual device. It may take up to a minute to display an exclamation mark on the Room Thermostat screen.
- The Room Thermostat displays an exclamation mark until you tap **OK**.



Using the device

Setting the room temperature

You can set the room temperature manually using the room thermostat button or remotely using the Wiser Home app.

Setting room temperature manually

You can increase or decrease or boost the room temperature using the Room Thermostat button.

The room temperature can be increased or decreased, and boost time can be set using a Room Thermostat button.

- Press the + button to increase the set-point temperature by 0.5 °C.
- Press the - button to decrease the set-point temperature by 0.5 °C.




The amount of time the boost remains active depends on how many times you press O as follows:

- Press 1 time = 30 minutes
- Press 2 time = 1 hour
- Press 3 time = 2 hours
- Press 4 time = 3 hours
- Press 5 times = Cancel

NOTE: With only boost features, you can set the time like how long you want the room to be heated up.

Setting the room temperature using the app

Using the Wiser Home app, you can adjust the room temperature. On the control panel page, drag the sliding bar up/down to adjust the room temperature.



Wake up the Device

If there has been no interaction for 15 seconds, the Room Thermostat goes into Sleep Mode, and the display fades out. Wake up the Room Thermostat by tapping any button.

Voice control

You can control the plug using Amazon Alexa® and Google home by giving a voice command.

Amazon Alexa™

Amazon Alexa™ (Alexa) is an intelligent personal assistant developed by Amazon™, and is capable of voice interaction.

Common Wiser commands for Alexa

- Discover Devices: “Alexa, discover devices”
- Reduce Temperature: “Alexa, decrease the temperature upstairs by 4 degrees”
- Increase Temperature: “Alexa, increase the temperature upstairs by 3 degrees”
- Set Temperature: “Alexa, set the upstairs to 20 degrees”
- Get Temperature: “Alexa, what is the upstairs temperature?”
- Get the Set Point: “Alexa, what is the upstairs set to?”

Google Home

Google Home is a brand of smart speakers that work similarly to Amazon’s Alexa. The user can speak a profusion of commands to request information, or ask Google Assistant to perform action.”

Common Wiser commands for Google Home:

- Inquiry: “OK, Google, is the hot water on?”
- Hot Water Command: “OK, Google, turn on/off the hot water”
- Room Temperature: “OK, Google, how warm is (room name)?”
- Set Temperature: “OK, Google, set (room name) to XX degrees”
- Increase Temperature: “OK, Google, increase the setpoint by XX degrees”
- Set Temperature: “OK, Google, set (room name) to XX degree”


Changes made with Google Home

All changes made through a voice command related to room thermostat that is valid for one hour, or until the next scheduled event. The user cannot change this action. This also applies for boosts initiated from the room thermostat.


Creating a moment

Moment allows you to group multiple actions that are usually performed together. By using the Wiser Home app, you can create moments based on your needs. To create a moment:

1. On the **Home** page, tap .
2. Go to **Moments** >  to create a moment.
3. Enter the name of the moment (A).
TIP: You can choose the cover image that best represents your moment by tapping .
4. Tap **Add actions** (B) to select the list of devices.




5. In the **Add actions** menu, you can select the devices (C).



6. Once all the device are selected, tap **Done**.

7. On the **Moment creator** page, tap the device to set the condition. For example, select heating.
 - Set the required temperature using sliding bar (D).




When the desired condition is set, tap **Set**.

8. Once all conditions are set, tap **Save**.

Once the moment is saved, it is visible on the **Moments** tab. You can tap on the moment to enable it.

Editing a moment

1. On the **Home** page, tap **Automations** .
2. Go to **Moments**, locate the moment you want to edit and tap .
3. On the **Moment editor** page, you can perform following changes:
 - Change the icon .
 - Rename the moment.
 - Tap each action to change the settings.
 - To remove an action, slide the action to the left and then tap  (A) to delete it.
 - Tap  **Add actions** (B) to add new action.




4. Tap **Save** to save the changes.

Deleting a moment

1. On the **Home** page, tap **Automations** .
2. Go to **Moments**, locate the moment you want to delete and tap .

3. On the Moment editor page, tap **Delete** (A) and then tap **OK** (B).




Creating an automation

An automation allows you to group multiple actions that are usually done together, triggered automatically or at scheduled times. By using the Wiser app, you can create automations based on your needs.

To create an automation:



1. On the **Home** page, tap .
2. Go to **Automation** >  to create an automation.
NOTE: Maximum 10 automations can be added.
3. Tap **If** (A) and select any of the following conditions (B):
 - **All conditions:** This triggers an action only when all conditions are met.
 - **Any condition:** This triggers an action when at least one condition is met.



4. Tap **Add conditions** and select any of the following (C):


- **Device status change:** Select a device to enable automation.
- **Away Mode:** Enable/Disable away mode to trigger an action.

TIP: Away mode can also be used as a trigger to turn off the lights, dimmer or closing the shutter etc. For more information refer to *Away mode*.

5. Tap **Device status change** > **Climate**, Set the temperature using sliding bar (D) and select the condition (E) (less than / more than), then tap **Set**.**NOTE:**

- Maximum 10 conditions can be added.
- To remove an added condition, swipe left and tap .


6. To set a specific time for your automation, tap **When > Add time** and select any of the following (F):
 - **Specific time of the day: Sunrise, Sunset, Custom.**
 - **Period of time: Daytime, Night time, Custom.**




NOTE:

- Maximum 10 entries can be added
- To remove a specific time, swipe left and tap .


7. To add an action, tap **Then > Add an action** and select any of the following (G):
 - **Control a device:** Select a devices that you want to trigger.
 - **Send notification:** Turn on the notification for the automation.
 - **Activate a moment:** Select the moment that you want to trigger.
 - **Wait:** This option allows you to add a delay in an automation sequence. You can set the wait time in increments of 1 hour and 1 minute, up to a maximum of 24 hours. This feature is useful for delaying actions within an automation.



8. Tap **Control a device** > **Heating** and select any of the following (H):
- **Boost**: Set the duration to increase the temperature by 2° C.
 - **Setpoint**: Set the desired temperature.



9. Tap **Setpoint**, set the required temperature using vertical sliding bar (I), then tap **Set**.




NOTE:

- Maximum 10 actions can be added.
- To remove an action, swipe it left on the action and then tap .

10. Enter the automation name (J).


You can choose the cover image that represents your automation by tapping



11. Tap **Save**.

Once the automation is saved, it is visible on the **Automation** tab.

Using the  (K) you can enable and disable the automation.



Example of an automation

This demonstration shows you how to create an automation to turn on the Heating to the desired temperature (set point) of 20 °C when the temperature is less than 18 °C.


NOTE: It is mandatory to create two automations:

- First, switch on the heater at the desired 20 °C when the room temperature is 18°C or lower.
- Second, switch off the heater when the room temperature is at 25 °C or above.


The room heater will not turn off automatically until you create another automation.

1. Go to **Automation** >  to create an automation.

2. To add a condition, tap **Add Condition > Device status change > Temperature/Humidity Sensor > Temperature**.
3. Set the temperature as 18 °C (A) and the condition as **less than** (B) and tap **Set**.




4. Read the information and tap **OK**.
5. To add an action, tap **Then > Add an action > Control a device > Heating > Setpoint**. Set the temperature to 20 °C (C), then tap **Set**.



6. Read the information and tap **OK**.
7. Enter the name of the automation.

TIP: You can choose the cover image that represents your automation by tapping .


8. Tap Save.
Once the automation is saved, it is visible on the Automation tab.



NOTE: You can enable or disable saved automations on the **Automations** tab by using  (D).

Editing an automation

1. On the **Home** page, tap **Automations** .
2. Go to **Automation**, tap the automation you want to edit.
3. On the **Edit automation** page, you can perform following changes:
 - Change the icon .
 - Rename the automation.
 - Tap each condition to change the settings.
 - To remove a condition, slide the condition towards left and then tap  (A) to delete it.
 - Tap  **Add conditions** (B) to add new condition.
 - To change the order of actions, tap the **Then** option, and hold an action then drag and drop to the desired position.




4. Tap **Save** to save the changes.

Deleting an automation

1. On the **Home** page, tap **Automations** .
2. Go to **Automation**, tap the automation you want to delete.

- On the **Edit automation** page, tap **Delete automation** (A) and read the confirmation message and then tap **OK** (B).




Removing the device

Using the Wiser home app, you can remove the Room Thermostat from the Wiser system.

To delete the Room Thermostat:

- On the Home page, tap .
- Tap **Devices > Room Thermostat > Delete** (A).



Resetting the device

The Room Thermostat can be reset manually at any time, e.g., if the Hub is replaced. To remove the device from a heating system and join another system. To reset the Room Thermostat:

- Remove the batteries and re-insert them.

2. When the “Wiser” startup screen appears, press the + and - buttons at the same time for 20 seconds until the unit restarts.



Replacing the batteries

Replace the batteries when the battery level is low. The battery level can be seen in the Room Thermostat display top-right corner. It can also be viewed in the Wiser Home app under Settings > Devices. Follow the steps below to replace the batteries:

1. Open the battery compartments.
2. Replace the batteries.

TIP: Make sure that the polarity of the batteries (+ and -) are in the right direction. The polarity is indicated on the terminals of the device.

NOTICE

USE ONLY STANDARD, NON-RECHARGEABLE AA ALKALINE BATTERIES

- **Do not use** rechargeable batteries, Zinc Carbon, or Zinc Chloride batteries.
- Rechargeable batteries are not optimized for Wiser device systems.

Failure to follow these instructions can result in equipment damage.

3. Close the battery compartments.



LED indications

Room thermostat

Status	LED	Description
Low Battery		Flashes red when the batteries are low.

Troubleshooting

Symptom	Possible cause	Solution
The Room Thermostat screen goes blank.	Batteries may be low or drained	Replace the batteries., page 31
Unable to set the room temperature	Wiser Hub signal is weak or not connected to the WIFI network.	Check for a Wi-Fi® signal.
Unable to set the room temperature, control are disabled.	Check room details if only if Room thermostat is alone in the room and the hub is not connected to the boiler relay.	Add a heating device to this room will enable to control temperature.

Technical Data

Power supply	2 alkaline batteries type IEC LR6 1.5 V (AA)
Interfaces	User: TFT screen, touch buttons
Wiring	No cabling required
Temperature setting range	5 °C to 30 °C
Temperature resolution	0.5 °C
Operating temperature	0 °C to 45 °C
Storage temperature	-20 °C to 65 °C
Operating frequencies	2.4 GHz (bidirectional, mesh)
Transmission	+13 dBm (20 mW)
Degree of pollution	2
Radio signal range	30 m in free space
Software class	A
IP rating	IP20
Mounting	Wall bracket or table stand
Product dimensions:(H x W x D)	76 x 76 x 25 mm

Compliance

Compliance information for Green Premium products

Find and download comprehensive information about Green Premium products, including RoHS compliance and REACH declarations as well as Product Environmental Profile (PEP) and End-of-Life instructions (EOLI).

<https://checkaproduct.se.com/>



General information about Green Premium products

Click the link below to read about Schneider Electric's Green Premium product strategy.

<https://www.schneider-electric.com/en/work/support/green-premium/>



EU Declaration of Conformity

Hereby, Schneider Electric Industries, declares that this product is in compliance with the essential requirements and other relevant provisions of RADIO DIRECTIVE 2014/53/EU. Declaration of conformity can be downloaded on se.com/docs.

Trademarks

This guide makes reference to system and brand names that are trademarks of their relevant owners.

- Zigbee® is a registered trademark of the Connectivity Standards Alliance.
- Apple® and App Store® are brand names or registered trademarks of Apple Inc.
- Google Play™ Store and Android™ are brand names or registered trademarks of Google Inc.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.
- Wiser™ is a trademark and the property of Schneider Electric, its subsidiaries and affiliated companies.
- Amazon Alexa™ is a trademark of AMAZON TECHNOLOGIES, INC.
- Google Home™ is a trademark of Google INC.

Other brands and registered trademarks are the property of their respective owners.

Schneider Electric
35 rue Joseph Monier
92500 Rueil Malmaison
France

+ 33 (0) 1 41 29 70 00

www.se.com

As standards, specifications, and design change from time to time,
please ask for confirmation of the information given in this publication.

© 2021 – 2024 Schneider Electric. All rights reserved.

DUG_Room Thermostat_WH-06