



- 1** Make an opening through the wall (inside / outside)
- 2** Push the Insulated Sleeve Support Plate through the opening made from the outside
- 3** Put the insulated sleeve in place through the opening made from the inside and then cut level with the internal wall
- 4** Slide the flue through the insulated sleeve. Fix the outside Air-tight Wall Plate first and then the Wall Finishing Plate, finally connect the Tee.
- 5** Fix the Air-Tight Wall Plate on the inner wall, then finish off with the Wall Finishing Plate.