


PRODUCT-DETAILS

1721-286

1721-286 Cover Frame 1gang(s) green Horizontal mounting - Busch-axcent



Informations générales

Extension du type de produit	1721-286
Code de produit	2CKA001754A4337
EAN	4011395113318
Description courte	1721-286 Cover Frame 1gang(s) green Horizontal mounting - Busch-axcent
Description longue	1721-286 Cover Frame 1-gang

Technique

Number of Gangs	1
Design Range	Busch-axcent
Type de montage	Flush Mounted
Type of Fastening	Clamp
Sens de montage	Horizontal Vertical
Finition de surface	Untreated Glossy
Matériau	Thermoplastic
Label Space Provided	No
RAL Number	RAL 6032 - Vert de sécurité

Couleur	green
---------	-------

Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E2686
REACH Declaration	2CKA309999E9999

Dimensions

Poids net	0.031 kg
-----------	----------

Commande

Quantité minimum	1 pièce
Emballage Niveau 1 Unités	carton 10 pièce
Emballage Niveau 1 Poids	0.416 kg
Code douanier	85389099
E-Number (Finland)	2166226
E-Number (Sweden)	1817635
Pays d'origine	Germany (DE)

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E2686
--------------------------------	-----------------

Classifications

ETIM 8	EC000007 - Cover frame for domestic switching devices
ETIM 9	EC000007 - Cover frame for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144001

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
2CKA001731A1916	1720-84 Rocker Switch Pull cord studio white - 63x63	1720-84	1	piece
2CKA001710A3808	1740 DR/03-84 Cover Plate Level switch Turn button studio white - 63x63	1740 DR/03-84	1	piece

2CKA001710A3512	1740 DRL-84-503 Cover Plate Level switch Turn button Symbol "3-level switch" studio white - 63x63	1740 DRL-84-503	1	piece
2CKA001710A3172	1740-84 Cover Plate Venetian blind Turn button studio white - 63x63	1740-84	1	piece
2CKA001710A3161	1742-84 Cover Plate Blind cap 1 gang(s) with Mounting plate studio white - 63x63	1742-84	1	piece
2CKA001710A3991	1742-84-500 Inserts with Cover Plate Blind cap 1 gang(s) 0 pole studio white - 63x63	1742-84-500	1	piece
2CKA001724A4368	1743/10-04-84 Cover Plate SAT 1 gang(s) 4 gang(s) studio white - 63x63	1743/10-04-84	1	piece
2CKA001724A4377	1743-04-84 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) studio white - 63x63	1743-04-84	1	piece
2CKA001724A4332	1743-84-500 Cover Plates SAT 1 gang(s) 3 gang(s) studio white - 63x63	1743-84-500	1	piece
2CKA001710A3173	1745-84 Cover Plate telephone connector boxes (VDo) 1 gang(s) studio white - 63x63	1745-84	1	piece
2CKA001710A3993	1746/10-84-500 Cover Plates Telecommunication inserts 0 gang(s) studio white - 63x63	1746/10-84-500	1	piece
2CKA001710A3167	1746-84 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid studio white - 63x63	1746-84	1	piece
2CKA001710A4096	1747 BSI-84 Intermediate Ring Cover plates Busch-Balance® SI studio white - 63x63	1747 BSI-84	1	piece
2CKA001710A3863	1747 SI-84 Cover Plates studio white - 63x63	1747 SI-84	1	piece
2CKA001710A3861	1747-84 Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI studio white - 63x63	1747-84	1	piece
2CKA001710A3656	1748-84 Cover Plate Data connection 2 gang(s) studio white - 63x63	1748-84	1	piece
2CKA001710A3163	1749-84 Cover Plate Cable outlet 1 gang(s) 0 gang(s) studio white - 63x63	1749-84	1	piece
2CKA001710A3166	1750-84 Cover Plate BNC/TNC 2 gang(s) studio white - 63x63	1750-84	1	piece
2CKA001723A0240	1751-84 Cover Plate Loudspeaker 2 gang(s) studio white - 63x63	1751-84	1	piece
2CKA001710A3175	1755 SL/PZ-84-101 Cover Plate Venetian blind Key studio white - 63x63	1755 SL/PZ-84-101	1	piece
2CKA001753A0092	1756-84 Cover Plate Info light studio white - 63x63	1756-84	1	piece
2CKA001724A2761	1758-84 Cover Plate For data connection housing 2 gang(s) studio white - 63x63	1758-84	1	piece
2CKA001710A4106	1762-84-506 Cover Plates TDO 1 gang(s) 1 gang(s) studio white - 63x63	1762-84-506	1	piece
2CKA001731A1877	1764 NLI-84 Rocker Switch/push button Single push button with Pilot lamp studio white - 63x63	1764 NLI-84	1	piece
2CKA001710A3992	1766-84-500 Cover Plates TAE 1 gang(s) 0 gang(s) studio white - 63x63	1766-84-500	1	piece
2CKA001753A0258	1770-84-103 Cover Plate Time switch Toggle studio white - 63x63	1770-84-103	1	piece
2CKA001753A0301	1771-84-103 Cover Plate Time switch Toggle studio white - 63x63	1771-84-103	1	piece
2CKA001751A3099	1785 JA/02-84 Rocker Venetian blind Two-part rocker Symbol "arrows" studio white	1785 JA/02-84	1	piece
2CKA001751A3088	1785 JA-84-500 Cover Plates Venetian blind Two-part rocker Symbol "arrows" studio white - 63x63	1785 JA-84-500	1	piece

2CKA001751A3128	1785 K-84-500 Cover Plates Switch/push button Two-part rocker None studio white - 63x63	1785 K-84-500	1	piece
2CKA001751A2992	1785/11-84 Rocker Switch/push button Two-part rocker studio white - 63x63	1785/11-84	1	piece
2CKA001751A3076	1785-84-500 Cover Plates Switch/push button Two-part rocker Without imprint studio white - 63x63	1785-84-500	1	piece
2CKA001751A3098	1786 JA/02-84 Rocker Venetian blind Single rocker studio white	1786 JA/02-84	1	piece
2CKA001751A2998	1786/11-84 Rocker Switch/push button Single rocker studio white - 63x63	1786/11-84	1	piece
2CKA001751A3074	1786-84-500 Cover Plates Switch/push button Single rocker Without imprint studio white - 63x63	1786-84-500	1	piece
2CKA001751A2750	1788-84 Rocker Switch/push button Single rocker studio white - 63x63	1788-84	1	piece
2CKA001751A2751	1789 H-84 Rocker Switch/push button Single rocker Heizung studio white - 63x63	1789 H-84	1	piece
2CKA001751A2754	1789 KI-84 Rocker Switch/push button Single rocker Symbol "bell" studio white - 63x63	1789 KI-84	1	piece
2CKA001751A3084	1789 LI-84-500 Cover Plates Switch/push button Single rocker Symbol "light" studio white - 63x63	1789 LI-84-500	1	piece
2CKA001751A3151	1789 N-84-500 Cover Plates Switch/push button Single rocker Without imprint studio white - 63x63	1789 N-84-500	1	piece
2CKA001751A3161	1789 ST-84-500 Cover Plates Switch/push button Single rocker Various symbols studio white - 63x63	1789 ST-84- 500	1	piece
2CKA001751A2755	1789 TR-84 Rocker Switch/push button Single rocker studio white - 63x63	1789 TR-84	1	piece
2CKA001751A3091	1789-84-500 Cover Plates Switch/push button Single rocker Without imprint studio white - 63x63	1789-84-500	1	piece
2CKA001710A4113	1790-592-84 Cover Plate Medical alarm studio white - 63x63	1790-592-84	1	piece
2CKA001710A3698	1794 TA-84 Cover Plate Thermostat Turn button studio white - 63x63	1794 TA-84	1	piece
2CKA001710A3544	1794-84 Cover Plate Thermostat studio white - 63x63	1794-84	1	piece
2CKA001710A4017	1795 HK-84 Cover Plate Thermostat Turn button studio white - 63x63	1795 HK-84	1	piece
2CKA001710A4049	1795 HKEA-84 Cover Plate Thermostat Turn button 1 switchover studio white - 63x63	1795 HKEA-84	1	piece
2CKA001710A3725	1795 TA-84 Cover Plate Thermostat Turn button studio white - 63x63	1795 TA-84	1	piece
2CKA001710A3569	1795-84 Cover Plate Thermostat Turn button studio white - 63x63	1795-84	1	piece
2CKA001753A0311	1796-84 Cover Plate Pull cord studio white - 63x63	1796-84	1	piece
2CKA001710A3990	1800-84-500 Cover Plates Modular Jack 1 gang (s) 2 gang(s) studio white - 63x63	1800-84-500	1	piece
2CKA001710A1551	1803-02-84-500 Cover Plates UAE/IAE (ISDN) 1 gang(s) 2 gang(s) studio white - 63x63	1803-02-84- 500	1	piece
2CKA001710A1550	1803-84-500 Cover Plates UAE/IAE (ISDN) 1 gang(s) 1 gang(s) studio white - 63x63	1803-84-500	1	piece
2CKA002013A5407	20 EUAB-84 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	20 EUAB-84	1	piece

2CKA002011A6207	20 EUC-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUC-84- 500	1	piece
2CKA002013A5418	20 EUCBDR-84 Socket insert Busch-Service- Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	20 EUCBDR- 84	1	piece
2CKA002013A5286	20 EUCBL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) studio white - 63x63	20 EUCBL-84	1	piece
2CKA002013A5294	20 EUCBLI-84 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) studio white - 63x63	20 EUCBLI-84	1	piece
2CKA002013A5268	20 EUCKS/DV-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	20 EUCKS/DV- 84	1	piece
2CKA002013A5372	20 EUCKS-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUCKS-84- 500	1	piece
2CKA002013A5441	20 EUCRB-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUCRB-84- 500	1	piece
2CKA002018A1509	20 EUK-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) with Hinged Lid studio white - 63x63	20 EUK-84-500	1	piece
2CKA002018A1520	20 EUKB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKB-84	1	piece
2CKA002018A1529	20 EUKBR-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKBR-84	1	piece
2CKA002018A1540	20 EUKNB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNB-84	1	piece
2CKA002018A1551	20 EUKNBL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNBL-84	1	piece
2CKA002018A1563	20 EUKNBSL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNBSL- 84	1	piece
2CKA002018A1564	20 EUKNBSL-84-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNBSL- 84-101	1	piece
2CKA002011A6209	20 EUN-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUN-84- 500	1	piece
2CKA002017A0786	20 MUC-84-500 Socket insert 1gang(s) studio white - 63x63	20 MUC-84- 500	1	piece
2CKA002017A0807	20 MUCKS-84-500 Inserts with Cover Plate 1gang(s) studio white - 63x63	20 MUCKS-84- 500	1	piece
2CKA001751A3170	2029 UC-84 Bell push-switch DND / MUR insert Bell Single push button studio white - 63x63	2029 UC-84	1	piece
2CKA002495A0086	2095 UC-84 Socket insert Equipotential compensation studio white - 63x63	2095 UC-84	1	piece
2CKA002190A0215	2190 EUC-84 Inserts with Cover Plate 1gang(s) studio white	2190 EUC-84	1	piece
2CKA002013A5477	23 EUCB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	23 EUCB-84	1	piece

2CKA002013A5451	2300 EUCB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	2300 EUCB-84	1	piece
2CKA002113A0511	2300 UCRKS-84-503 Inserts with Cover Plate 1gang(s) studio white - 63x63	2300 UCRKS-84-503	1	piece
2CKA002011A3833	2310 EUGL/VA-84-11 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	2310 EUGL/VA-84-11	1	piece
2CKA002099A0214	2399 UCKS-84 Socket insert Safety Shutter 1gang(s) studio white - 63x63	2399 UCKS-84	1	piece
2CKA002099A0192	2399 UCKS-84-505 Inserts with Cover Plate 1gang(s) studio white - 63x63	2399 UCKS-84-505	1	piece
2CKA001719A0220	2518-WD-84 Intermediate Ring with Hinged Lid 1 gang(s) studio white - 63x63	2518-WD-84	1	piece
2CKA001751A3180	2520 KI-84-500 Cover Plates Switch/push button Single rocker studio white - 63x63	2520 KI-84-500	1	piece
2CKA001751A3199	2520 TR-84 Rocker Switch/push button Single rocker studio white - 63x63	2520 TR-84	1	piece
2CKA001724A4256	2533-84 Cover Plate Bore hole 1 gang(s) studio white - 63x63	2533-84	1	piece
2CKA001710A3646	2542 DR/01-84 Cover Plate Level switch Turn button Symbol "0-1-2-3" studio white - 63x63	2542 DR/01-84	1	piece
2CKA001710A3651	2542 DR/02-84 Cover Plate Level switch Turn button Symbol "1-2-3" studio white - 63x63	2542 DR/02-84	1	piece
2CKA001724A4388	2548-022 AR-84 Cover Plate Doctor Blue 1 button(s) studio white - 63x63	2548-022 AR-84	1	piece
2CKA001724A4402	2553-84 Cover Plate XLR 1 gang(s) 1 gang(s) studio white - 63x63	2553-84	1	piece
2CKA001753A0394	2561-02-84 Cover Plate Modular Jack 1 gang(s) 2 gang(s) studio white - 63x63	2561-02-84	1	piece
2CKA001753A0403	2561-84 Cover Plate Modular Jack 1 gang(s) 1 gang(s) studio white - 63x63	2561-84	1	piece
2CKA003116A0662	3120 EUCB-84 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - solo	3120 EUCB-84	1	piece
2CKA003117A0006	3151 UC-84 RCD - Insert Buschmat 30 mA studio white - 63x63	3151 UC-84	1	piece
2CKA006115A0486	6108/61-84-500 Coverplate f. CE	6108/61-84-500	1	piece
2CKA006155A0063	6109/03-84-500 Coverplate f. RTC	6109/03-84-500	1	piece
2CKA006132A0379	6122/10-84-500 BW standard	6122/10-84-500	1	piece
2CKA006115A0183	6125/01-84-500 Control element 1g w. BAU	6125/01-84-500	1	piece
2CKA006115A0219	6125/02-84-500 Control element 1/2gang	6125/02-84-500	1	piece
2CKA006116A0174	6126/01-84-500 Control element 2g w. BAU	6126/01-84-500	1	piece
2CKA006116A0209	6126/02-84-500 Control element 2/4gang	6126/02-84-500	1	piece
2CKA006117A0200	6127/01-84-500 Control element 4g w. BAU	6127/01-84-500	1	piece
2CKA006117A0235	6127/02-84-500 Control element 4/8gang	6127/02-84-500	1	piece

2CKA006134A0334	6128/28-84-500 RTC Control element 2/4g	6128/28-84-500	1	piece
2CKA006135A0146	6129/01-84-500 Control element 3/6g w. IR	6129/01-84-500	1	piece
2CKA006430A0400	6430-84-102-500 Cover Plates Venetian blind Symbol "arrows" studio white - 63x63	6430-84-102-500	1	piece
2CKA006430A0306	6435-84 Cover Plate Time switch studio white - 63x63	6435-84	1	piece
2CKA006470A0004	6476-84 Cover Plate Proximity switch studio white - 63x63	6476-84	1	piece
2CKA006400A0059	6477-84 Cover Plate PowerDock 1 gang(s) studio white	6477-84	1	piece
2CKA006400A0047	6480/11-84-500 Complete Devices studio white	6480/11-84-500	1	piece
2CKA006400A0045	6480-84-500 Complete Devices studio white - future linear	6480-84-500	1	piece
2CKA006599A3009	6540-84-102-500 Cover Plates Dimmer studio white - 63x63	6540-84-102-500	1	piece
2CKA006599A2835	6541-84 Cover Plate Cooling Central cover plate studio white - 63x63	6541-84	1	piece
2CKA006599A3010	6543-84-101-500 Cover Plates Switch/dimmer Single push button Without imprint studio white - 63x63	6543-84-101-500	1	piece
2CKA006599A2908	6545-84 Control Element Dimmer Two-part button with Neon lamp studio white - 63x63	6545-84	1	piece
2CKA006710A0011	6716 UJ-84-500 Complete Devices studio white - future linear	6716 UJ-84-500	1	piece
2CKA006730A0038	6731-84-500 Cover Plates studio white - 63x63	6731-84-500	1	piece
2CKA006730A0039	6732-84-500 Cover Plates studio white - 63x63	6732-84-500	1	piece
2CKA006730A0040	6733-84-500 Wall sensor studio white - 63x63	6733-84-500	1	piece
2CKA006730A0136	6736 FoH-84 Control Element Switch/dimmer Two-part button studio white	6736 FoH-84	1	piece
2CKA006800A2834	6815-84-101-500 Cover Plates studio white	6815-84-101-500	1	piece
2CKA008200A0081	8253-84 Cover Plate Loudspeaker studio white - 63x63	8253-84	1	piece
2CKA006220A0244	CP-FCC-84 C-plate Fan Coil	CP-FCC-84	1	piece
2CKA006220A0181	CP-RTC-84 C-plate RT sensor unit	CP-RTC-84	1	piece
2CKA006220A0214	MD-F-1.0.1-84 Movement detector	MD-F-1.0.1-84	1	piece
2CKA006220A0217	MSA-F-1.1.1-84 Mov. detector/actuator 1g	MSA-F-1.1.1-84	1	piece
2CKA006200A0086	MSA-F-1.1.1-84-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-84-WL	1	piece
2CKA006220A0139	SR-1-84 rocker 1gang	SR-1-84	1	piece
2CKA006220A0154	SR-2-84 rocker 2gang	SR-2-84	1	piece
2CKA006220A0145	SRB-1-84 rocker 1gang, blinds	SRB-1-84	1	piece
2CKA006220A0160	SRB-2-84 rocker 2g, blinds	SRB-2-84	1	piece
2CKA006220A0151	SRD-1-84 rocker 1gang, dimming	SRD-1-84	1	piece
2CKA006220A0166	SRD-2-L-84 rocker 2g, left, dimming	SRD-2-L-84	1	piece
2CKA006220A0260	SRD-2-R-84 rocker 2g, right, dimming	SRD-2-R-84	1	piece
2CKA006220A0142	SRL-1-84 rocker 1gang, lighting	SRL-1-84	1	piece
2CKA006220A0157	SRL-2-L-84 rocker 2g, left, lighting	SRL-2-L-84	1	piece

2CKA006220A0169	SRL-2-R-84 rocker 2g, right, lighting	SRL-2-R-84	1	piece
2CKA006220A0148	SRS-1-84 rocker 1gang, scene	SRS-1-84	1	piece
2CKA006220A0163	SRS-2-L-84 rocker 2gang, left, scene	SRS-2-L-84	1	piece
2CKA006220A0175	SRS-2-R-84 rocker 2g, right, scene	SRS-2-R-84	1	piece
2CKA001731A1921	1716-81 Cover Info light anthracite - 63x63	1716-81	1	piece
2CKA001731A1922	1716-82 Cover Info light ivory white - 63x63	1716-82	1	piece
2CKA001731A1950	1716-83 Cover Info light aluminium silver - 63x63	1716-83	1	piece
2CKA001731A2025	1716-840-500 Cover Plates LED antique brass - 63x63	1716-840-500	1	piece
2CKA001731A1955	1716-866 Cover Info light stainless steel - Pure Stainless Steel	1716-866	1	piece
2CKA001731A1978	1716-884 Cover Info light studio white matt - 63x63	1716-884	1	piece
2CKA001731A1980	1716-885 Cover Info light black matt - 63x63	1716-885	1	piece
2CKA001731A1914	1720-81 Rocker Switch Pull cord anthracite - 63x63	1720-81	1	piece
2CKA001731A1915	1720-82 Rocker Switch Pull cord ivory white - 63x63	1720-82	1	piece
2CKA001731A1949	1720-83 Rocker Switch Pull cord aluminium silver - 63x63	1720-83	1	piece
2CKA001731A1954	1720-866 Rocker Switch Pull cord stainless steel - Pure Stainless Steel	1720-866	1	piece
2CKA001731A1979	1720-884 Rocker Switch Pull cord studio white matt - 63x63	1720-884	1	piece
2CKA001731A1981	1720-885 Rocker Switch Pull cord black matt - 63x63	1720-885	1	piece
2CKA001710A4119	1740 DR/03-803 Cover Plate Level switch Turn button grey metallic - 63x63	1740 DR/03-803	1	piece
2CKA001710A4120	1740 DR/03-81 Cover Plate Level switch Turn button anthracite - 63x63	1740 DR/03-81	1	piece
2CKA001710A3807	1740 DR/03-82 Cover Plate Level switch Turn button ivory white - 63x63	1740 DR/03-82	1	piece
2CKA001710A3811	1740 DR/03-83 Cover Plate Level switch Turn button aluminium silver - 63x63	1740 DR/03-83	1	piece
2CKA001710A3812	1740 DR/03-866 Cover Plate Level switch Turn button stainless steel - Pure Stainless Steel	1740 DR/03-866	1	piece
2CKA001710A3870	1740 DR/03-884 Cover Plate Level switch Turn button studio white matt - 63x63	1740 DR/03-884	1	piece
2CKA001710A3892	1740 DR/03-885 Cover Plate Level switch Turn button black matt - 63x63	1740 DR/03-885	1	piece
2CKA001710A4121	1740 DRL-803-503 Cover Plates Level switch Turn button Symbol "3-level switch" grey metallic - 63x63	1740 DRL-803-503	1	piece
2CKA001710A4122	1740 DRL-81-503 Cover Plates Level switch Turn button Symbol "3-level switch" anthracite - 63x63	1740 DRL-81-503	1	piece
2CKA001710A3511	1740 DRL-82-503 Cover Plates Level switch Turn button Symbol "3-level switch" ivory white - 63x63	1740 DRL-82-503	1	piece
2CKA001710A4123	1740 DRL-83-503 Cover Plates Level switch Turn button Symbol "3-level switch" aluminium silver - 63x63	1740 DRL-83-503	1	piece
2CKA001710A3771	1740 DRL-866-503 Cover Plates Level switch Turn button Symbol "arrows" stainless steel - Pure Stainless Steel	1740 DRL-866-503	1	piece

2CKA001710A3871	1740 DRL-884-503 Cover Plates Level switch Turn button Symbol "3-level switch" studio white matt - 63x63	1740 DRL-884- 503	1	piece
2CKA001710A3893	1740 DRL-885-503 Cover Plates Level switch Turn button Symbol "3-level switch" black matt - 63x63	1740 DRL-885- 503	1	piece
2CKA001710A3840	1740-803 Cover Plate Venetian blind Turn button grey metallic - 63x63	1740-803	1	piece
2CKA001710A3623	1740-81 Cover Plate Venetian blind Turn button anthracite - 63x63	1740-81	1	piece
2CKA001710A3154	1740-82 Cover Plate Venetian blind Turn button ivory white - 63x63	1740-82	1	piece
2CKA001710A3661	1740-83 Cover Plate Venetian blind Turn button aluminium silver - 63x63	1740-83	1	piece
2CKA001710A4089	1740-840-500 Cover Plates Venetian blind Turn button Symbol "arrows" antique brass - 63x63	1740-840-500	1	piece
2CKA001710A3748	1740-866 Cover Plate Venetian blind Turn button stainless steel - Pure Stainless Steel	1740-866	1	piece
2CKA001710A3872	1740-884 Cover Plate Venetian blind Turn button studio white matt - 63x63	1740-884	1	piece
2CKA001710A3894	1740-885 Cover Plate Venetian blind Turn button black matt - 63x63	1740-885	1	piece
2CKA001710A3843	1742-803 Cover Plate Blind cap 1 gang(s) with Mounting plate grey metallic - 63x63	1742-803	1	piece
2CKA001710A3612	1742-81 Cover Plate Blind cap 1 gang(s) with Mounting plate anthracite - 63x63	1742-81	1	piece
2CKA001710A3143	1742-82 Cover Plate Blind cap 1 gang(s) with Mounting plate ivory white - 63x63	1742-82	1	piece
2CKA001710A3664	1742-83 Cover Plate Blind cap 1 gang(s) with Mounting plate aluminium silver - 63x63	1742-83	1	piece
2CKA001710A4080	1742-840-500 Inserts with Cover Plate Blind cap 0 pole antique brass - 63x63	1742-840-500	1	piece
2CKA001710A3751	1742-866 Cover Plate Blind cap 1 gang(s) with Mounting plate stainless steel - Pure Stainless Steel	1742-866	1	piece
2CKA001710A3873	1742-884 Cover Plate Blind cap 1 gang(s) with Mounting plate studio white matt - 63x63	1742-884	1	piece
2CKA001710A3895	1742-885 Cover Plate Blind cap 1 gang(s) with Mounting plate black matt - 63x63	1742-885	1	piece
2CKA001724A4364	1743/10-04-803 Cover Plate SAT 1 gang(s) 4 gang(s) grey metallic - 63x63	1743/10-04- 803	1	piece
2CKA001724A4365	1743/10-04-81 Cover Plate SAT 1 gang(s) 4 gang (s) anthracite - 63x63	1743/10-04-81	1	piece
2CKA001724A4366	1743/10-04-82 Cover Plate SAT 1 gang(s) 4 gang (s) ivory white - 63x63	1743/10-04-82	1	piece
2CKA001724A4367	1743/10-04-83 Cover Plate SAT 1 gang(s) 4 gang (s) aluminium silver - 63x63	1743/10-04-83	1	piece
2CKA001724A4369	1743/10-04-866 Cover Plate SAT 1 gang(s) 4 gang(s) stainless steel - Pure Stainless Steel	1743/10-04- 866	1	piece
2CKA001724A4370	1743/10-04-884 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) studio white matt - 63x63	1743/10-04- 884	1	piece
2CKA001724A4371	1743/10-04-885 Cover Plate SAT 1 gang(s) 4 gang(s) black matt - 63x63	1743/10-04- 885	1	piece
2CKA001724A4373	1743-04-803 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) grey metallic - 63x63	1743-04-803	1	piece

2CKA001724A4374	1743-04-81 Cover Plate SAT 1 gang(s) 4 gang(s) anthracite - 63x63	1743-04-81	1	piece
2CKA001724A4375	1743-04-82 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) ivory white - 63x63	1743-04-82	1	piece
2CKA001724A4376	1743-04-83 Cover Plate SAT 1 gang(s) 4 gang(s) aluminium silver - 63x63	1743-04-83	1	piece
2CKA001724A4378	1743-04-866 Cover Plate SAT 1 gang(s) 4 gang (s) stainless steel - Pure Stainless Steel	1743-04-866	1	piece
2CKA001724A4379	1743-04-884 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) studio white matt - 63x63	1743-04-884	1	piece
2CKA001724A4380	1743-04-885 Cover Plate SAT 1 gang(s) 4 gang (s) black matt - 63x63	1743-04-885	1	piece
2CKA001724A4291	1743-803 Cover Plate SAT 1 gang(s) 3 gang(s) grey metallic - 63x63	1743-803	1	piece
2CKA001724A4252	1743-81 Cover Plate SAT 1 gang(s) 3 gang(s) anthracite - 63x63	1743-81	1	piece
2CKA001724A2758	1743-82 Cover Plate SAT 1 gang(s) 3 gang(s) ivory white - 63x63	1743-82	1	piece
2CKA001724A4262	1743-83 Cover Plate SAT 1 gang(s) 3 gang(s) aluminium silver - 63x63	1743-83	1	piece
2CKA001724A4362	1743-840-500 Cover Plate SAT 3 gang(s) antique brass - 63x63	1743-840-500	1	piece
2CKA001724A4271	1743-866 Cover Plate SAT 1 gang(s) 3 gang(s) stainless steel - Pure Stainless Steel	1743-866	1	piece
2CKA001724A4293	1743-884 Cover Plate SAT 1 gang(s) 3 gang(s) studio white matt - 63x63	1743-884	1	piece
2CKA001724A4298	1743-885 Cover Plate SAT 1 gang(s) 3 gang(s) black matt - 63x63	1743-885	1	piece
2CKA001710A3855	1745-803 Cover Plate telephone connector boxes (VDo) 1 gang(s) grey metallic - 63x63	1745-803	1	piece
2CKA001710A3624	1745-81 Cover Plate telephone connector boxes (VDo) 1 gang(s) anthracite - 63x63	1745-81	1	piece
2CKA001710A3155	1745-82 Cover Plate telephone connector boxes (VDo) 1 gang(s) ivory white - 63x63	1745-82	1	piece
2CKA001710A3675	1745-83 Cover Plate telephone connector boxes (VDo) 1 gang(s) aluminium silver - 63x63	1745-83	1	piece
2CKA001710A3766	1745-866 Cover Plate telephone connector boxes (VDo) 1 gang(s) stainless steel - Pure Stainless Steel	1745-866	1	piece
2CKA001710A3874	1745-884 Cover Plate telephone connector boxes (VDo) 1 gang(s) studio white matt - 63x63	1745-884	1	piece
2CKA001710A3896	1745-885 Cover Plate telephone connector boxes (VDo) 1 gang(s) black matt - 63x63	1745-885	1	piece
2CKA001710A3857	1746/10-803 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) grey metallic - 63x63	1746/10-803	1	piece
2CKA001710A3628	1746/10-81 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) anthracite - 63x63	1746/10-81	1	piece
2CKA001710A3521	1746/10-82 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) ivory white - 63x63	1746/10-82	1	piece
2CKA001710A3677	1746/10-83 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) aluminium silver - 63x63	1746/10-83	1	piece
2CKA001710A3768	1746/10-866 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) stainless steel - Pure Stainless Steel	1746/10-866	1	piece

2CKA001710A3875	1746/10-884 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) studio white matt - 63x63	1746/10-884	1	piece
2CKA001710A3897	1746/10-885 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) black matt - 63x63	1746/10-885	1	piece
2CKA001710A3858	1746-803 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid grey metallic - 63x63	1746-803	1	piece
2CKA001710A3618	1746-81 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid anthracite - 63x63	1746-81	1	piece
2CKA001710A3149	1746-82 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid ivory white - 63x63	1746-82	1	piece
2CKA001710A3678	1746-83 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid aluminium silver - 63x63	1746-83	1	piece
2CKA001710A4086	1746-840-500 Switch Assortments 0 pole antique brass - 63x63	1746-840-500	1	piece
2CKA001710A3769	1746-866 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid stainless steel - Pure Stainless Steel	1746-866	1	piece
2CKA001710A3876	1746-884 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid studio white matt - 63x63	1746-884	1	piece
2CKA001710A3898	1746-885 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid black matt - 63x63	1746-885	1	piece
2CKA001710A4092	1747 BSI-803 Intermediate Ring Cover plates Busch-Balance® SI grey metallic - 63x63	1747 BSI-803	1	piece
2CKA001710A4093	1747 BSI-81 Intermediate Ring Cover plates Busch-Balance® SI anthracite - 63x63	1747 BSI-81	1	piece
2CKA001710A4094	1747 BSI-82 Intermediate Ring Cover plates Busch-Balance® SI ivory white - 63x63	1747 BSI-82	1	piece
2CKA001710A4095	1747 BSI-83 Intermediate Ring Cover plates Busch-Balance® SI aluminium silver - 63x63	1747 BSI-83	1	piece
2CKA001710A4097	1747 BSI-866 Intermediate Ring Cover plates Busch-Balance® SI stainless steel - Pure Stainless Steel	1747 BSI-866	1	piece
2CKA001710A4098	1747 BSI-884 Intermediate Ring Cover plates Busch-Balance® SI studio white matt - 63x63	1747 BSI-884	1	piece
2CKA001710A4099	1747 BSI-885 Intermediate Ring Cover plates Busch-Balance® SI black matt - 63x63	1747 BSI-885	1	piece
2CKA001710A3862	1747 SI-82 Intermediate Ring Cover plates Busch -Duro 2000® SI and Reflex SI ivory white - 63x63	1747 SI-82	1	piece
2CKA001710A4079	1747 SI-840-500 Cover Plates antique brass - 63x63	1747 SI-840- 500	1	piece
2CKA001710A3860	1747-82 Intermediate Ring Cover plates Busch- Duro 2000® SI and Reflex SI ivory white - 63x63	1747-82	1	piece
2CKA001710A3851	1748-803 Cover Plate Data connection 2 gang(s) grey metallic - 63x63	1748-803	1	piece
2CKA001710A3654	1748-81 Cover Plate Data connection 2 gang(s) anthracite - 63x63	1748-81	1	piece
2CKA001710A3655	1748-82 Cover Plate Data connection 2 gang(s) ivory white - 63x63	1748-82	1	piece

2CKA001710A3673	1748-83 Cover Plate Data connection 2 gang(s) aluminium silver - 63x63	1748-83	1	piece
2CKA001710A3760	1748-866 Cover Plate Data connection 2 gang(s) stainless steel - Pure Stainless Steel	1748-866	1	piece
2CKA001710A3877	1748-884 Cover Plate Data connection 2 gang(s) studio white matt - 63x63	1748-884	1	piece
2CKA001710A3899	1748-885 Cover Plate Data connection 2 gang(s) black matt - 63x63	1748-885	1	piece
2CKA001710A3844	1749-803 Cover Plate Cable outlet 1 gang(s) grey metallic - 63x63	1749-803	1	piece
2CKA001710A3614	1749-81 Cover Plate Cable outlet 1 gang(s) anthracite - 63x63	1749-81	1	piece
2CKA001710A3145	1749-82 Cover Plate Cable outlet 1 gang(s) ivory white - 63x63	1749-82	1	piece
2CKA001710A3665	1749-83 Cover Plate Cable outlet 1 gang(s) aluminium silver - 63x63	1749-83	1	piece
2CKA001710A4081	1749-840-500 Cover Plates Cable outlet 0 pole antique brass - 63x63	1749-840-500	1	piece
2CKA001710A3752	1749-866 Cover Plate Cable outlet 1 gang(s) stainless steel - Pure Stainless Steel	1749-866	1	piece
2CKA001710A3878	1749-884 Cover Plate Cable outlet 1 gang(s) studio white matt - 63x63	1749-884	1	piece
2CKA001710A3900	1749-885 Cover Plate Cable outlet 1 gang(s) black matt - 63x63	1749-885	1	piece
2CKA001710A3859	1750-803 Cover Plate BNC/TNC 2 gang(s) grey metallic - 63x63	1750-803	1	piece
2CKA001710A3617	1750-81 Cover Plate BNC/TNC 2 gang(s) anthracite - 63x63	1750-81	1	piece
2CKA001710A3148	1750-82 Cover Plate BNC/TNC 2 gang(s) ivory white - 63x63	1750-82	1	piece
2CKA001710A3679	1750-83 Cover Plate BNC/TNC 2 gang(s) aluminium silver - 63x63	1750-83	1	piece
2CKA001710A3770	1750-866 Cover Plate BNC/TNC 2 gang(s) stainless steel - Pure Stainless Steel	1750-866	1	piece
2CKA001710A3879	1750-884 Cover Plate BNC/TNC 2 gang(s) studio white matt - 63x63	1750-884	1	piece
2CKA001710A3901	1750-885 Cover Plate BNC/TNC 2 gang(s) black matt - 63x63	1750-885	1	piece
2CKA001723A0257	1751-803 Cover Plate Loudspeaker 2 gang(s) grey metallic - 63x63	1751-803	1	piece
2CKA001723A0253	1751-81 Cover Plate Loudspeaker 2 gang(s) anthracite - 63x63	1751-81	1	piece
2CKA001723A0239	1751-82 Cover Plate Loudspeaker 2 gang(s) ivory white - 63x63	1751-82	1	piece
2CKA001723A0254	1751-83 Cover Plate Loudspeaker 2 gang(s) aluminium silver - 63x63	1751-83	1	piece
2CKA001723A0255	1751-866 Cover Plate Loudspeaker 2 gang(s) stainless steel - Pure Stainless Steel	1751-866	1	piece
2CKA001723A0260	1751-884 Cover Plate Loudspeaker 2 gang(s) studio white matt - 63x63	1751-884	1	piece
2CKA001723A0259	1751-885 Cover Plate Loudspeaker 2 gang(s) black matt - 63x63	1751-885	1	piece
2CKA001710A3841	1755 SL/PZ-803-101 Cover Plate Venetian blind Key grey metallic - 63x63	1755 SL/PZ- 803-101	1	piece

2CKA001710A3626	1755 SL/PZ-81-101 Cover Plate Venetian blind Key anthracite - 63x63	1755 SL/PZ-81-101	1	piece
2CKA001710A3157	1755 SL/PZ-82-101 Cover Plate Venetian blind Key ivory white - 63x63	1755 SL/PZ-82-101	1	piece
2CKA001710A3662	1755 SL/PZ-83-101 Cover Plate Venetian blind Key aluminium silver - 63x63	1755 SL/PZ-83-101	1	piece
2CKA001710A3749	1755 SL/PZ-866-101 Cover Plate Venetian blind Key stainless steel - Pure Stainless Steel	1755 SL/PZ-866-101	1	piece
2CKA001710A3925	1755 SL/PZ-884-101 Cover Plate Venetian blind Key studio white matt - 63x63	1755 SL/PZ-884-101	1	piece
2CKA001710A3902	1755 SL/PZ-885-101 Cover Plate Venetian blind Key black matt - 63x63	1755 SL/PZ-885-101	1	piece
2CKA001753A0088	1756-803 Cover Plate Info light grey metallic - 63x63	1756-803	1	piece
2CKA001753A0089	1756-81 Cover Plate Info light anthracite - 63x63	1756-81	1	piece
2CKA001753A0091	1756-83 Cover Plate Info light aluminium silver - 63x63	1756-83	1	piece
2CKA001753A0093	1756-866 Cover Plate Info light stainless steel - Pure Stainless Steel	1756-866	1	piece
2CKA001753A0251	1756-884 Cover Plate Info light studio white matt - 63x63	1756-884	1	piece
2CKA001753A0252	1756-885 Cover Plate Info light black matt - 63x63	1756-885	1	piece
2CKA001724A4292	1758-803 Cover Plate For data connection housing 2 gang(s) grey metallic - 63x63	1758-803	1	piece
2CKA001724A4253	1758-81 Cover Plate For data connection housing 2 gang(s) anthracite - 63x63	1758-81	1	piece
2CKA001724A2759	1758-82 Cover Plate For data connection housing 2 gang(s) ivory white - 63x63	1758-82	1	piece
2CKA001724A4263	1758-83 Cover Plate For data connection housing 2 gang(s) aluminium silver - 63x63	1758-83	1	piece
2CKA001724A4272	1758-866 Cover Plate For data connection housing 2 gang(s) stainless steel - Pure Stainless Steel	1758-866	1	piece
2CKA001724A4307	1758-884 Cover Plate For data connection housing 2 gang(s) studio white matt - 63x63	1758-884	1	piece
2CKA001724A4299	1758-885 Cover Plate For data connection housing 2 gang(s) black matt - 63x63	1758-885	1	piece
2CKA001710A4103	1762-81-506 Cover Plates TDO anthracite - 63x63	1762-81-506	1	piece
2CKA001710A4104	1762-82-506 Cover Plates TDO ivory white - 63x63	1762-82-506	1	piece
2CKA001710A4105	1762-83-506 Cover Plates TDO aluminium silver - 63x63	1762-83-506	1	piece
2CKA001710A4107	1762-866-506 Cover Plates TDO stainless steel - Pure Stainless Steel	1762-866-506	1	piece
2CKA001710A4108	1762-884-506 Cover Plates TDO studio white matt - 63x63	1762-884-506	1	piece
2CKA001710A4109	1762-885-506 Cover Plates TDO black matt - 63x63	1762-885-506	1	piece
2CKA001731A3997	1764 NLI/KI-803 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp grey metallic - 63x63	1764 NLI/KI-803	1	piece
2CKA001731A3998	1764 NLI/KI-81 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp anthracite - 63x63	1764 NLI/KI-81	1	piece

2CKA001731A3999	1764 NLI/KI-82 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp ivory white - 63x63	1764 NLI/KI-82	1	piece
2CKA001731A4000	1764 NLI/KI-83 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp aluminium silver - 63x63	1764 NLI/KI-83	1	piece
2CKA001731A4003	1764 NLI/KI-866 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp stainless steel - Pure Stainless Steel	1764 NLI/KI-866	1	piece
2CKA001731A4004	1764 NLI/KI-884 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp studio white matt - 63x63	1764 NLI/KI-884	1	piece
2CKA001731A4005	1764 NLI/KI-885 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp black matt - 63x63	1764 NLI/KI-885	1	piece
2CKA001731A4011	1764 NLI-12-82-101 Rocker Switch/push button Single push button with Pilot lamp red - 63x63	1764 NLI-12-82-101	1	piece
2CKA001731A4007	1764 NLI-13-82 Rocker Switch/push button Single push button with Pilot lamp green - 63x63	1764 NLI-13-82	1	piece
2CKA001731A1975	1764 NLI-803 Rocker Switch/push button Single rocker with Pilot lamp grey metallic - 63x63	1764 NLI-803	1	piece
2CKA001731A1552	1764 NLI-81 Rocker Switch/push button Single push button with Pilot lamp anthracite - 63x63	1764 NLI-81	1	piece
2CKA001731A1876	1764 NLI-82 Rocker Switch/push button Single push button with Pilot lamp ivory white - 63x63	1764 NLI-82	1	piece
2CKA001731A1948	1764 NLI-83 Rocker Switch/push button Single push button with Pilot lamp aluminium silver - 63x63	1764 NLI-83	1	piece
2CKA001731A2024	1764 NLI-840-500 Rocker Switch/push button Single rocker Without imprint with Pilot lamp antique brass - 63x63	1764 NLI-840-500	1	piece
2CKA001731A1953	1764 NLI-866 Rocker Switch/push button Single push button with Pilot lamp stainless steel - Pure Stainless Steel	1764 NLI-866	1	piece
2CKA001731A1985	1764 NLI-884 Rocker Switch/push button Single push button with Pilot lamp studio white matt - 63x63	1764 NLI-884	1	piece
2CKA001731A1982	1764 NLI-885 Rocker Switch/push button Single push button with Pilot lamp black matt - 63x63	1764 NLI-885	1	piece
2CKA001710A3854	1766-803 Cover Plate TAE 1 gang(s) 1 gang(s) grey metallic - 63x63	1766-803	1	piece
2CKA001710A3613	1766-81 Cover Plate TAE 1 gang(s) 1 gang(s) anthracite - 63x63	1766-81	1	piece
2CKA001710A3144	1766-82 Cover Plate TAE 1 gang(s) 1 gang(s) ivory white - 63x63	1766-82	1	piece
2CKA001710A3659	1766-83 Cover Plate TAE 1 gang(s) 1 gang(s) aluminium silver - 63x63	1766-83	1	piece
2CKA001710A4084	1766-840-500 Cover Plate TAE 0 gang(s) brass - 63x63	1766-840-500	1	piece
2CKA001710A3765	1766-866 Cover Plate TAE 1 gang(s) 1 gang(s) stainless steel - Pure Stainless Steel	1766-866	1	piece
2CKA001710A3926	1766-884 Cover Plate TAE 1 gang(s) 1 gang(s) studio white matt - 63x63	1766-884	1	piece
2CKA001710A3903	1766-885 Cover Plate TAE 1 gang(s) 1 gang(s) black matt - 63x63	1766-885	1	piece
2CKA001753A0254	1770-803-103 Cover Plate Time switch Toggle grey metallic - 63x63	1770-803-103	1	piece

2CKA001753A0255	1770-81-103 Cover Plate Time switch Toggle anthracite - 63x63	1770-81-103	1	piece
2CKA001753A0256	1770-82-103 Cover Plate Time switch Toggle ivory white - 63x63	1770-82-103	1	piece
2CKA001753A0257	1770-83-103 Cover Plate Time switch Toggle aluminium silver - 63x63	1770-83-103	1	piece
2CKA001753A0259	1770-866-103 Cover Plate Time switch Toggle stainless steel - Pure Stainless Steel	1770-866-103	1	piece
2CKA001753A0260	1770-884-103 Cover Plate Time switch Toggle studio white matt - 63x63	1770-884-103	1	piece
2CKA001753A0261	1770-885-103 Cover Plate Time switch Toggle black matt - 63x63	1770-885-103	1	piece
2CKA001753A0264	1771-803-103 Cover Plate Time switch Toggle grey metallic - 63x63	1771-803-103	1	piece
2CKA001753A0265	1771-81-103 Cover Plate Time switch Toggle anthracite - 63x63	1771-81-103	1	piece
2CKA001753A0266	1771-82-103 Cover Plate Time switch Toggle ivory white - 63x63	1771-82-103	1	piece
2CKA001753A0267	1771-83-103 Cover Plate Time switch Toggle aluminium silver - 63x63	1771-83-103	1	piece
2CKA001753A0302	1771-866-103 Cover Plate Time switch Toggle stainless steel - Pure Stainless Steel	1771-866-103	1	piece
2CKA001753A0303	1771-884-103 Cover Plate Time switch Toggle studio white matt - 63x63	1771-884-103	1	piece
2CKA001753A0304	1771-885-103 Cover Plate Time switch Toggle black matt - 63x63	1771-885-103	1	piece
2CKA001751A3101	1785 JA/02-82 Rocker Venetian blind Two-part rocker Symbol "arrows" ivory white	1785 JA/02-82	1	piece
2CKA001751A3097	1785 JA/02-83 Rocker Venetian blind Two-part rocker Symbol "arrows" aluminium silver	1785 JA/02-83	1	piece
2CKA001751A3103	1785 JA/02-884 Rocker Venetian blind Two-part rocker Symbol "arrows" studio white matt	1785 JA/02-884	1	piece
2CKA001751A3105	1785 JA/02-885 Rocker Venetian blind Two-part rocker Symbol "arrows" black matt	1785 JA/02-885	1	piece
2CKA001751A3020	1785 JA-803 Rocker Venetian blind Two-part rocker Symbol "arrows" grey metallic - 63x63	1785 JA-803	1	piece
2CKA001751A2934	1785 JA-81 Rocker Venetian blind Two-part rocker Symbol "arrows" anthracite - 63x63	1785 JA-81	1	piece
2CKA001751A2748	1785 JA-82 Rocker Venetian blind Two-part rocker Symbol "arrows" ivory white - 63x63	1785 JA-82	1	piece
2CKA001751A2944	1785 JA-83 Rocker Venetian blind Two-part rocker Symbol "arrows" aluminium silver - 63x63	1785 JA-83	1	piece
2CKA001751A3120	1785 JA-840-500 Cover Plates Venetian blind Two-part rocker Symbol "arrows" antique brass - 63x63	1785 JA-840-500	1	piece
2CKA001751A2964	1785 JA-866 Rocker Venetian blind Two-part rocker Symbol "arrows" stainless steel - Pure Stainless Steel	1785 JA-866	1	piece
2CKA001751A3022	1785 JA-884 Rocker Venetian blind Two-part rocker Symbol "arrows" studio white matt - 63x63	1785 JA-884	1	piece
2CKA001751A3036	1785 JA-885 Rocker Venetian blind Two-part rocker Symbol "arrows" black matt - 63x63	1785 JA-885	1	piece
2CKA001751A3126	1785 K-83-500 Cover Plates Switch/push button Two-part rocker None aluminium silver - 63x63	1785 K-83-500	1	piece
2CKA001751A3204	1785/11-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1785/11-803	1	piece

2CKA001751A3205	1785/11-81 Rocker Switch/push button Two-part rocker anthracite - 63x63	1785/11-81	1	piece
2CKA001751A2991	1785/11-82 Rocker Switch/push button Two-part rocker ivory white - 63x63	1785/11-82	1	piece
2CKA001751A2995	1785/11-83 Rocker Switch/push button Two-part rocker aluminium silver - 63x63	1785/11-83	1	piece
2CKA001751A3119	1785/11-840-500 Cover Plates Switch/push button Two-part rocker antique brass - 63x63	1785/11-840- 500	1	piece
2CKA001751A2996	1785/11-866 Rocker Switch/push button Two-part rocker stainless steel - Pure Stainless Steel	1785/11-866	1	piece
2CKA001751A3023	1785/11-884 Rocker Switch/push button Two-part rocker studio white matt - 63x63	1785/11-884	1	piece
2CKA001751A3037	1785/11-885 Rocker Switch/push button Two-part rocker black matt - 63x63	1785/11-885	1	piece
2CKA001751A3018	1785-803 Rocker Switch/push button Two-part rocker grey metallic - 63x63	1785-803	1	piece
2CKA001751A2930	1785-81 Rocker Switch/push button Two-part rocker anthracite - 63x63	1785-81	1	piece
2CKA001751A2744	1785-82 Rocker Switch/push button Two-part rocker ivory white - 63x63	1785-82	1	piece
2CKA001751A2942	1785-83 Rocker Switch/push button Two-part rocker aluminium silver - 63x63	1785-83	1	piece
2CKA001751A3092	1785-83-500 Cover Plates Switch/push button Two-part rocker Without imprint aluminium silver - 63x63	1785-83-500	1	piece
2CKA001751A3117	1785-840-500 Cover Plates Switch/push button Two-part rocker Without imprint antique brass - 63x63	1785-840-500	1	piece
2CKA001751A3087	1785-866-500 Cover Plates Switch/push button Two-part rocker Without imprint stainless steel - Pure Stainless Steel	1785-866-500	1	piece
2CKA001751A3024	1785-884 Rocker Switch/push button Two-part rocker studio white matt - 63x63	1785-884	1	piece
2CKA001751A3038	1785-885 Rocker Switch/push button Two-part rocker black matt - 63x63	1785-885	1	piece
2CKA001751A3100	1786 JA/02-82 Rocker Venetian blind Single rocker ivory white	1786 JA/02-82	1	piece
2CKA001751A3096	1786 JA/02-83 Rocker Switch/push button Symbol "arrows" aluminium silver	1786 JA/02-83	1	piece
2CKA001751A3102	1786 JA/02-884 Rocker Venetian blind Single rocker studio white matt	1786 JA/02- 884	1	piece
2CKA001751A3104	1786 JA/02-885 Rocker Symbol "arrows" black matt	1786 JA/02- 885	1	piece
2CKA001751A3207	1786/11-81 Rocker Switch/push button Single rocker anthracite - 63x63	1786/11-81	1	piece
2CKA001751A2997	1786/11-82 Rocker Switch/push button Single rocker ivory white - 63x63	1786/11-82	1	piece
2CKA001751A3001	1786/11-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1786/11-83	1	piece
2CKA001751A3002	1786/11-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1786/11-866	1	piece
2CKA001751A3026	1786/11-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1786/11-884	1	piece
2CKA001751A3040	1786/11-885 Rocker Switch/push button Single rocker black matt - 63x63	1786/11-885	1	piece

2CKA001751A3145	1786-12-82 Rocker Switch/push button Single rocker red - 63x63	1786-12-82	1	piece
2CKA001751A3093	1786-803-500 Cover Plates Switch/push button Single rocker Without imprint grey metallic - 63x63	1786-803-500	1	piece
2CKA001751A3079	1786-81-500 Cover Plates Switch/push button Single rocker Without imprint anthracite - 63x63	1786-81-500	1	piece
2CKA001751A3083	1786-82-500 Cover Plates Switch/push button Single rocker Without imprint ivory white - 63x63	1786-82-500	1	piece
2CKA001751A3075	1786-83-500 Cover Plates Switch/push button Single rocker Without imprint aluminium silver - 63x63	1786-83-500	1	piece
2CKA001751A3116	1786-840-500 Cover Plates Switch/push button Single rocker Without imprint antique brass - 63x63	1786-840-500	1	piece
2CKA001751A3077	1786-866-500 Cover Plates Switch/push button Single rocker Without imprint stainless steel - Pure Stainless Steel	1786-866-500	1	piece
2CKA001751A3089	1786-884-500 Cover Plates Switch/push button Single rocker Without imprint studio white matt - 63x63	1786-884-500	1	piece
2CKA001751A3094	1786-885-500 Cover Plates Switch/push button Single rocker Without imprint black matt - 63x63	1786-885-500	1	piece
2CKA001751A3017	1788-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1788-803	1	piece
2CKA001751A2927	1788-81 Rocker Switch/push button Single rocker anthracite - 63x63	1788-81	1	piece
2CKA001751A2742	1788-82 Rocker Switch/push button Single rocker ivory white - 63x63	1788-82	1	piece
2CKA001751A2954	1788-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1788-83	1	piece
2CKA001751A2961	1788-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1788-866	1	piece
2CKA001751A3028	1788-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1788-884	1	piece
2CKA001751A3042	1788-885 Rocker Switch/push button Single rocker black matt - 63x63	1788-885	1	piece
2CKA001751A3019	1789 H-803 Rocker Switch/push button Single rocker Heizung grey metallic - 63x63	1789 H-803	1	piece
2CKA001751A2929	1789 H-81 Rocker Switch/push button Single rocker Heizung anthracite - 63x63	1789 H-81	1	piece
2CKA001751A2743	1789 H-82 Rocker Switch/push button Single rocker Heizung ivory white - 63x63	1789 H-82	1	piece
2CKA001751A2955	1789 H-83 Rocker Switch/push button Single rocker Heizung aluminium silver - 63x63	1789 H-83	1	piece
2CKA001751A2963	1789 H-866 Rocker Switch/push button Single rocker Heizung stainless steel - Pure Stainless Steel	1789 H-866	1	piece
2CKA001751A3029	1789 H-884 Rocker Switch/push button Single rocker Heizung studio white matt - 63x63	1789 H-884	1	piece
2CKA001751A3043	1789 H-885 Rocker Switch/push button Single rocker Heizung black matt - 63x63	1789 H-885	1	piece
2CKA001751A3015	1789 KI-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 KI-803	1	piece
2CKA001751A2932	1789 KI-81 Rocker Switch/push button Single rocker Symbol "bell" anthracite - 63x63	1789 KI-81	1	piece

2CKA001751A2746	1789 KI-82 Rocker Switch/push button Single rocker Symbol "bell" ivory white - 63x63	1789 KI-82	1	piece
2CKA001751A2952	1789 KI-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 KI-83	1	piece
2CKA001751A2959	1789 KI-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 KI-866	1	piece
2CKA001751A3030	1789 KI-884 Rocker Switch/push button Single rocker Symbol "bell" studio white matt - 63x63	1789 KI-884	1	piece
2CKA001751A3044	1789 KI-885 Rocker Switch/push button Single rocker Symbol "bell" black matt - 63x63	1789 KI-885	1	piece
2CKA001751A3014	1789 LI-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 LI-803	1	piece
2CKA001751A2931	1789 LI-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 LI-81	1	piece
2CKA001751A2745	1789 LI-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 LI-82	1	piece
2CKA001751A2951	1789 LI-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 LI-83	1	piece
2CKA001751A2958	1789 LI-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 LI-866	1	piece
2CKA001751A3031	1789 LI-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 LI-884	1	piece
2CKA001751A3045	1789 LI-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 LI-885	1	piece
2CKA001751A3146	1789 N-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 N-803	1	piece
2CKA001751A3147	1789 N-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 N-81	1	piece
2CKA001751A3148	1789 N-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 N-82	1	piece
2CKA001751A3149	1789 N-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 N-83	1	piece
2CKA001751A3152	1789 N-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 N-866	1	piece
2CKA001751A3153	1789 N-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 N-884	1	piece
2CKA001751A3154	1789 N-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 N-885	1	piece
2CKA001751A3156	1789 ST-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 ST-803	1	piece
2CKA001751A3157	1789 ST-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 ST-81	1	piece
2CKA001751A3158	1789 ST-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 ST-82	1	piece
2CKA001751A3159	1789 ST-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 ST-83	1	piece
2CKA001751A3162	1789 ST-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 ST-866	1	piece
2CKA001751A3163	1789 ST-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 ST-884	1	piece
2CKA001751A3164	1789 ST-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 ST-885	1	piece
2CKA001751A3016	1789 TR-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 TR-803	1	piece

2CKA001751A2933	1789 TR-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 TR-81	1	piece
2CKA001751A2747	1789 TR-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 TR-82	1	piece
2CKA001751A2953	1789 TR-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 TR-83	1	piece
2CKA001751A2960	1789 TR-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 TR-866	1	piece
2CKA001751A3032	1789 TR-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 TR-884	1	piece
2CKA001751A3046	1789 TR-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 TR-885	1	piece
2CKA001751A3013	1789-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789-803	1	piece
2CKA001751A2928	1789-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789-81	1	piece
2CKA001751A2813	1789-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789-82	1	piece
2CKA001751A2945	1789-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789-83	1	piece
2CKA001751A3118	1789-840-500 Cover Plates Switch/push button Single rocker Without imprint antique brass - 63x63	1789-840-500	1	piece
2CKA001751A2957	1789-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789-866	1	piece
2CKA001751A3033	1789-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789-884	1	piece
2CKA001751A3047	1789-885 Rocker Switch/push button Single rocker black matt - 63x63	1789-885	1	piece
2CKA001710A4124	1792-803 Cover Plate Switch/push button Hotel card grey metallic - 63x63	1792-803	1	piece
2CKA001710A3639	1792-81 Cover Plate Switch/push button Hotel card anthracite - 63x63	1792-81	1	piece
2CKA001710A3640	1792-82 Cover Plate Switch/push button Hotel card ivory white - 63x63	1792-82	1	piece
2CKA001710A3670	1792-83 Cover Plate Switch/push button Hotel card aluminium silver - 63x63	1792-83	1	piece
2CKA001710A4078	1792-840-500 Cover Plates Switch/push button Hotel card antique brass - 63x63	1792-840-500	1	piece
2CKA001710A3757	1792-866 Cover Plate Switch/push button Hotel card stainless steel - Pure Stainless Steel	1792-866	1	piece
2CKA001710A3928	1792-884 Cover Plate Switch/push button Hotel card studio white matt - 63x63	1792-884	1	piece
2CKA001710A3905	1792-885 Cover Plate Switch/push button Hotel card black matt - 63x63	1792-885	1	piece
2CKA001710A3849	1794 TA-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1794 TA-803	1	piece
2CKA001710A3695	1794 TA-81 Cover Plate Thermostat Turn button anthracite - 63x63	1794 TA-81	1	piece
2CKA001710A3696	1794 TA-82 Cover Plate Thermostat Turn button ivory white - 63x63	1794 TA-82	1	piece
2CKA001710A3697	1794 TA-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1794 TA-83	1	piece
2CKA001710A3761	1794 TA-866 Cover Plate Thermostat Turn button stainless steel - Pure Stainless Steel	1794 TA-866	1	piece

2CKA001710A3883	1794 TA-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1794 TA-884	1	piece
2CKA001710A3906	1794 TA-885 Cover Plate Thermostat Turn button black matt - 63x63	1794 TA-885	1	piece
2CKA001710A3847	1794-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1794-803	1	piece
2CKA001710A3629	1794-81 Cover Plate Thermostat Turn button anthracite - 63x63	1794-81	1	piece
2CKA001710A3543	1794-82 Cover Plate Thermostat Turn button ivory white - 63x63	1794-82	1	piece
2CKA001710A3668	1794-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1794-83	1	piece
2CKA001710A4087	1794-840-500 Cover Plates antique brass - 63x63	1794-840-500	1	piece
2CKA001710A3755	1794-866 Cover Plate Thermostat stainless steel - Pure Stainless Steel	1794-866	1	piece
2CKA001710A3884	1794-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1794-884	1	piece
2CKA001710A3907	1794-885 Cover Plate Thermostat Turn button black matt - 63x63	1794-885	1	piece
2CKA001710A4012	1795 HK-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1795 HK-803	1	piece
2CKA001710A4013	1795 HK-81 Cover Plate Thermostat Turn button anthracite - 63x63	1795 HK-81	1	piece
2CKA001710A4015	1795 HK-82 Cover Plate Thermostat Turn button ivory white - 63x63	1795 HK-82	1	piece
2CKA001710A4016	1795 HK-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1795 HK-83	1	piece
2CKA001710A4018	1795 HK-866 Cover Plate Thermostat Turn button stainless steel - Pure Stainless Steel	1795 HK-866	1	piece
2CKA001710A4019	1795 HK-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1795 HK-884	1	piece
2CKA001710A4020	1795 HK-885 Cover Plate Thermostat Turn button black matt - 63x63	1795 HK-885	1	piece
2CKA001710A4044	1795 HKEA-803 Cover Plate Thermostat Turn button 1 switchover grey metallic - 63x63	1795 HKEA- 803	1	piece
2CKA001710A4045	1795 HKEA-81 Cover Plate Thermostat Turn button 1 switchover anthracite - 63x63	1795 HKEA-81	1	piece
2CKA001710A4047	1795 HKEA-82 Cover Plate Thermostat Turn button 1 switchover ivory white - 63x63	1795 HKEA-82	1	piece
2CKA001710A4048	1795 HKEA-83 Cover Plate Thermostat Turn button 1 switchover aluminium silver - 63x63	1795 HKEA-83	1	piece
2CKA001710A4050	1795 HKEA-866 Cover Plate Thermostat Turn button 1 switchover stainless steel - Pure Stainless Steel	1795 HKEA- 866	1	piece
2CKA001710A4051	1795 HKEA-884 Cover Plate Thermostat Turn button 1 switchover studio white matt - 63x63	1795 HKEA- 884	1	piece
2CKA001710A4052	1795 HKEA-885 Cover Plate Thermostat Turn button 1 switchover black matt - 63x63	1795 HKEA- 885	1	piece
2CKA001710A3850	1795 TA-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1795 TA-803	1	piece
2CKA001710A3722	1795 TA-81 Cover Plate Thermostat Turn button anthracite - 63x63	1795 TA-81	1	piece
2CKA001710A3723	1795 TA-82 Cover Plate Thermostat Turn button ivory white - 63x63	1795 TA-82	1	piece

2CKA001710A3724	1795 TA-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1795 TA-83	1	piece
2CKA001710A3762	1795 TA-866 Cover Plate Thermostat Turn button stainless steel - Pure Stainless Steel	1795 TA-866	1	piece
2CKA001710A3885	1795 TA-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1795 TA-884	1	piece
2CKA001710A3908	1795 TA-885 Cover Plate Thermostat Turn button black matt - 63x63	1795 TA-885	1	piece
2CKA001710A3848	1795-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1795-803	1	piece
2CKA001710A3630	1795-81 Cover Plate Thermostat Turn button anthracite - 63x63	1795-81	1	piece
2CKA001710A3568	1795-82 Cover Plate Thermostat Turn button ivory white - 63x63	1795-82	1	piece
2CKA001710A3669	1795-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1795-83	1	piece
2CKA001710A4088	1795-840-500 Cover Plates antique brass - 63x63	1795-840-500	1	piece
2CKA001710A3756	1795-866 Cover Plate Thermostat Turn button stainless steel - Pure Stainless Steel	1795-866	1	piece
2CKA001710A3886	1795-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1795-884	1	piece
2CKA001710A3909	1795-885 Cover Plate Thermostat Turn button black matt - 63x63	1795-885	1	piece
2CKA001753A0307	1796-803 Cover Plate Pull cord grey metallic - 63x63	1796-803	1	piece
2CKA001753A0308	1796-81 Cover Plate Pull cord anthracite - 63x63	1796-81	1	piece
2CKA001753A0309	1796-82 Cover Plate Pull cord ivory white - 63x63	1796-82	1	piece
2CKA001753A0310	1796-83 Cover Plate Pull cord aluminium silver - 63x63	1796-83	1	piece
2CKA001753A0312	1796-866 Cover Plate Pull cord stainless steel - Pure Stainless Steel	1796-866	1	piece
2CKA001753A0313	1796-884 Cover Plate Pull cord studio white matt - 63x63	1796-884	1	piece
2CKA001753A0314	1796-885 Cover Plate Pull cord black matt - 63x63	1796-885	1	piece
2CKA001710A3856	1800-803 Cover Plate Modular Jack 1 gang(s) 2 gang(s) grey metallic - 63x63	1800-803	1	piece
2CKA001710A3627	1800-81 Cover Plate Modular Jack 1 gang(s) 2 gang(s) anthracite - 63x63	1800-81	1	piece
2CKA001710A3158	1800-82 Cover Plate Modular Jack 1 gang(s) 2 gang(s) ivory white - 63x63	1800-82	1	piece
2CKA001710A3676	1800-83 Cover Plate Modular Jack 1 gang(s) 2 gang(s) aluminium silver - 63x63	1800-83	1	piece
2CKA001710A4085	1800-840-500 Cover Plate Modular Jack 2 gang (s) antique brass - 63x63	1800-840-500	1	piece
2CKA001710A3767	1800-866 Cover Plate Modular Jack 1 gang(s) 2 gang(s) stainless steel - Pure Stainless Steel	1800-866	1	piece
2CKA001710A3887	1800-884 Cover Plate Modular Jack 1 gang(s) 2 gang(s) studio white matt - 63x63	1800-884	1	piece
2CKA001710A3910	1800-885 Cover Plate Modular Jack 1 gang(s) 2 gang(s) black matt - 63x63	1800-885	1	piece
2CKA001710A3853	1803-02-803 Cover Plate UAE/IAE (ISDN) 2 gang (s) 2 gang(s) grey metallic - 63x63	1803-02-803	1	piece
2CKA001710A3615	1803-02-81 Cover Plate UAE/IAE (ISDN) 2 gang (s) 2 gang(s) anthracite - 63x63	1803-02-81	1	piece

2CKA001710A3146	1803-02-82 Cover Plate UAE/IAE (ISDN) 2 gang (s) 2 gang(s) ivory white - 63x63	1803-02-82	1	piece
2CKA001710A3610	1803-02-83 Cover Plate UAE/IAE (ISDN) 2 gang (s) 2 gang(s) aluminium silver - 63x63	1803-02-83	1	piece
2CKA001710A4083	1803-02-840-500 Cover Plate UAE/IAE (ISDN) 2 gang(s) antique brass - 63x63	1803-02-840- 500	1	piece
2CKA001710A3764	1803-02-866 Cover Plate UAE/IAE (ISDN) 2 gang (s) 2 gang(s) stainless steel - Pure Stainless Steel	1803-02-866	1	piece
2CKA001710A3888	1803-02-884 Cover Plate UAE/IAE (ISDN) 2 gang (s) 2 gang(s) studio white matt - 63x63	1803-02-884	1	piece
2CKA001710A3911	1803-02-885 Cover Plate UAE/IAE (ISDN) 2 gang (s) 2 gang(s) black matt - 63x63	1803-02-885	1	piece
2CKA001710A3852	1803-803 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) grey metallic - 63x63	1803-803	1	piece
2CKA001710A3616	1803-81 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) anthracite - 63x63	1803-81	1	piece
2CKA001710A3147	1803-82 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) ivory white - 63x63	1803-82	1	piece
2CKA001710A3674	1803-83 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) aluminium silver - 63x63	1803-83	1	piece
2CKA001710A4082	1803-840-500 Cover Plate UAE/IAE (ISDN) 1 gang(s) antique brass - 63x63	1803-840-500	1	piece
2CKA001710A3763	1803-866 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) stainless steel - Pure Stainless Steel	1803-866	1	piece
2CKA001710A3889	1803-884 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) studio white matt - 63x63	1803-884	1	piece
2CKA001710A3912	1803-885 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) black matt - 63x63	1803-885	1	piece
2CKA002013A5404	20 EUAB-81 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUAB-81	1	piece
2CKA002013A5405	20 EUAB-82 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUAB-82	1	piece
2CKA002013A5406	20 EUAB-83 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUAB-83	1	piece
2CKA002013A5408	20 EUAB-866 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUAB-866	1	piece
2CKA002013A5409	20 EUAB-884 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUAB-884	1	piece
2CKA002013A5410	20 EUAB-885 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUAB-885	1	piece
2CKA002011A6260	20 EUC-13-82-101 Socket insert Protective Contact (SCHUKO) 1gang(s) green - 63x63	20 EUC-13-82- 101	1	piece
2CKA002011A3723	20 EUC-14-82 Socket Protective Contact (SCHUKO) 1gang(s) orange - 63x63	20 EUC-14-82	1	piece
2CKA002011A6216	20 EUC-803-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) grey metallic - 63x63	20 EUC-803- 500	1	piece
2CKA002011A6215	20 EUC-81-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) anthracite - 63x63	20 EUC-81- 500	1	piece

2CKA002011A6214	20 EUC-82-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) ivory white - 63x63	20 EUC-82- 500	1	piece
2CKA002011A6213	20 EUC-83-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) aluminium silver - 63x63	20 EUC-83- 500	1	piece
2CKA002011A6212	20 EUC-866-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) stainless steel - Pure Stainless Steel	20 EUC-866- 500	1	piece
2CKA002011A6208	20 EUC-884-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white matt - 63x63	20 EUC-884- 500	1	piece
2CKA002011A6211	20 EUC-885-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) black matt - 63x63	20 EUC-885- 500	1	piece
2CKA002013A5472	20 EUCB-13-82-102 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) green - 63x63	20 EUCB-13- 82-102	1	piece
2CKA002013A5413	20 EUCB-14-82-10 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) orange - 63x63	20 EUCB-14- 82-10	1	piece
2CKA002013A5414	20 EUCBDR-803 Socket insert Busch-Service- Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUCBDR- 803	1	piece
2CKA002013A5415	20 EUCBDR-81 Socket insert Busch-Service- Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCBDR- 81	1	piece
2CKA002013A5416	20 EUCBDR-82 Socket insert Busch-Service- Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUCBDR- 82	1	piece
2CKA002013A5417	20 EUCBDR-83 Socket insert Busch-Service- Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUCBDR- 83	1	piece
2CKA002013A5419	20 EUCBDR-866 Socket insert Busch-Service- Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUCBDR- 866	1	piece
2CKA002013A5420	20 EUCBDR-884 Socket insert Busch-Service- Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUCBDR- 884	1	piece
2CKA002013A5421	20 EUCBDR-885 Socket insert Busch-Service- Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCBDR- 885	1	piece
2CKA002013A5467	20 EUCBL-13-84-101 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) green - 63x63	20 EUCBL-13- 84-101	1	piece
2CKA002013A5288	20 EUCBL-14-84 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) orange - 63x63	20 EUCBL-14- 84	1	piece
2CKA002013A5456	20 EUCBL-803 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) grey metallic - 63x63	20 EUCBL-803	1	piece
2CKA002013A5457	20 EUCBL-81 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) anthracite - 63x63	20 EUCBL-81	1	piece
2CKA002013A5284	20 EUCBL-82 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) ivory white - 63x63	20 EUCBL-82	1	piece

2CKA002013A5285	20 EUCBL-83 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) aluminium silver - 63x63	20 EUCBL-83	1	piece
2CKA002013A5289	20 EUCBL-866 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) stainless steel - Pure Stainless Steel	20 EUCBL-866	1	piece
2CKA002013A5336	20 EUCBL-884 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) studio white matt - 63x63	20 EUCBL-884	1	piece
2CKA002013A5330	20 EUCBL-885 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) black matt - 63x63	20 EUCBL-885	1	piece
2CKA002013A5458	20 EUCBLI-803 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) grey metallic - 63x63	20 EUCBLI-803	1	piece
2CKA002013A5459	20 EUCBLI-81 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) anthracite - 63x63	20 EUCBLI-81	1	piece
2CKA002013A5292	20 EUCBLI-82 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) ivory white - 63x63	20 EUCBLI-82	1	piece
2CKA002013A5293	20 EUCBLI-83 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) aluminium silver - 63x63	20 EUCBLI-83	1	piece
2CKA002013A5399	20 EUCBLI-840-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass - 63x63	20 EUCBLI-840-500	1	piece
2CKA002013A5460	20 EUCBLI-866 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) stainless steel - Pure Stainless Steel	20 EUCBLI-866	1	piece
2CKA002013A5326	20 EUCBLI-884 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) studio white matt - 63x63	20 EUCBLI-884	1	piece
2CKA002013A5331	20 EUCBLI-885 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) black matt - 63x63	20 EUCBLI-885	1	piece
2CKA002013A5463	20 EUCKS/DV-12-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) red - 63x63	20 EUCKS/DV-12-82-101	1	piece
2CKA002013A5462	20 EUCKS/DV-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUCKS/DV-803	1	piece
2CKA002013A5266	20 EUCKS/DV-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCKS/DV-81	1	piece
2CKA002013A5267	20 EUCKS/DV-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUCKS/DV-82	1	piece
2CKA002013A5273	20 EUCKS/DV-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUCKS/DV-83	1	piece
2CKA002013A5277	20 EUCKS/DV-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUCKS/DV-866	1	piece
2CKA002013A5327	20 EUCKS/DV-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUCKS/DV-884	1	piece
2CKA002013A5332	20 EUCKS/DV-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCKS/DV-885	1	piece

2CKA002013A5464	20 EUCKS-12-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) red - 63x63	20 EUCKS-12-82-101	1	piece
2CKA002013A5470	20 EUCKS-13-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) green - 63x63	20 EUCKS-13-82-101	1	piece
2CKA002013A5324	20 EUCKS-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) orange - 63x63	20 EUCKS-14-82	1	piece
2CKA002013A5297	20 EUCKS-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUCKS-803	1	piece
2CKA002013A5265	20 EUCKS-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCKS-81	1	piece
2CKA002013A5376	20 EUCKS-82-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) ivory white - 63x63	20 EUCKS-82-500	1	piece
2CKA002013A5375	20 EUCKS-83-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) aluminium silver - 63x63	20 EUCKS-83-500	1	piece
2CKA002013A5401	20 EUCKS-845-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass anthracite - 63x63	20 EUCKS-845-500	1	piece
2CKA002013A5398	20 EUCKS-848-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass ivory white - 63x63	20 EUCKS-848-500	1	piece
2CKA002013A5374	20 EUCKS-866-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) stainless steel - Pure Stainless Steel	20 EUCKS-866-500	1	piece
2CKA002013A5373	20 EUCKS-884-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white matt - 63x63	20 EUCKS-884-500	1	piece
2CKA002013A5333	20 EUCKS-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCKS-885	1	piece
2CKA002013A5423	20 EUCNB-12-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) red - 63x63	20 EUCNB-12-82	1	piece
2CKA002013A5424	20 EUCNB-13-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) green - 63x63	20 EUCNB-13-82	1	piece
2CKA002013A5425	20 EUCNB-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) orange - 63x63	20 EUCNB-14-82	1	piece
2CKA002013A5426	20 EUCNB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUCNB-803	1	piece
2CKA002013A5427	20 EUCNB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCNB-81	1	piece
2CKA002013A5428	20 EUCNB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUCNB-82	1	piece
2CKA002013A5429	20 EUCNB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUCNB-83	1	piece
2CKA002013A5432	20 EUCNB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUCNB-866	1	piece

2CKA002013A5433	20 EUCNB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUCNB-884	1	piece
2CKA002013A5434	20 EUCNB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCNB-885	1	piece
2CKA002013A5436	20 EUCRB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUCRB-803	1	piece
2CKA002013A5437	20 EUCRB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCRB-81	1	piece
2CKA002013A5438	20 EUCRB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUCRB-82	1	piece
2CKA002013A5439	20 EUCRB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUCRB-83	1	piece
2CKA002013A5442	20 EUCRB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUCRB-866	1	piece
2CKA002013A5443	20 EUCRB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUCRB-884	1	piece
2CKA002013A5444	20 EUCRB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCRB-885	1	piece
2CKA002018A1493	20 EUK-803 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUK-803	1	piece
2CKA002018A1486	20 EUK-81 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid anthracite - 63x63	20 EUK-81	1	piece
2CKA002018A1465	20 EUK-82 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid ivory white - 63x63	20 EUK-82	1	piece
2CKA002018A1487	20 EUK-83 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUK-83	1	piece
2CKA002018A1515	20 EUK-840-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) with Hinged Lid antique brass - 63x63	20 EUK-840-500	1	piece
2CKA002018A1490	20 EUK-866 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid stainless steel - Pure Stainless Steel	20 EUK-866	1	piece
2CKA002018A1494	20 EUK-884 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUK-884	1	piece
2CKA002018A1495	20 EUK-885 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid black matt - 63x63	20 EUK-885	1	piece
2CKA002018A1516	20 EUKB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUKB-803	1	piece
2CKA002018A1517	20 EUKB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKB-81	1	piece
2CKA002018A1518	20 EUKB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKB-82	1	piece

2CKA002018A1519	20 EUKB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKB-83	1	piece
2CKA002018A1521	20 EUKB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid stainless steel - Pure Stainless Steel	20 EUKB-866	1	piece
2CKA002018A1522	20 EUKB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKB-884	1	piece
2CKA002018A1523	20 EUKB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKB-885	1	piece
2CKA002018A1525	20 EUKBR-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUKBR-803	1	piece
2CKA002018A1526	20 EUKBR-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKBR-81	1	piece
2CKA002018A1527	20 EUKBR-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKBR-82	1	piece
2CKA002018A1528	20 EUKBR-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKBR-83	1	piece
2CKA002018A1530	20 EUKBR-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKBR-884	1	piece
2CKA002018A1531	20 EUKBR-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKBR-885	1	piece
2CKA002018A1533	20 EUKNB-12-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid red - 63x63	20 EUKNB-12-82	1	piece
2CKA002018A1534	20 EUKNB-13-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid green - 63x63	20 EUKNB-13-82	1	piece
2CKA002018A1535	20 EUKNB-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid orange - 63x63	20 EUKNB-14-82	1	piece
2CKA002018A1536	20 EUKNB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUKNB-803	1	piece
2CKA002018A1537	20 EUKNB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKNB-81	1	piece
2CKA002018A1538	20 EUKNB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKNB-82	1	piece
2CKA002018A1539	20 EUKNB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKNB-83	1	piece
2CKA002018A1541	20 EUKNB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKNB-884	1	piece
2CKA002018A1542	20 EUKNB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKNB-885	1	piece
2CKA002018A1544	20 EUKNBL-12-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid red - 63x63	20 EUKNBL-12-82	1	piece

2CKA002018A1545	20 EUKNBL-13-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid green - 63x63	20 EUKNBL-13-82	1	piece
2CKA002018A1546	20 EUKNBL-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid orange - 63x63	20 EUKNBL-14-82	1	piece
2CKA002018A1547	20 EUKNBL-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUKNBL-803	1	piece
2CKA002018A1548	20 EUKNBL-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKNBL-81	1	piece
2CKA002018A1552	20 EUKNBL-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKNBL-884	1	piece
2CKA002018A1553	20 EUKNBL-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKNBL-885	1	piece
2CKA002018A1557	20 EUKNBSL-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKNBSL-81	1	piece
2CKA002018A1558	20 EUKNBSL-81-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKNBSL-81-101	1	piece
2CKA002018A1559	20 EUKNBSL-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKNBSL-82	1	piece
2CKA002018A1560	20 EUKNBSL-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKNBSL-82-101	1	piece
2CKA002018A1561	20 EUKNBSL-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKNBSL-83	1	piece
2CKA002018A1562	20 EUKNBSL-83-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKNBSL-83-101	1	piece
2CKA002018A1565	20 EUKNBSL-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKNBSL-884	1	piece
2CKA002018A1566	20 EUKNBSL-884-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKNBSL-884-101	1	piece
2CKA002018A1567	20 EUKNBSL-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKNBSL-885	1	piece
2CKA002018A1568	20 EUKNBSL-885-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKNBSL-885-101	1	piece
2CKA002011A3876	20 EUN-803 Socket insert Protective Contact (SCHUKO) 1gang(s) grey metallic - 63x63	20 EUN-803	1	piece
2CKA002011A3802	20 EUN-81 Socket insert Protective Contact (SCHUKO) 1gang(s) anthracite - 63x63	20 EUN-81	1	piece
2CKA002011A3726	20 EUN-82 Socket insert Protective Contact (SCHUKO) 1gang(s) ivory white - 63x63	20 EUN-82	1	piece
2CKA002011A3810	20 EUN-83 Socket insert Protective Contact (SCHUKO) 1gang(s) aluminium silver - 63x63	20 EUN-83	1	piece
2CKA002011A3851	20 EUN-866 Socket insert Protective Contact (SCHUKO) 1gang(s) stainless steel - Pure Stainless Steel	20 EUN-866	1	piece

2CKA002011A3881	20 EUN-884 Socket insert Protective Contact (SCHUKO) 1gang(s) studio white matt - 63x63	20 EUN-884	1	piece
2CKA002011A3884	20 EUN-885 Socket insert Protective Contact (SCHUKO) 1gang(s) black matt - 63x63	20 EUN-885	1	piece
2CKA002017A0785	20 MUC-82-500 Socket insert Earthing Pin 1gang(s) ivory white - 63x63	20 MUC-82-500	1	piece
2CKA002017A0852	20 MUCKS-803-500 Inserts with Cover Plate 1gang(s) grey metallic - 63x63	20 MUCKS-803-500	1	piece
2CKA002017A0898	20 MUCKS-81-500 Socket insert Safety Shutter 1gang(s) anthracite - 63x63	20 MUCKS-81-500	1	piece
2CKA002017A0806	20 MUCKS-82-500 Socket insert Earthing Pin Safety Shutter 1gang(s) ivory white - 63x63	20 MUCKS-82-500	1	piece
2CKA002017A0899	20 MUCKS-83-500 Socket insert Safety Shutter 1gang(s) aluminium silver - 63x63	20 MUCKS-83-500	1	piece
2CKA002017A0900	20 MUCKS-866-500 Socket insert Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 MUCKS-866-500	1	piece
2CKA002017A0901	20 MUCKS-884-500 Socket insert Safety Shutter 1gang(s) studio white matt - 63x63	20 MUCKS-884-500	1	piece
2CKA002017A0902	20 MUCKS-885-500 Socket insert Safety Shutter 1gang(s) black matt - 63x63	20 MUCKS-885-500	1	piece
2CKA001510A0005	2068/11-84 Cover Reflector Ambient / orientation lightning	2068/11-84	1	piece
2CKA001510A0008	2068/14-84 Cover Reflector Ambient / orientation lightning, Infolight	2068/14-84	1	piece
2CKA001510A0017	2068/22-84 Cover Ambient lightning - 63x63	2068/22-84	1	piece
2CKA001510A0015	2069/11-84 Busch-iceLight set LED studio white - future linear	2069/11-84	1	piece
2CKA002495A0084	2095 UC-81 Socket insert Equipotential compensation anthracite - 63x63	2095 UC-81	1	piece
2CKA002495A0085	2095 UC-82 Socket insert Equipotential compensation white - 63x63	2095 UC-82	1	piece
2CKA002495A0089	2095 UC-83 Socket insert Equipotential compensation aluminium - 63x63	2095 UC-83	1	piece
2CKA002495A0090	2095 UC-866 Socket insert Equipotential compensation stainless steel - Pure Stainless Steel	2095 UC-866	1	piece
2CKA002495A0091	2095 UC-884 Socket insert Equipotential compensation white - 63x63	2095 UC-884	1	piece
2CKA002495A0092	2095 UC-885 Socket insert Equipotential compensation black - 63x63	2095 UC-885	1	piece
2CKA002190A0224	2190 EUC-803 Inserts with Cover Plate 1gang(s) grey metallic	2190 EUC-803	1	piece
2CKA002190A0216	2190 EUC-81 Inserts with Cover Plate 1gang(s) anthracite	2190 EUC-81	1	piece
2CKA002190A0213	2190 EUC-82 Inserts with Cover Plate 1gang(s) ivory	2190 EUC-82	1	piece
2CKA002190A0214	2190 EUC-83 Inserts with Cover Plate 1gang(s) aluminium silver	2190 EUC-83	1	piece
2CKA002190A0222	2190 EUC-840-500 Inserts with Cover Plate 1gang(s) antique brass - 63x63	2190 EUC-840-500	1	piece
2CKA002190A0217	2190 EUC-866 Inserts with Cover Plate 1gang(s) stainless steel - Pure Stainless Steel	2190 EUC-866	1	piece
2CKA002190A0218	2190 EUC-884 Inserts with Cover Plate 1gang(s) studio white matt	2190 EUC-884	1	piece

2CKA002013A5475	23 EUCB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	23 EUCB-82	1	piece
2CKA002013A5476	23 EUCB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	23 EUCB-83	1	piece
2CKA002013A5478	23 EUCB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	23 EUCB-866	1	piece
2CKA002013A5480	23 EUCB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	23 EUCB-885	1	piece
2CKA002011A6247	23 EUCKS-845-507 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass anthracite - 63x63	23 EUCKS-845-507	1	piece
2CKA002011A6245	23 EUCKS-848-507 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass ivory white - 63x63	23 EUCKS-848-507	1	piece
2CKA002017A0891	23 MUCKS-845-500 Inserts with Cover Plate 1gang(s) antique brass anthracite - 63x63	23 MUCKS-845-500	1	piece
2CKA002017A0889	23 MUCKS-848-500 Inserts with Cover Plate 1gang(s) antique brass ivory white - 63x63	23 MUCKS-848-500	1	piece
2CKA002013A5447	2300 EUCB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	2300 EUCB-803	1	piece
2CKA002013A5448	2300 EUCB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	2300 EUCB-81	1	piece
2CKA002013A5449	2300 EUCB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	2300 EUCB-82	1	piece
2CKA002013A5450	2300 EUCB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	2300 EUCB-83	1	piece
2CKA002013A5452	2300 EUCB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	2300 EUCB-866	1	piece
2CKA002013A5453	2300 EUCB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	2300 EUCB-884	1	piece
2CKA002013A5454	2300 EUCB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	2300 EUCB-885	1	piece
2CKA002113A5339	2300 UCRKS-81-503 Inserts with Cover Plate 1gang(s) anthracite - 63x63	2300 UCRKS-81-503	1	piece
2CKA002113A0510	2300 UCRKS-82-503 Inserts with Cover Plate 1gang(s) ivory white - 63x63	2300 UCRKS-82-503	1	piece
2CKA002113A5337	2300 UCRKS-884-503 Inserts with Cover Plate 1gang(s) studio white matt - 63x63	2300 UCRKS-884-503	1	piece
2CKA002113A5340	2300 UCRKS-885-503 Inserts with Cover Plate 1gang(s) black matt - 63x63	2300 UCRKS-885-503	1	piece
2CKA002011A6257	2310 EUGL/VA-12-82-101 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang(s) red - 63x63	2310 EUGL/VA-12-82-101	1	piece
2CKA002011A3830	2310 EUGL/VA-81-11 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang(s) anthracite - 63x63	2310 EUGL/VA-81-11	1	piece

2CKA002011A3831	2310 EUGL/VA-82-11 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang (s) ivory white - 63x63	2310 EUGL/VA-82-11	1	piece
2CKA002011A3832	2310 EUGL/VA-83-11 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang (s) aluminium silver - 63x63	2310 EUGL/VA-83-11	1	piece
2CKA002011A3877	2310EUGL/VA-803-11 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang (s) grey metallic - 63x63	2310EUGL/VA-803-11	1	piece
2CKA002011A3853	2310EUGL/VA-866-11 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang (s) stainless steel - Pure Stainless Steel	2310EUGL/VA-866-11	1	piece
2CKA002011A3882	2310EUGL/VA-884-11 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang (s) studio white matt - 63x63	2310EUGL/VA-884-11	1	piece
2CKA002011A3885	2310EUGL/VA-885-11 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang (s) black matt - 63x63	2310EUGL/VA-885-11	1	piece
2CKA002099A0253	2399 UCKS-803 Inserts with Cover Plate 1gang (s) grey metallic - 63x63	2399 UCKS-803	1	piece
2CKA002099A0216	2399 UCKS-81 Inserts with Cover Plate 1gang(s) anthracite - 63x63	2399 UCKS-81	1	piece
2CKA002099A0211	2399 UCKS-82 Inserts with Cover Plate 1gang(s) ivory - 63x63	2399 UCKS-82	1	piece
2CKA002099A0191	2399 UCKS-82-505 Inserts with Cover Plate 1gang(s) ivory white - 63x63	2399 UCKS-82-505	1	piece
2CKA002099A0241	2399 UCKS-83 Inserts with Cover Plate 1gang(s) aluminium silver - 63x63	2399 UCKS-83	1	piece
2CKA002099A0193	2399 UCKS-85-505 Inserts with Cover Plate 1gang(s) manhattan/graphite	2399 UCKS-85-505	1	piece
2CKA002099A0243	2399 UCKS-866 Socket 1 gang(s) stainless steel - Pure Stainless Steel	2399 UCKS-866	1	piece
2CKA002099A0255	2399 UCKS-884 Inserts with Cover Plate 1gang (s) studio white matt - 63x63	2399 UCKS-884	1	piece
2CKA001751A3175	2520 KI-803 Rocker Switch/push button Single rocker Symbol "bell" grey metallic - 63x63	2520 KI-803	1	piece
2CKA001751A3176	2520 KI-81 Rocker Switch/push button Single rocker Symbol "bell" anthracite - 63x63	2520 KI-81	1	piece
2CKA001751A3177	2520 KI-82 Rocker Switch/push button Single rocker Symbol "bell" ivory white - 63x63	2520 KI-82	1	piece
2CKA001751A3178	2520 KI-83 Rocker Switch/push button Single rocker Symbol "bell" aluminium silver - 63x63	2520 KI-83	1	piece
2CKA001751A3181	2520 KI-866 Rocker Switch/push button Single rocker Symbol "bell" stainless steel - Pure Stainless Steel	2520 KI-866	1	piece
2CKA001751A3182	2520 KI-884 Rocker Switch/push button Single rocker Symbol "bell" studio white matt - 63x63	2520 KI-884	1	piece
2CKA001751A3183	2520 KI-885 Rocker Switch/push button Single rocker Symbol "bell" black matt - 63x63	2520 KI-885	1	piece
2CKA001751A3185	2520 LI-803 Rocker Switch/push button Single rocker grey metallic - 63x63	2520 LI-803	1	piece
2CKA001751A3186	2520 LI-81 Rocker Switch/push button Single rocker anthracite - 63x63	2520 LI-81	1	piece
2CKA001751A3187	2520 LI-82 Rocker Switch/push button Single rocker ivory white - 63x63	2520 LI-82	1	piece
2CKA001751A3188	2520 LI-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	2520 LI-83	1	piece

2CKA001751A3191	2520 LI-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	2520 LI-866	1	piece
2CKA001751A3192	2520 LI-884 Rocker Switch/push button Single rocker studio white matt - 63x63	2520 LI-884	1	piece
2CKA001751A3193	2520 LI-885 Rocker Switch/push button Single rocker black matt - 63x63	2520 LI-885	1	piece
2CKA001751A3195	2520 TR-803 Rocker Switch/push button Single rocker grey metallic - 63x63	2520 TR-803	1	piece
2CKA001751A3196	2520 TR-81 Rocker Switch/push button Single rocker anthracite - 63x63	2520 TR-81	1	piece
2CKA001751A3197	2520 TR-82 Rocker Switch/push button Single rocker ivory white - 63x63	2520 TR-82	1	piece
2CKA001751A3198	2520 TR-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	2520 TR-83	1	piece
2CKA001751A3200	2520 TR-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	2520 TR-866	1	piece
2CKA001751A3201	2520 TR-884 Rocker Switch/push button Single rocker studio white matt - 63x63	2520 TR-884	1	piece
2CKA001751A3202	2520 TR-885 Rocker Switch/push button Single rocker black matt - 63x63	2520 TR-885	1	piece
2CKA001724A4407	2533-803 Cover Plate Bore hole grey metallic - 63x63	2533-803	1	piece
2CKA001724A4254	2533-81 Cover Plate Bore hole 1 gang(s) anthracite - 63x63	2533-81	1	piece
2CKA001724A4255	2533-82 Cover Plate Bore hole 1 gang(s) ivory white - 63x63	2533-82	1	piece
2CKA001724A4382	2533-82-15 Cover Plate Bore hole 1 gang(s) 1 gang(s) yellow - 63x63	2533-82-15	1	piece
2CKA001724A4261	2533-83 Cover Plate Bore hole 1 gang(s) aluminium silver - 63x63	2533-83	1	piece
2CKA001724A4270	2533-866 Cover Plate Bore hole 1 gang(s) stainless steel - Pure Stainless Steel	2533-866	1	piece
2CKA001724A4296	2533-884 Cover Plate Bore hole 1 gang(s) studio white matt - 63x63	2533-884	1	piece
2CKA001724A4301	2533-885 Cover Plate Bore hole 1 gang(s) black matt - 63x63	2533-885	1	piece
2CKA001710A4125	2542 DR/01-803 Cover Plate Level switch Turn button Symbol "0-1-2-3" grey metallic - 63x63	2542 DR/01-803	1	piece
2CKA001710A3644	2542 DR/01-81 Cover Plate Level switch Turn button Symbol "0-1-2-3" anthracite - 63x63	2542 DR/01-81	1	piece
2CKA001710A3645	2542 DR/01-82 Cover Plate Level switch Turn button Symbol "0-1-2-3" ivory white - 63x63	2542 DR/01-82	1	piece
2CKA001710A3671	2542 DR/01-83 Cover Plate Level switch Turn button Symbol "0-1-2-3" aluminium silver - 63x63	2542 DR/01-83	1	piece
2CKA001710A3758	2542 DR/01-866 Cover Plate Level switch Turn button Symbol "0-1-2-3" stainless steel - Pure Stainless Steel	2542 DR/01-866	1	piece
2CKA001710A3890	2542 DR/01-884 Cover Plate Level switch Turn button Symbol "0-1-2-3" studio white matt - 63x63	2542 DR/01-884	1	piece
2CKA001710A3913	2542 DR/01-885 Cover Plate Level switch Turn button Symbol "0-1-2-3" black matt - 63x63	2542 DR/01-885	1	piece
2CKA001710A4126	2542 DR/02-803 Cover Plate Level switch Turn button Symbol "1-2-3" grey metallic - 63x63	2542 DR/02-803	1	piece
2CKA001710A3649	2542 DR/02-81 Cover Plate Level switch Turn button Symbol "1-2-3" anthracite - 63x63	2542 DR/02-81	1	piece

2CKA001710A3650	2542 DR/02-82 Cover Plate Level switch Turn button Symbol "1-2-3" ivory white - 63x63	2542 DR/02-82	1	piece
2CKA001710A3672	2542 DR/02-83 Cover Plate Level switch Turn button Symbol "1-2-3" aluminium silver - 63x63	2542 DR/02-83	1	piece
2CKA001710A3759	2542 DR/02-866 Cover Plate Level switch Turn button Symbol "1-2-3" stainless steel - Pure Stainless Steel	2542 DR/02-866	1	piece
2CKA001710A3891	2542 DR/02-884 Cover Plate Level switch Turn button Symbol "1-2-3" studio white matt - 63x63	2542 DR/02-884	1	piece
2CKA001710A3914	2542 DR/02-885 Cover Plate Level switch Turn button Symbol "1-2-3" black matt - 63x63	2542 DR/02-885	1	piece
2CKA001724A4398	2553-803 Cover Plate XLR grey metallic - 63x63	2553-803	1	piece
2CKA001724A4399	2553-81 Cover Plate XLR 1 gang(s) 1 gang(s) anthracite - 63x63	2553-81	1	piece
2CKA001724A4400	2553-82 Cover Plate XLR 1 gang(s) 1 gang(s) ivory white - 63x63	2553-82	1	piece
2CKA001724A4401	2553-83 Cover Plate XLR 1 gang(s) 1 gang(s) aluminium silver - 63x63	2553-83	1	piece
2CKA001724A4403	2553-866 Cover Plate XLR 1 gang(s) 1 gang(s) stainless steel - Pure Stainless Steel	2553-866	1	piece
2CKA001724A4404	2553-884 Cover Plate XLR 1 gang(s) 1 gang(s) studio white matt - 63x63	2553-884	1	piece
2CKA001724A4405	2553-885 Cover Plate XLR 1 gang(s) 1 gang(s) black matt - 63x63	2553-885	1	piece
2CKA001753A0316	2561-02-803 Cover Plate Modular Jack 1 gang(s) 2 gang(s) grey metallic - 63x63	2561-02-803	1	piece
2CKA001753A0317	2561-02-81 Cover Plate Modular Jack 1 gang(s) 2 gang(s) anthracite - 63x63	2561-02-81	1	piece
2CKA001753A0392	2561-02-82 Cover Plate Modular Jack ivory white - 63x63	2561-02-82	1	piece
2CKA001753A0393	2561-02-83 Cover Plate Modular Jack 1 gang(s) 2 gang(s) aluminium silver - 63x63	2561-02-83	1	piece
2CKA001753A0396	2561-02-884 Cover Plate Modular Jack 1 gang(s) 2 gang(s) studio white matt - 63x63	2561-02-884	1	piece
2CKA001753A0397	2561-02-885 Cover Plate Modular Jack 1 gang(s) 2 gang(s) black matt - 63x63	2561-02-885	1	piece
2CKA001753A0399	2561-803 Cover Plate Modular Jack 1 gang(s) 1 gang(s) grey metallic - 63x63	2561-803	1	piece
2CKA001753A0400	2561-81 Cover Plate Modular Jack 1 gang(s) 1 gang(s) anthracite - 63x63	2561-81	1	piece
2CKA001753A0401	2561-82 Cover Plate Modular Jack 1 gang(s) 1 gang(s) ivory white - 63x63	2561-82	1	piece
2CKA001753A0402	2561-83 Cover Plate Modular Jack 1 gang(s) 1 gang(s) aluminium silver - 63x63	2561-83	1	piece
2CKA001753A0404	2561-866 Cover Plate Modular Jack 1 gang(s) 1 gang(s) stainless steel - Pure Stainless Steel	2561-866	1	piece
2CKA001753A0405	2561-884 Cover Plate Modular Jack 1 gang(s) 1 gang(s) studio white matt - 63x63	2561-884	1	piece
2CKA001753A0406	2561-885 Cover Plate Modular Jack 1 gang(s) 1 gang(s) black matt - 63x63	2561-885	1	piece
2CKA003116A0666	3120 EUCB-803 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	3120 EUCB-803	1	piece
2CKA003116A0667	3120 EUCB-81 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	3120 EUCB-81	1	piece

2CKA003116A0661	3120 EUCB-82 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 3120 EUCB-82 1gang(s) ivory white - solo		1	piece
2CKA003116A0668	3120 EUCB-83 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 3120 EUCB-83 1gang(s) aluminium silver - 63x63		1	piece
2CKA003116A0669	3120 EUCB-866 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	3120 EUCB-866	1	piece
2CKA003116A0670	3120 EUCB-884 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	3120 EUCB-884	1	piece
2CKA003116A0671	3120 EUCB-885 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	3120 EUCB-885	1	piece
2CKA003117A0008	3151 UC-803 RCD - Insert Buschmat 30 mA grey metallic - 63x63	3151 UC-803	1	piece
2CKA003117A0009	3151 UC-81 RCD - Insert Buschmat 30 mA anthracite - 63x63	3151 UC-81	1	piece
2CKA003117A0005	3151 UC-82 RCD - Insert Buschmat 30 mA ivory white - 63x63	3151 UC-82	1	piece
2CKA003117A0010	3151 UC-83 RCD - Insert Buschmat 30 mA aluminium silver - 63x63	3151 UC-83	1	piece
2CKA003117A0011	3151 UC-866 RCD - Insert Buschmat 30 mA stainless steel - Pure Stainless Steel	3151 UC-866	1	piece
2CKA003117A0012	3151 UC-884 RCD - Insert Buschmat 30 mA studio white matt - 63x63	3151 UC-884	1	piece
2CKA003117A0013	3151 UC-885 RCD - Insert Buschmat 30 mA black matt - 63x63	3151 UC-885	1	piece
2CKA006115A0489	6108/61-803-500 Coverplate f. CE	6108/61-803-500	1	piece
2CKA006115A0483	6108/61-81-500 Coverplate f. CE	6108/61-81-500	1	piece
2CKA006115A0484	6108/61-82-500 Coverplate f. CE	6108/61-82-500	1	piece
2CKA006115A0485	6108/61-83-500 Coverplate f. CE	6108/61-83-500	1	piece
2CKA006155A0121	6108/61-840-500 Coverplate f. CE	6108/61-840-500	1	piece
2CKA006115A0492	6108/61-866-500 Coverplate f. CE	6108/61-866-500	1	piece
2CKA006115A0487	6108/61-884-500 Coverplate f. CE	6108/61-884-500	1	piece
2CKA006115A0488	6108/61-885-500 Coverplate f. CE	6108/61-885-500	1	piece
2CKA006155A0066	6109/03-803-500 Coverplate f. RTC	6109/03-803-500	1	piece
2CKA006155A0060	6109/03-81-500 Coverplate f. RTC	6109/03-81-500	1	piece
2CKA006155A0061	6109/03-82-500 Coverplate f. RTC	6109/03-82-500	1	piece
2CKA006155A0062	6109/03-83-500 Coverplate f. RTC	6109/03-83-500	1	piece
2CKA006155A0114	6109/03-840-500 Coverplate f. RTC	6109/03-840-500	1	piece

2CKA006155A0069	6109/03-866-500 Coverplate f. RTC	6109/03-866-500	1	piece
2CKA006155A0064	6109/03-884-500 Coverplate f. RTC	6109/03-884-500	1	piece
2CKA006155A0065	6109/03-885-500 Coverplate f. RTC	6109/03-885-500	1	piece
2CKA006132A0382	6122/10-803-500 BW standard	6122/10-803-500	1	piece
2CKA006132A0376	6122/10-81-500 BW standard	6122/10-81-500	1	piece
2CKA006132A0377	6122/10-82-500 BW standard	6122/10-82-500	1	piece
2CKA006132A0378	6122/10-83-500 BW standard	6122/10-83-500	1	piece
2CKA006132A0407	6122/10-840-500 BW standard	6122/10-840-500	1	piece
2CKA006132A0385	6122/10-866-500 BW standard	6122/10-866-500	1	piece
2CKA006132A0380	6122/10-884-500 BW standard	6122/10-884-500	1	piece
2CKA006132A0381	6122/10-885-500 BW standard	6122/10-885-500	1	piece
2CKA006115A0212	6125/01-803-500 Control element 1g w. BAU	6125/01-803-500	1	piece
2CKA006115A0205	6125/01-81-500 Control element 1g w. BAU	6125/01-81-500	1	piece
2CKA006115A0206	6125/01-82-500 Control element 1g w. BAU	6125/01-82-500	1	piece
2CKA006115A0207	6125/01-83-500 Control element 1g w. BAU	6125/01-83-500	1	piece
2CKA006115A0211	6125/01-866-500 Control element 1g w. BAU	6125/01-866-500	1	piece
2CKA006115A0214	6125/01-884-500 Control element 1g w. BAU	6125/01-884-500	1	piece
2CKA006115A0215	6125/01-885-500 Control element 1g w. BAU	6125/01-885-500	1	piece
2CKA006115A0224	6125/02-803-500 Control element 1/2gang	6125/02-803-500	1	piece
2CKA006115A0216	6125/02-81-500 Control element 1/2gang	6125/02-81-500	1	piece
2CKA006115A0217	6125/02-82-500 Control element 1/2gang	6125/02-82-500	1	piece
2CKA006115A0218	6125/02-83-500 Control element 1/2gang	6125/02-83-500	1	piece
2CKA006115A0452	6125/02-840-500 cont.-element KNX 1g	6125/02-840-500	1	piece
2CKA006115A0223	6125/02-866-500 Control element 1/2gang	6125/02-866-500	1	piece
2CKA006115A0226	6125/02-884-500 Control element 1/2gang	6125/02-884-500	1	piece
2CKA006115A0227	6125/02-885-500 Control element 1/2gang	6125/02-885-500	1	piece
2CKA006116A0202	6126/01-803-500 Control element 2g w. BAU	6126/01-803-500	1	piece

2CKA006116A0195	6126/01-81-500 Control element 2g w. BAU	6126/01-81-500	1	piece
2CKA006116A0196	6126/01-82-500 Control element 2g w. BAU	6126/01-82-500	1	piece
2CKA006116A0197	6126/01-83-500 Control element 2g w. BAU	6126/01-83-500	1	piece
2CKA006116A0201	6126/01-866-500 Control element 2g w. BAU	6126/01-866-500	1	piece
2CKA006116A0204	6126/01-884-500 Control element 2g w. BAU	6126/01-884-500	1	piece
2CKA006116A0205	6126/01-885-500 Control element 2g w. BAU	6126/01-885-500	1	piece
2CKA006116A0214	6126/02-803-500 Control element 2/4gang	6126/02-803-500	1	piece
2CKA006116A0206	6126/02-81-500 Control element 2/4gang	6126/02-81-500	1	piece
2CKA006116A0207	6126/02-82-500 Control element 2/4gang	6126/02-82-500	1	piece
2CKA006116A0208	6126/02-83-500 Control element 2/4gang	6126/02-83-500	1	piece
2CKA006116A0227	6126/02-840-500 cont.-element KNX 2g	6126/02-840-500	1	piece
2CKA006116A0213	6126/02-866-500 Control element 2/4gang	6126/02-866-500	1	piece
2CKA006116A0216	6126/02-884-500 Control element 2/4gang	6126/02-884-500	1	piece
2CKA006116A0217	6126/02-885-500 Control element 2/4gang	6126/02-885-500	1	piece
2CKA006117A0228	6127/01-803-500 Control element 4g w. BAU	6127/01-803-500	1	piece
2CKA006117A0221	6127/01-81-500 Control element 4g w. BAU	6127/01-81-500	1	piece
2CKA006117A0222	6127/01-82-500 Control element 4g w. BAU	6127/01-82-500	1	piece
2CKA006117A0223	6127/01-83-500 Control element 4g w. BAU	6127/01-83-500	1	piece
2CKA006117A0227	6127/01-866-500 Control element 4g w. BAU	6127/01-866-500	1	piece
2CKA006117A0230	6127/01-884-500 Control element 4g w. BAU	6127/01-884-500	1	piece
2CKA006117A0231	6127/01-885-500 Control element 4g w. BAU	6127/01-885-500	1	piece
2CKA006117A0240	6127/02-803-500 Control element 4/8gang	6127/02-803-500	1	piece
2CKA006117A0232	6127/02-81-500 Control element 4/8gang	6127/02-81-500	1	piece
2CKA006117A0233	6127/02-82-500 Control element 4/8gang	6127/02-82-500	1	piece
2CKA006117A0234	6127/02-83-500 Control element 4/8gang	6127/02-83-500	1	piece
2CKA006117A0252	6127/02-840-500 cont.-element KNX 4g	6127/02-840-500	1	piece
2CKA006117A0239	6127/02-866-500 Control element 4/8gang	6127/02-866-500	1	piece

2CKA006117A0242	6127/02-884-500 Control element 4/8gang	6127/02-884-500	1	piece
2CKA006117A0243	6127/02-885-500 Control element 4/8gang	6127/02-885-500	1	piece
2CKA006134A0336	6128/28-803-500 RTC Control element 2/4g	6128/28-803-500	1	piece
2CKA006134A0331	6128/28-81-500 RTC Control element 2/4g	6128/28-81-500	1	piece
2CKA006134A0332	6128/28-82-500 RTC Control element 2/4g	6128/28-82-500	1	piece
2CKA006134A0333	6128/28-83-500 RTC Control element 2/4g	6128/28-83-500	1	piece
2CKA006134A0342	6128/28-840-500 RTC Control element 2/4g	6128/28-840-500	1	piece
2CKA006134A0335	6128/28-866-500 RTC Control element 2/4g	6128/28-866-500	1	piece
2CKA006134A0338	6128/28-884-500 RTC Control element 2/4g	6128/28-884-500	1	piece
2CKA006134A0339	6128/28-885-500 RTC Control element 2/4g	6128/28-885-500	1	piece
2CKA006135A0163	6129/01-803-500 Control element 3/6g w. IR	6129/01-803-500	1	piece
2CKA006135A0156	6129/01-81-500 Control element 3/6g w. IR	6129/01-81-500	1	piece
2CKA006135A0157	6129/01-82-500 Control element 3/6g w. IR	6129/01-82-500	1	piece
2CKA006135A0158	6129/01-83-500 Control element 3/6g w. IR	6129/01-83-500	1	piece
2CKA006135A0162	6129/01-866-500 Control element 3/6g w. IR	6129/01-866-500	1	piece
2CKA006135A0165	6129/01-884-500 Control element 3/6g w. IR	6129/01-884-500	1	piece
2CKA006135A0166	6129/01-885-500 Control element 3/6g w. IR	6129/01-885-500	1	piece
2CKA006430A0350	6430-803-102 Control Element Venetian blind Symbol "arrows" grey metallic - 63x63	6430-803-102	1	piece
2CKA006430A0326	6430-81-102 Control Element Venetian blind Symbol "arrows" anthracite - 63x63	6430-81-102	1	piece
2CKA006430A0327	6430-82-102 Control Element Venetian blind Symbol "arrows" ivory white - 63x63	6430-82-102	1	piece
2CKA006430A0328	6430-83-102 Control Element Venetian blind Symbol "arrows" aluminium silver - 63x63	6430-83-102	1	piece
2CKA006430A0407	6430-840-102-500 cont.-element blinds	6430-840-102-500	1	piece
2CKA006430A0343	6430-866-102 Control Element Venetian blind Symbol "arrows" stainless steel - Pure Stainless Steel	6430-866-102	1	piece
2CKA006430A0385	6430-884-102 Control Element Venetian blind Symbol "arrows" studio white matt - 63x63	6430-884-102	1	piece
2CKA006430A0386	6430-885-102 Control Element Venetian blind Symbol "arrows" black matt - 63x63	6430-885-102	1	piece
2CKA006430A0351	6435-803 Cover Plate Time switch grey metallic - 63x63	6435-803	1	piece
2CKA006430A0303	6435-81 Cover Plate Time switch anthracite - 63x63	6435-81	1	piece

2CKA006430A0304	6435-82 Cover Plate Time switch ivory white - 63x63	6435-82	1	piece
2CKA006430A0305	6435-83 Cover Plate Time switch aluminium silver - 63x63	6435-83	1	piece
2CKA006430A0405	6435-840-500 Cover Plates Time switch antique brass - 63x63	6435-840-500	1	piece
2CKA006430A0344	6435-866 Cover Plate Time switch stainless steel - Pure Stainless Steel	6435-866	1	piece
2CKA006430A0388	6435-884 Cover Plate Time switch studio white matt - 63x63	6435-884	1	piece
2CKA006430A0389	6435-885 Cover Plate Time switch black matt - 63x63	6435-885	1	piece
2CKA006470A0006	6476-803 Cover Plate Proximity switch grey metallic - 63x63	6476-803	1	piece
2CKA006470A0007	6476-81 Cover Plate Proximity switch anthracite - 63x63	6476-81	1	piece
2CKA006470A0003	6476-82 Cover Plate Proximity switch ivory white - 63x63	6476-82	1	piece
2CKA006470A0008	6476-83 Cover Plate Proximity switch aluminium silver - 63x63	6476-83	1	piece
2CKA006470A0009	6476-866 Cover Plate Proximity switch stainless steel - Pure Stainless Steel	6476-866	1	piece
2CKA006470A0010	6476-884 Cover Plate Proximity switch studio white matt - 63x63	6476-884	1	piece
2CKA006470A0011	6476-885 Cover Plate Proximity switch black matt - 63x63	6476-885	1	piece
2CKA006400A0060	6477-803 Cover Plate PowerDock 1 gang(s) grey	6477-803	1	piece
2CKA006400A0056	6477-81 Cover Plate PowerDock 1 gang(s) anthracite	6477-81	1	piece
2CKA006400A0057	6477-82 Cover Plate PowerDock 1 gang(s) white	6477-82	1	piece
2CKA006400A0058	6477-83 Cover Plate PowerDock 1 gang(s) aluminium	6477-83	1	piece
2CKA006400A0061	6477-840-500 Switch Assortments USB antique brass - 63x63	6477-840-500	1	piece
2CKA006400A0064	6477-866 Cover Plate PowerDock 1 gang(s) stainless steel - Pure Stainless Steel	6477-866	1	piece
2CKA006400A0062	6477-884 Cover Plate PowerDock 1 gang(s) white	6477-884	1	piece
2CKA006400A0063	6477-885 Cover Plate PowerDock 1 gang(s) black	6477-885	1	piece
2CKA006599A2980	6540-803-102 Cover Plate Dimmer Turn button grey metallic - 63x63	6540-803-102	1	piece
2CKA006599A2950	6540-81-102 Cover Plate Dimmer Turn button anthracite - 63x63	6540-81-102	1	piece
2CKA006599A2951	6540-82-102 Cover Plate Dimmer Turn button ivory white - 63x63	6540-82-102	1	piece
2CKA006599A2952	6540-83-102 Cover Plate Dimmer Turn button aluminium silver - 63x63	6540-83-102	1	piece
2CKA006599A3022	6540-840-102-500 Cover Plates Dimmer Turn button antique brass - 63x63	6540-840-102-500	1	piece
2CKA006599A2959	6540-866-102 Cover Plate Dimmer Turn button stainless steel - Pure Stainless Steel	6540-866-102	1	piece
2CKA006599A2961	6540-884-102 Cover Plate Dimmer Turn button studio white matt - 63x63	6540-884-102	1	piece

2CKA006599A2966	6540-885-102 Cover Plate Dimmer Turn button black matt - 63x63	6540-885-102	1	piece
2CKA006599A2882	6541-81 Cover Plate Cooling Central cover plate anthracite - 63x63	6541-81	1	piece
2CKA006599A2832	6541-82 Cover Plate Cooling Central cover plate ivory white - 63x63	6541-82	1	piece
2CKA006599A2885	6541-83 Cover Plate Cooling Central cover plate aluminium silver - 63x63	6541-83	1	piece
2CKA006599A2924	6541-866 Cover Plate Cooling Central cover plate stainless steel - Pure Stainless Steel	6541-866	1	piece
2CKA006599A2962	6541-884 Cover Plate Cooling Central cover plate studio white matt - 63x63	6541-884	1	piece
2CKA006599A2967	6541-885 Cover Plate Cooling black matt - 63x63	6541-885	1	piece
2CKA006599A2881	6543-81-101 Control Element Switch/dimmer Single push button anthracite - 63x63	6543-81-101	1	piece
2CKA006599A2831	6543-82-101 Control Element Switch/dimmer Single push button ivory white - 63x63	6543-82-101	1	piece
2CKA006599A2887	6543-83-101 Control Element Switch/dimmer Single push button aluminium silver - 63x63	6543-83-101	1	piece
2CKA006599A3023	6543-840-101-500 Cover Plates Switch/dimmer Single push button Without imprint antique brass - 63x63	6543-840-101- 500	1	piece
2CKA006599A2926	6543-866-101 Control Element Switch/dimmer Single push button stainless steel - Pure Stainless Steel	6543-866-101	1	piece
2CKA006599A2963	6543-884-101 Control Element Switch/dimmer Single push button studio white matt - 63x63	6543-884-101	1	piece
2CKA006599A2968	6543-885-101 Control Element Switch/dimmer Single push button black matt - 63x63	6543-885-101	1	piece
2CKA006599A2943	6545-803 Control Element Dimmer Two-part button with Neon lamp grey metallic - 63x63	6545-803	1	piece
2CKA006599A2906	6545-81 Control Element Dimmer Two-part button with Neon lamp anthracite - 63x63	6545-81	1	piece
2CKA006599A2907	6545-82 Control Element Dimmer Two-part button with Neon lamp ivory white - 63x63	6545-82	1	piece
2CKA006599A2914	6545-83 Control Element Dimmer Two-part button with Neon lamp aluminium silver - 63x63	6545-83	1	piece
2CKA006599A3024	6545-840-500 Cover Plates Dimmer Two-part button Without imprint antique brass - 63x63	6545-840-500	1	piece
2CKA006599A2927	6545-866 Control Element Dimmer Two-part button with Neon lamp stainless steel - Pure Stainless Steel	6545-866	1	piece
2CKA006599A2964	6545-884 Control Element Dimmer Two-part button with Neon lamp studio white matt - 63x63	6545-884	1	piece
2CKA006599A2969	6545-885 Control Element Dimmer Two-part button with Neon lamp black matt - 63x63	6545-885	1	piece
2CKA006730A0032	6731-82-500 Cover Plates ivory white - 63x63	6731-82-500	1	piece
2CKA006730A0035	6731-83-500 Cover Plates aluminium silver - 63x63	6731-83-500	1	piece
2CKA006730A0094	6731-840-500 cont.-element WaveL 1g	6731-840-500	1	piece
2CKA006730A0041	6731-866-500 Cover Plates WaveLine stainless steel - Pure Stainless Steel	6731-866-500	1	piece
2CKA006730A0033	6732-82-500 Cover Plates ivory white - 63x63	6732-82-500	1	piece
2CKA006730A0036	6732-83-500 Cover Plates aluminium silver - 63x63	6732-83-500	1	piece

2CKA006730A0095	6732-840-500 cont.-element WaveL 2g	6732-840-500	1	piece
2CKA006730A0042	6732-866-500 Wall sensor stainless steel - Pure Stainless Steel	6732-866-500	1	piece
2CKA006730A0034	6733-82-500 Cover Plates ivory white - 63x63	6733-82-500	1	piece
2CKA006730A0037	6733-83-500 Cover Plates aluminium silver - 63x63	6733-83-500	1	piece
2CKA006730A0043	6733-866-500 Cover Plates stainless steel - Pure Stainless Steel	6733-866-500	1	piece
2CKA006730A0141	6736 FoH-885 Control Element Switch/dimmer Two-part button black	6736 FoH-885	1	piece
2CKA006800A2828	6815-81-101-500 Cover Plates Movement sensor anthracite	6815-81-101-500	1	piece
2CKA006800A2830	6815-82-101-500 Cover Plates ivory white	6815-82-101-500	1	piece
2CKA006800A2832	6815-83-101-500 Cover Plates aluminium silver	6815-83-101-500	1	piece
2CKA006800A2843	6815-866-101-500 Cover Plates stainless steel - Pure Stainless Steel	6815-866-101-500	1	piece
2CKA006800A2840	6815-885-101-500 Cover Plates Movement sensor black matt	6815-885-101-500	1	piece
2CKA008200A0115	8253-803 Cover Plate Loudspeaker grey - 63x63	8253-803	1	piece
2CKA008200A0078	8253-81 Cover Plate Loudspeaker anthracite - 63x63	8253-81	1	piece
2CKA008200A0079	8253-82 Cover Plate Loudspeaker white - 63x63	8253-82	1	piece
2CKA008200A0080	8253-83 Cover Plate Loudspeaker aluminium - 63x63	8253-83	1	piece
2CKA008200A0191	8253-840-500 Cover Plates antique brass - 63x63	8253-840-500	1	piece
2CKA008200A0087	8253-866 Cover Plate Loudspeaker stainless steel - Pure Stainless Steel	8253-866	1	piece
2CKA008200A0123	8253-884 Cover Plate Loudspeaker white - 63x63	8253-884	1	piece
2CKA008200A0126	8253-885 Cover Plate Loudspeaker black - 63x63	8253-885	1	piece
2CKA006220A0566	CP-FCC-803 C-plate Fan Coil	CP-FCC-803	1	piece
2CKA006220A0242	CP-FCC-81 C-plate Fan Coil	CP-FCC-81	1	piece
2CKA006220A0532	CP-FCC-82 C-plate Fan Coil	CP-FCC-82	1	piece
2CKA006220A0243	CP-FCC-83 C-plate Fan Coil	CP-FCC-83	1	piece
2CKA006220A0549	CP-FCC-866 C-plate Fan Coil	CP-FCC-866	1	piece
2CKA006220A0617	CP-FCC-884 C-plate Fan Coil	CP-FCC-884	1	piece
2CKA006220A0634	CP-FCC-885 C-plate Fan Coil	CP-FCC-885	1	piece
2CKA006220A0563	CP-RTC-803 C-plate RT sensor unit	CP-RTC-803	1	piece
2CKA006220A0179	CP-RTC-81 C-plate RT sensor unit	CP-RTC-81	1	piece
2CKA006220A0529	CP-RTC-82 C-plate RT sensor unit	CP-RTC-82	1	piece
2CKA006220A0180	CP-RTC-83 C-plate RT sensor unit	CP-RTC-83	1	piece
2CKA006220A0384	CP-RTC-840 c-plate temp.	CP-RTC-840	1	piece
2CKA006220A0546	CP-RTC-866 C-plate RT sensor unit	CP-RTC-866	1	piece
2CKA006220A0614	CP-RTC-884 C-plate RT sensor unit	CP-RTC-884	1	piece
2CKA006220A0631	CP-RTC-885 C-plate RT sensor unit	CP-RTC-885	1	piece
2CKA006220A0564	MD-F-1.0.1-803 Movement detector	MD-F-1.0.1-803	1	piece
2CKA006220A0212	MD-F-1.0.1-81 Movement detector	MD-F-1.0.1-81	1	piece
2CKA006220A0530	MD-F-1.0.1-82 Movement detector	MD-F-1.0.1-82	1	piece

2CKA006220A0213	MD-F-1.0.1-83 Movement detector	MD-F-1.0.1-83	1	piece
2CKA006220A0385	MD-F-1.0.1-840 WD 180 sens	MD-F-1.0.1-840	1	piece
2CKA006220A0547	MD-F-1.0.1-866 Movement detector	MD-F-1.0.1-866	1	piece
2CKA006220A0615	MD-F-1.0.1-884 Movement detector	MD-F-1.0.1-884	1	piece
2CKA006220A0632	MD-F-1.0.1-885 Movement detector	MD-F-1.0.1-885	1	piece
2CKA006220A0565	MSA-F-1.1.1-803 Mov. detector/actuator 1g	MSA-F-1.1.1-803	1	piece
2CKA006220A0215	MSA-F-1.1.1-81 Mov. detector/actuator 1g	MSA-F-1.1.1-81	1	piece
2CKA006200A0083	MSA-F-1.1.1-81-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-81-WL	1	piece
2CKA006200A0084	MSA-F-1.1.1-82-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-82-WL	1	piece
2CKA006220A0216	MSA-F-1.1.1-83 Mov. detector/actuator 1g	MSA-F-1.1.1-83	1	piece
2CKA006200A0085	MSA-F-1.1.1-83-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-83-WL	1	piece
2CKA006220A0386	MSA-F-1.1.1-840 WD 180 sens actuator	MSA-F-1.1.1-840	1	piece
2CKA006220A0548	MSA-F-1.1.1-866 Mov. detector/actuator 1g	MSA-F-1.1.1-866	1	piece
2CKA006220A0616	MSA-F-1.1.1-884 Mov. detector/actuator 1g	MSA-F-1.1.1-884	1	piece
2CKA006200A0097	MSA-F-1.1.1-884-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-884-WL	1	piece
2CKA006220A0633	MSA-F-1.1.1-885 Mov. detector/actuator 1g	MSA-F-1.1.1-885	1	piece
2CKA006200A0098	MSA-F-1.1.1-885-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-885-WL	1	piece
2CKA006220A0550	SR-1-803 rocker 1gang	SR-1-803	1	piece
2CKA006220A0137	SR-1-81 rocker 1gang	SR-1-81	1	piece
2CKA006220A0516	SR-1-82 rocker 1gang	SR-1-82	1	piece
2CKA006220A0138	SR-1-83 rocker 1gang	SR-1-83	1	piece
2CKA006220A0371	SR-1-840 rocker 1g neural	SR-1-840	1	piece
2CKA006220A0533	SR-1-866 rocker 1gang	SR-1-866	1	piece
2CKA006220A0601	SR-1-884 rocker 1gang	SR-1-884	1	piece
2CKA006220A0618	SR-1-885 rocker 1gang	SR-1-885	1	piece
2CKA006220A0555	SR-2-803 rocker 2gang	SR-2-803	1	piece
2CKA006220A0152	SR-2-81 rocker 2gang	SR-2-81	1	piece
2CKA006220A0521	SR-2-82 rocker 2gang	SR-2-82	1	piece
2CKA006220A0153	SR-2-83 rocker 2gang	SR-2-83	1	piece
2CKA006220A0376	SR-2-840 rocker 2g neutral	SR-2-840	1	piece
2CKA006220A0538	SR-2-866 rocker 2gang	SR-2-866	1	piece
2CKA006220A0606	SR-2-884 rocker 2gang	SR-2-884	1	piece
2CKA006220A0623	SR-2-885 rocker 2gang	SR-2-885	1	piece
2CKA006220A0552	SRB-1-803 rocker 1gang, blinds	SRB-1-803	1	piece
2CKA006220A0143	SRB-1-81 rocker 1gang, blinds	SRB-1-81	1	piece

2CKA006220A0518	SRB-1-82 rocker 1gang, blinds	SRB-1-82	1	piece
2CKA006220A0144	SRB-1-83 rocker 1gang, blinds	SRB-1-83	1	piece
2CKA006220A0373	SRB-1-840 rocker 1g blinds	SRB-1-840	1	piece
2CKA006220A0535	SRB-1-866 rocker 1gang, blinds	SRB-1-866	1	piece
2CKA006220A0603	SRB-1-884 rocker 1gang, blinds	SRB-1-884	1	piece
2CKA006220A0620	SRB-1-885 rocker 1gang, blinds	SRB-1-885	1	piece
2CKA006220A0557	SRB-2-803 rocker 2g, blinds	SRB-2-803	1	piece
2CKA006220A0158	SRB-2-81 rocker 2g, blinds	SRB-2-81	1	piece
2CKA006220A0523	SRB-2-82 rocker 2g, blinds	SRB-2-82	1	piece
2CKA006220A0159	SRB-2-83 rocker 2g, blinds	SRB-2-83	1	piece
2CKA006220A0378	SRB-2-840 rocker 2g blinds	SRB-2-840	1	piece
2CKA006220A0540	SRB-2-866 rocker 2g, blinds	SRB-2-866	1	piece
2CKA006220A0608	SRB-2-884 rocker 2g, blinds	SRB-2-884	1	piece
2CKA006220A0625	SRB-2-885 rocker 2g, blinds	SRB-2-885	1	piece
2CKA006220A0554	SRD-1-803 rocker 1gang, dimming	SRD-1-803	1	piece
2CKA006220A0149	SRD-1-81 rocker 1gang, dimming	SRD-1-81	1	piece
2CKA006220A0520	SRD-1-82 rocker 1gang, dimming	SRD-1-82	1	piece
2CKA006220A0150	SRD-1-83 rocker 1gang, dimming	SRD-1-83	1	piece
2CKA006220A0375	SRD-1-840 rocker 1g dimming	SRD-1-840	1	piece
2CKA006220A0537	SRD-1-866 rocker 1gang, dimming	SRD-1-866	1	piece
2CKA006220A0605	SRD-1-884 rocker 1gang, dimming	SRD-1-884	1	piece
2CKA006220A0622	SRD-1-885 rocker 1gang, dimming	SRD-1-885	1	piece
2CKA006220A0559	SRD-2-L-803 rocker 2g, left, dimming	SRD-2-L-803	1	piece
2CKA006220A0164	SRD-2-L-81 rocker 2g, left, dimming	SRD-2-L-81	1	piece
2CKA006220A0525	SRD-2-L-82 rocker 2g, left, dimming	SRD-2-L-82	1	piece
2CKA006220A0165	SRD-2-L-83 rocker 2g, left, dimming	SRD-2-L-83	1	piece
2CKA006220A0380	SRD-2-L-840 rocker 2g left dimming	SRD-2-L-840	1	piece
2CKA006220A0542	SRD-2-L-866 rocker 2g, left, dimming	SRD-2-L-866	1	piece
2CKA006220A0610	SRD-2-L-884 rocker 2g, left, dimming	SRD-2-L-884	1	piece
2CKA006220A0627	SRD-2-L-885 rocker 2g, left, dimming	SRD-2-L-885	1	piece
2CKA006220A0560	SRD-2-R-803 rocker 2g, right, dimming	SRD-2-R-803	1	piece
2CKA006220A0258	SRD-2-R-81 rocker 2g, right, dimming	SRD-2-R-81	1	piece
2CKA006220A0526	SRD-2-R-82 rocker 2g, right, dimming	SRD-2-R-82	1	piece
2CKA006220A0259	SRD-2-R-83 rocker 2g, right, dimming	SRD-2-R-83	1	piece
2CKA006220A0383	SRD-2-R-840 rocker 2g right dimming	SRD-2-R-840	1	piece
2CKA006220A0543	SRD-2-R-866 rocker 2g, right, dimming	SRD-2-R-866	1	piece
2CKA006220A0611	SRD-2-R-884 rocker 2g, right, dimming	SRD-2-R-884	1	piece
2CKA006220A0628	SRD-2-R-885 rocker 2g, right, dimming	SRD-2-R-885	1	piece
2CKA006220A0551	SRL-1-803 rocker 1gang, lighting	SRL-1-803	1	piece
2CKA006220A0140	SRL-1-81 rocker 1gang, lighting	SRL-1-81	1	piece
2CKA006220A0517	SRL-1-82 rocker 1gang, lighting	SRL-1-82	1	piece
2CKA006220A0141	SRL-1-83 rocker 1gang, lighting	SRL-1-83	1	piece
2CKA006220A0372	SRL-1-840 rocker 1g light	SRL-1-840	1	piece
2CKA006220A0534	SRL-1-866 rocker 1gang, lighting	SRL-1-866	1	piece
2CKA006220A0602	SRL-1-884 rocker 1gang, lighting	SRL-1-884	1	piece
2CKA006220A0619	SRL-1-885 rocker 1gang, lighting	SRL-1-885	1	piece

2CKA006220A0556	SRL-2-L-803 rocker 2g, left, lighting	SRL-2-L-803	1	piece
2CKA006220A0155	SRL-2-L-81 rocker 2g, left, lighting	SRL-2-L-81	1	piece
2CKA006220A0522	SRL-2-L-82 rocker 2g, left, lighting	SRL-2-L-82	1	piece
2CKA006220A0156	SRL-2-L-83 rocker 2g, left, lighting	SRL-2-L-83	1	piece
2CKA006220A0377	SRL-2-L-840 rocker 2g left light	SRL-2-L-840	1	piece
2CKA006220A0539	SRL-2-L-866 rocker 2g, left, lighting	SRL-2-L-866	1	piece
2CKA006220A0607	SRL-2-L-884 rocker 2g, left, lighting	SRL-2-L-884	1	piece
2CKA006220A0624	SRL-2-L-885 rocker 2g, left, lighting	SRL-2-L-885	1	piece
2CKA006220A0561	SRL-2-R-803 rocker 2g, right, lighting	SRL-2-R-803	1	piece
2CKA006220A0167	SRL-2-R-81 rocker 2g, right, lighting	SRL-2-R-81	1	piece
2CKA006220A0527	SRL-2-R-82 rocker 2g, right, lighting	SRL-2-R-82	1	piece
2CKA006220A0168	SRL-2-R-83 rocker 2g, right, lighting	SRL-2-R-83	1	piece
2CKA006220A0381	SRL-2-R-840 rocker2g right light	SRL-2-R-840	1	piece
2CKA006220A0544	SRL-2-R-866 rocker 2g, right, lighting	SRL-2-R-866	1	piece
2CKA006220A0612	SRL-2-R-884 rocker 2g, right, lighting	SRL-2-R-884	1	piece
2CKA006220A0629	SRL-2-R-885 rocker 2g, right, lighting	SRL-2-R-885	1	piece
2CKA006220A0553	SRS-1-803 rocker 1gang, scene	SRS-1-803	1	piece
2CKA006220A0146	SRS-1-81 rocker 1gang, scene	SRS-1-81	1	piece
2CKA006220A0519	SRS-1-82 rocker 1gang, scene	SRS-1-82	1	piece
2CKA006220A0147	SRS-1-83 rocker 1gang, scene	SRS-1-83	1	piece
2CKA006220A0374	SRS-1-840 rocker 1g scene	SRS-1-840	1	piece
2CKA006220A0536	SRS-1-866 rocker 1gang, scene	SRS-1-866	1	piece
2CKA006220A0604	SRS-1-884 rocker 1gang, scene	SRS-1-884	1	piece
2CKA006220A0621	SRS-1-885 rocker 1gang, scene	SRS-1-885	1	piece
2CKA006220A0558	SRS-2-L-803 rocker 2gang, left, scene	SRS-2-L-803	1	piece
2CKA006220A0161	SRS-2-L-81 rocker 2gang, left, scene	SRS-2-L-81	1	piece
2CKA006220A0524	SRS-2-L-82 rocker 2gang, left, scene	SRS-2-L-82	1	piece
2CKA006220A0162	SRS-2-L-83 rocker 2gang, left, scene	SRS-2-L-83	1	piece
2CKA006220A0379	SRS-2-L-840 rocker 2g left scene	SRS-2-L-840	1	piece
2CKA006220A0541	SRS-2-L-866 rocker 2gang, left, scene	SRS-2-L-866	1	piece
2CKA006220A0609	SRS-2-L-884 rocker 2gang, left, scene	SRS-2-L-884	1	piece
2CKA006220A0626	SRS-2-L-885 rocker 2gang, left, scene	SRS-2-L-885	1	piece
2CKA006220A0562	SRS-2-R-803 rocker 2g, right, scene	SRS-2-R-803	1	piece
2CKA006220A0173	SRS-2-R-81 rocker 2g, right, scene	SRS-2-R-81	1	piece
2CKA006220A0528	SRS-2-R-82 rocker 2g, right, scene	SRS-2-R-82	1	piece
2CKA006220A0174	SRS-2-R-83 rocker 2g, right, scene	SRS-2-R-83	1	piece
2CKA006220A0382	SRS-2-R-840 rocker 2g right scene	SRS-2-R-840	1	piece
2CKA006220A0545	SRS-2-R-866 rocker 2g, right, scene	SRS-2-R-866	1	piece
2CKA006220A0613	SRS-2-R-884 rocker 2g, right, scene	SRS-2-R-884	1	piece
2CKA006220A0630	SRS-2-R-885 rocker 2g, right, scene	SRS-2-R-885	1	piece

Catégories

Produits basse tension → Switch Assortments → Frames

