

PRODUCT-DETAILS

1724-280

1724-280 Cover Frame 4gang(s) white glass Horizontal mounting - Busch-axcent



Informations générales

Extension du type de produit	1724-280
Code de produit	2CKA001754A4440
EAN	4011395156988
Description courte	1724-280 Cover Frame 4gang(s) white glass Horizontal mounting - Busch-axcent
Description longue	For vertical or horizontal installation.

Technique

Number of Gangs	4
Design Range	Busch-axcent
Type de montage	Flush Mounted
Type of Fastening	Clamp
Sens de montage	Horizontal Vertical
Finition de surface	Untreated Glossy
Matériau	Glass
Label Space Provided	No
Couleur	white glass

Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E2787
REACH Declaration	2CKA309999E9999

Dimensions

Poids net	145.31 g
-----------	----------

Commande

Quantité minimum	1 pièce
Emballage Niveau 1 Unités	carton 1 pièce
Emballage Niveau 1 Poids	0.33 kg
Code douanier	85389099
E-Number (Sweden)	1815102
Pays d'origine	Germany (DE)

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E2787
--------------------------------	-----------------

Classifications

ETIM 8	EC000007 - Cover frame for domestic switching devices
ETIM 9	EC000007 - Cover frame for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144001

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
2CKA001731A1916	1720-84 Rocker Switch Pull cord studio white - 63x63	1720-84	1	piece
2CKA001710A3808	1740 DR/03-84 Cover Plate Level switch Turn button studio white - 63x63	1740 DR/03-84	1	piece
2CKA001710A3512	1740 DRL-84-503 Cover Plate Level switch Turn button Symbol "3-level switch" studio white - 63x63	1740 DRL-84-503	1	piece
2CKA001710A3172	1740-84 Cover Plate Venetian blind Turn button studio white - 63x63	1740-84	1	piece
2CKA001710A3161	1742-84 Cover Plate Blind cap 1 gang(s) with Mounting plate studio white - 63x63	1742-84	1	piece
2CKA001710A3991	1742-84-500 Inserts with Cover Plate Blind cap 1 gang(s) 0 pole studio white - 63x63	1742-84-500	1	piece
2CKA001724A4368	1743/10-04-84 Cover Plate SAT 1 gang(s) 4 gang(s) studio white - 63x63	1743/10-04-84	1	piece

2CKA001724A4377	1743-04-84 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) studio white - 63x63	1743-04-84	1	piece
2CKA001724A4332	1743-84-500 Cover Plates SAT 1 gang(s) 3 gang(s) studio white - 63x63	1743-84-500	1	piece
2CKA001710A3173	1745-84 Cover Plate telephone connector boxes (VDo) 1 gang(s) studio white - 63x63	1745-84	1	piece
2CKA001710A3993	1746/10-84-500 Cover Plates Telecommunication inserts 0 gang(s) studio white - 63x63	1746/10-84-500	1	piece
2CKA001710A3167	1746-84 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid studio white - 63x63	1746-84	1	piece
2CKA001710A4096	1747 BSI-84 Intermediate Ring Cover plates Busch-Balance® SI studio white - 63x63	1747 BSI-84	1	piece
2CKA001710A3863	1747 SI-84 Cover Plates studio white - 63x63	1747 SI-84	1	piece
2CKA001710A3861	1747-84 Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI studio white - 63x63	1747-84	1	piece
2CKA001710A3656	1748-84 Cover Plate Data connection 2 gang(s) studio white - 63x63	1748-84	1	piece
2CKA001710A3163	1749-84 Cover Plate Cable outlet 1 gang(s) 0 gang(s) studio white - 63x63	1749-84	1	piece
2CKA001710A3166	1750-84 Cover Plate BNC/TNC 2 gang(s) studio white - 63x63	1750-84	1	piece
2CKA001723A0240	1751-84 Cover Plate Loudspeaker 2 gang(s) studio white - 63x63	1751-84	1	piece
2CKA001710A3175	1755 SL/PZ-84-101 Cover Plate Venetian blind Key studio white - 63x63	1755 SL/PZ-84-101	1	piece
2CKA001753A0092	1756-84 Cover Plate Info light studio white - 63x63	1756-84	1	piece
2CKA001724A2761	1758-84 Cover Plate For data connection housing 2 gang(s) studio white - 63x63	1758-84	1	piece
2CKA001710A4106	1762-84-506 Cover Plates TDO 1 gang(s) 1 gang(s) studio white - 63x63	1762-84-506	1	piece
2CKA001731A1877	1764 NLI-84 Rocker Switch/push button Single push button with Pilot lamp studio white - 63x63	1764 NLI-84	1	piece
2CKA001710A3992	1766-84-500 Cover Plates TAE 1 gang(s) 0 gang(s) studio white - 63x63	1766-84-500	1	piece
2CKA001753A0258	1770-84-103 Cover Plate Time switch Toggle studio white - 63x63	1770-84-103	1	piece
2CKA001753A0301	1771-84-103 Cover Plate Time switch Toggle studio white - 63x63	1771-84-103	1	piece
2CKA001751A3099	1785 JA/02-84 Rocker Venetian blind Two-part rocker Symbol "arrows" studio white	1785 JA/02-84	1	piece
2CKA001751A3088	1785 JA-84-500 Cover Plates Venetian blind Two-part rocker Symbol "arrows" studio white - 63x63	1785 JA-84-500	1	piece
2CKA001751A3128	1785 K-84-500 Cover Plates Switch/push button Two-part rocker None studio white - 63x63	1785 K-84-500	1	piece
2CKA001751A2992	1785/11-84 Rocker Switch/push button Two-part rocker studio white - 63x63	1785/11-84	1	piece
2CKA001751A3076	1785-84-500 Cover Plates Switch/push button Two-part rocker Without imprint studio white - 63x63	1785-84-500	1	piece
2CKA001751A3098	1786 JA/02-84 Rocker Venetian blind Single rocker studio white	1786 JA/02-84	1	piece
2CKA001751A2998	1786/11-84 Rocker Switch/push button Single rocker studio white - 63x63	1786/11-84	1	piece
2CKA001751A3074	1786-84-500 Cover Plates Switch/push button Single rocker Without imprint studio white - 63x63	1786-84-500	1	piece
2CKA001751A2750	1788-84 Rocker Switch/push button Single rocker studio white - 63x63	1788-84	1	piece
2CKA001751A2751	1789 H-84 Rocker Switch/push button Single rocker Heizung studio white - 63x63	1789 H-84	1	piece
2CKA001751A2754	1789 KI-84 Rocker Switch/push button Single rocker Symbol "bell" studio white - 63x63	1789 KI-84	1	piece

2CKA001751A3084	1789 LI-84-500 Cover Plates Switch/push button Single rocker Symbol "light" studio white - 63x63	1789 LI-84-500	1	piece
2CKA001751A3151	1789 N-84-500 Cover Plates Switch/push button Single rocker Without imprint studio white - 63x63	1789 N-84-500	1	piece
2CKA001751A3161	1789 ST-84-500 Cover Plates Switch/push button Single rocker Various symbols studio white - 63x63	1789 ST-84-500	1	piece
2CKA001751A2755	1789 TR-84 Rocker Switch/push button Single rocker studio white - 63x63	1789 TR-84	1	piece
2CKA001751A3091	1789-84-500 Cover Plates Switch/push button Single rocker Without imprint studio white - 63x63	1789-84-500	1	piece
2CKA001710A4113	1790-592-84 Cover Plate Medical alarm studio white - 63x63	1790-592-84	1	piece
2CKA001710A3698	1794 TA-84 Cover Plate Thermostat Turn button studio white - 63x63	1794 TA-84	1	piece
2CKA001710A3544	1794-84 Cover Plate Thermostat studio white - 63x63	1794-84	1	piece
2CKA001710A4017	1795 HK-84 Cover Plate Thermostat Turn button studio white - 63x63	1795 HK-84	1	piece
2CKA001710A4049	1795 HKEA-84 Cover Plate Thermostat Turn button 1 switchover studio white - 63x63	1795 HKEA-84	1	piece
2CKA001710A3725	1795 TA-84 Cover Plate Thermostat Turn button studio white - 63x63	1795 TA-84	1	piece
2CKA001710A3569	1795-84 Cover Plate Thermostat Turn button studio white - 63x63	1795-84	1	piece
2CKA001753A0311	1796-84 Cover Plate Pull cord studio white - 63x63	1796-84	1	piece
2CKA001710A3990	1800-84-500 Cover Plates Modular Jack 1 gang (s) 2 gang(s) studio white - 63x63	1800-84-500	1	piece
2CKA001710A1551	1803-02-84-500 Cover Plates UAE/IAE (ISDN) 1 gang(s) 2 gang(s) studio white - 63x63	1803-02-84-500	1	piece
2CKA001710A1550	1803-84-500 Cover Plates UAE/IAE (ISDN) 1 gang(s) 1 gang(s) studio white - 63x63	1803-84-500	1	piece
2CKA002013A5407	20 EUAB-84 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	20 EUAB-84	1	piece
2CKA002011A6207	20 EUC-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUC-84-500	1	piece
2CKA002013A5418	20 EUCBDR-84 Socket insert Busch-Service- Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	20 EUCBDR-84	1	piece
2CKA002013A5286	20 EUCBL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) studio white - 63x63	20 EUCBL-84	1	piece
2CKA002013A5294	20 EUCBLI-84 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) studio white - 63x63	20 EUCBLI-84	1	piece
2CKA002013A5268	20 EUCKS/DV-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	20 EUCKS/DV-84	1	piece
2CKA002013A5372	20 EUCKS-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUCKS-84-500	1	piece
2CKA002013A5441	20 EUCRB-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUCRB-84-500	1	piece
2CKA002018A1509	20 EUK-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) with Hinged Lid studio white - 63x63	20 EUK-84-500	1	piece
2CKA002018A1520	20 EUKB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKB-84	1	piece
2CKA002018A1529	20 EUKBR-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKBR-84	1	piece

2CKA002018A1540	20 EUKNB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNB-84	1	piece
2CKA002018A1551	20 EUKNBL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNBL-84	1	piece
2CKA002018A1563	20 EUKNBSL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNBSL-84	1	piece
2CKA002018A1564	20 EUKNBSL-84-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white - 63x63	20 EUKNBSL-84-101	1	piece
2CKA002011A6209	20 EUN-84-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	20 EUN-84-500	1	piece
2CKA002017A0786	20 MUC-84-500 Socket insert 1gang(s) studio white - 63x63	20 MUC-84-500	1	piece
2CKA002017A0807	20 MUCKS-84-500 Inserts with Cover Plate 1gang(s) studio white - 63x63	20 MUCKS-84-500	1	piece
2CKA001751A3170	2029 UC-84 Bell push-switch DND / MUR insert Bell Single push button studio white - 63x63	2029 UC-84	1	piece
2CKA002495A0086	2095 UC-84 Socket insert Equipotential compensation studio white - 63x63	2095 UC-84	1	piece
2CKA002190A0215	2190 EUC-84 Inserts with Cover Plate 1gang(s) studio white	2190 EUC-84	1	piece
2CKA002013A5477	23 EUCEB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	23 EUCEB-84	1	piece
2CKA002013A5451	2300 EUCEB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - 63x63	2300 EUCEB-84	1	piece
2CKA002113A0511	2300 UCRKS-84-503 Inserts with Cover Plate 1gang(s) studio white - 63x63	2300 UCRKS-84-503	1	piece
2CKA002011A3833	2310 EUGL/VA-84-11 Socket insert Busch-Protector® Protective Contact (SCHUKO) 1gang(s) studio white - 63x63	2310 EUGL/VA-84-11	1	piece
2CKA002099A0214	2399 UCKS-84 Socket insert Safety Shutter 1gang(s) studio white - 63x63	2399 UCKS-84	1	piece
2CKA002099A0192	2399 UCKS-84-505 Inserts with Cover Plate 1gang(s) studio white - 63x63	2399 UCKS-84-505	1	piece
2CKA001719A0220	2518-WD-84 Intermediate Ring with Hinged Lid 1 gang(s) studio white - 63x63	2518-WD-84	1	piece
2CKA001751A3180	2520 KI-84-500 Cover Plates Switch/push button Single rocker studio white - 63x63	2520 KI-84-500	1	piece
2CKA001751A3199	2520 TR-84 Rocker Switch/push button Single rocker studio white - 63x63	2520 TR-84	1	piece
2CKA001724A4256	2533-84 Cover Plate Bore hole 1 gang(s) studio white - 63x63	2533-84	1	piece
2CKA001710A3646	2542 DR/01-84 Cover Plate Level switch Turn button Symbol "0-1-2-3" studio white - 63x63	2542 DR/01-84	1	piece
2CKA001710A3651	2542 DR/02-84 Cover Plate Level switch Turn button Symbol "1-2-3" studio white - 63x63	2542 DR/02-84	1	piece
2CKA001724A4388	2548-022 AR-84 Cover Plate Doctor Blue 1 button (s) studio white - 63x63	2548-022 AR-84	1	piece
2CKA001724A4402	2553-84 Cover Plate XLR 1 gang(s) 1 gang(s) studio white - 63x63	2553-84	1	piece
2CKA001753A0394	2561-02-84 Cover Plate Modular Jack 1 gang(s) 2 gang(s) studio white - 63x63	2561-02-84	1	piece
2CKA001753A0403	2561-84 Cover Plate Modular Jack 1 gang(s) 1 gang(s) studio white - 63x63	2561-84	1	piece
2CKA003116A0662	3120 EUCEB-84 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white - solo	3120 EUCEB-84	1	piece
2CKA003117A0006	3151 UC-84 RCD - Insert Buschmat 30 mA studio white - 63x63	3151 UC-84	1	piece

2CKA006115A0486	6108/61-84-500 Coverplate f. CE	6108/61-84-500	1	piece
2CKA006155A0063	6109/03-84-500 Coverplate f. RTC	6109/03-84-500	1	piece
2CKA006132A0379	6122/10-84-500 BW standard	6122/10-84-500	1	piece
2CKA006115A0183	6125/01-84-500 Control element 1g w. BAU	6125/01-84-500	1	piece
2CKA006115A0219	6125/02-84-500 Control element 1/2gang	6125/02-84-500	1	piece
2CKA006116A0174	6126/01-84-500 Control element 2g w. BAU	6126/01-84-500	1	piece
2CKA006116A0209	6126/02-84-500 Control element 2/4gang	6126/02-84-500	1	piece
2CKA006117A0200	6127/01-84-500 Control element 4g w. BAU	6127/01-84-500	1	piece
2CKA006117A0235	6127/02-84-500 Control element 4/8gang	6127/02-84-500	1	piece
2CKA006134A0334	6128/28-84-500 RTC Control element 2/4g	6128/28-84-500	1	piece
2CKA006135A0146	6129/01-84-500 Control element 3/6g w. IR	6129/01-84-500	1	piece
2CKA006430A0400	6430-84-102-500 Cover Plates Venetian blind Symbol "arrows" studio white - 63x63	6430-84-102-500	1	piece
2CKA006430A0306	6435-84 Cover Plate Time switch studio white - 63x63	6435-84	1	piece
2CKA006470A0004	6476-84 Cover Plate Proximity switch studio white - 63x63	6476-84	1	piece
2CKA006400A0059	6477-84 Cover Plate PowerDock 1 gang(s) studio white	6477-84	1	piece
2CKA006400A0047	6480/11-84-500 Complete Devices studio white	6480/11-84-500	1	piece
2CKA006400A0045	6480-84-500 Complete Devices studio white - future linear	6480-84-500	1	piece
2CKA006599A3009	6540-84-102-500 Cover Plates Dimmer studio white - 63x63	6540-84-102-500	1	piece
2CKA006599A2835	6541-84 Cover Plate Cooling Central cover plate studio white - 63x63	6541-84	1	piece
2CKA006599A3010	6543-84-101-500 Cover Plates Switch/dimmer Single push button Without imprint studio white - 63x63	6543-84-101-500	1	piece
2CKA006599A2908	6545-84 Control Element Dimmer Two-part button with Neon lamp studio white - 63x63	6545-84	1	piece
2CKA006710A0011	6716 UJ-84-500 Complete Devices studio white - future linear	6716 UJ-84-500	1	piece
2CKA006730A0038	6731-84-500 Cover Plates studio white - 63x63	6731-84-500	1	piece
2CKA006730A0039	6732-84-500 Cover Plates studio white - 63x63	6732-84-500	1	piece
2CKA006730A0040	6733-84-500 Wall sensor studio white - 63x63	6733-84-500	1	piece
2CKA006730A0136	6736 FoH-84 Control Element Switch/dimmer Two-part button studio white	6736 FoH-84	1	piece
2CKA006800A2834	6815-84-101-500 Cover Plates studio white	6815-84-101-500	1	piece
2CKA008200A0081	8253-84 Cover Plate Loudspeaker studio white - 63x63	8253-84	1	piece
2CKA006220A0244	CP-FCC-84 C-plate Fan Coil	CP-FCC-84	1	piece
2CKA006220A0181	CP-RTC-84 C-plate RT sensor unit	CP-RTC-84	1	piece
2CKA006220A0214	MD-F-1.0.1-84 Movement detector	MD-F-1.0.1-84	1	piece
2CKA006220A0217	MSA-F-1.1.1-84 Mov. detector/actuator 1g	MSA-F-1.1.1-84	1	piece
2CKA006200A0086	MSA-F-1.1.1-84-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-84-WL	1	piece
2CKA006220A0139	SR-1-84 rocker 1gang	SR-1-84	1	piece

2CKA006220A0154	SR-2-84 rocker 2gang	SR-2-84	1	piece
2CKA006220A0145	SRB-1-84 rocker 1gang, blinds	SRB-1-84	1	piece
2CKA006220A0160	SRB-2-84 rocker 2g, blinds	SRB-2-84	1	piece
2CKA006220A0151	SRD-1-84 rocker 1gang, dimming	SRD-1-84	1	piece
2CKA006220A0166	SRD-2-L-84 rocker 2g, left, dimming	SRD-2-L-84	1	piece
2CKA006220A0260	SRD-2-R-84 rocker 2g, right, dimming	SRD-2-R-84	1	piece
2CKA006220A0142	SRL-1-84 rocker 1gang, lighting	SRL-1-84	1	piece
2CKA006220A0157	SRL-2-L-84 rocker 2g, left, lighting	SRL-2-L-84	1	piece
2CKA006220A0169	SRL-2-R-84 rocker 2g, right, lighting	SRL-2-R-84	1	piece
2CKA006220A0148	SRS-1-84 rocker 1gang, scene	SRS-1-84	1	piece
2CKA006220A0163	SRS-2-L-84 rocker 2gang, left, scene	SRS-2-L-84	1	piece
2CKA006220A0175	SRS-2-R-84 rocker 2g, right, scene	SRS-2-R-84	1	piece
2CKA001731A1921	1716-81 Cover Info light anthracite - 63x63	1716-81	1	piece
2CKA001731A1922	1716-82 Cover Info light ivory white - 63x63	1716-82	1	piece
2CKA001731A1950	1716-83 Cover Info light aluminium silver - 63x63	1716-83	1	piece
2CKA001731A2025	1716-840-500 Cover Plates LED antique brass - 63x63	1716-840-500	1	piece
2CKA001731A1955	1716-866 Cover Info light stainless steel - Pure Stainless Steel	1716-866	1	piece
2CKA001731A1978	1716-884 Cover Info light studio white matt - 63x63	1716-884	1	piece
2CKA001731A1980	1716-885 Cover Info light black matt - 63x63	1716-885	1	piece
2CKA001731A1914	1720-81 Rocker Switch Pull cord anthracite - 63x63	1720-81	1	piece
2CKA001731A1915	1720-82 Rocker Switch Pull cord ivory white - 63x63	1720-82	1	piece
2CKA001731A1949	1720-83 Rocker Switch Pull cord aluminium silver - 63x63	1720-83	1	piece
2CKA001731A1954	1720-866 Rocker Switch Pull cord stainless steel - Pure Stainless Steel	1720-866	1	piece
2CKA001731A1979	1720-884 Rocker Switch Pull cord studio white matt - 63x63	1720-884	1	piece
2CKA001731A1981	1720-885 Rocker Switch Pull cord black matt - 63x63	1720-885	1	piece
2CKA001710A4119	1740 DR/03-803 Cover Plate Level switch Turn button grey metallic - 63x63	1740 DR/03-803	1	piece
2CKA001710A4120	1740 DR/03-81 Cover Plate Level switch Turn button anthracite - 63x63	1740 DR/03-81	1	piece
2CKA001710A3807	1740 DR/03-82 Cover Plate Level switch Turn button ivory white - 63x63	1740 DR/03-82	1	piece
2CKA001710A3811	1740 DR/03-83 Cover Plate Level switch Turn button aluminium silver - 63x63	1740 DR/03-83	1	piece
2CKA001710A3812	1740 DR/03-866 Cover Plate Level switch Turn button stainless steel - Pure Stainless Steel	1740 DR/03-866	1	piece
2CKA001710A3870	1740 DR/03-884 Cover Plate Level switch Turn button studio white matt - 63x63	1740 DR/03-884	1	piece
2CKA001710A3892	1740 DR/03-885 Cover Plate Level switch Turn button black matt - 63x63	1740 DR/03-885	1	piece
2CKA001710A4121	1740 DRL-803-503 Cover Plates Level switch Turn button Symbol "3-level switch" grey metallic - 63x63	1740 DRL-803-503	1	piece
2CKA001710A4122	1740 DRL-81-503 Cover Plates Level switch Turn button Symbol "3-level switch" anthracite - 63x63	1740 DRL-81-503	1	piece
2CKA001710A3511	1740 DRL-82-503 Cover Plates Level switch Turn button Symbol "3-level switch" ivory white - 63x63	1740 DRL-82-503	1	piece
2CKA001710A4123	1740 DRL-83-503 Cover Plates Level switch Turn button Symbol "3-level switch" aluminium silver - 63x63	1740 DRL-83-503	1	piece

2CKA001710A3771	1740 DRL-866-503 Cover Plates Level switch Turn button Symbol "arrows" stainless steel - Pure Stainless Steel	1740 DRL-866-503	1	piece
2CKA001710A3871	1740 DRL-884-503 Cover Plates Level switch Turn button Symbol "3-level switch" studio white matt - 63x63	1740 DRL-884-503	1	piece
2CKA001710A3893	1740 DRL-885-503 Cover Plates Level switch Turn button Symbol "3-level switch" black matt - 63x63	1740 DRL-885-503	1	piece
2CKA001710A3840	1740-803 Cover Plate Venetian blind Turn button grey metallic - 63x63	1740-803	1	piece
2CKA001710A3623	1740-81 Cover Plate Venetian blind Turn button anthracite - 63x63	1740-81	1	piece
2CKA001710A3154	1740-82 Cover Plate Venetian blind Turn button ivory white - 63x63	1740-82	1	piece
2CKA001710A3661	1740-83 Cover Plate Venetian blind Turn button aluminium silver - 63x63	1740-83	1	piece
2CKA001710A4089	1740-840-500 Cover Plates Venetian blind Turn button Symbol "arrows" antique brass - 63x63	1740-840-500	1	piece
2CKA001710A3748	1740-866 Cover Plate Venetian blind Turn button stainless steel - Pure Stainless Steel	1740-866	1	piece
2CKA001710A3872	1740-884 Cover Plate Venetian blind Turn button studio white matt - 63x63	1740-884	1	piece
2CKA001710A3894	1740-885 Cover Plate Venetian blind Turn button black matt - 63x63	1740-885	1	piece
2CKA001710A3843	1742-803 Cover Plate Blind cap 1 gang(s) with Mounting plate grey metallic - 63x63	1742-803	1	piece
2CKA001710A3612	1742-81 Cover Plate Blind cap 1 gang(s) with Mounting plate anthracite - 63x63	1742-81	1	piece
2CKA001710A3143	1742-82 Cover Plate Blind cap 1 gang(s) with Mounting plate ivory white - 63x63	1742-82	1	piece
2CKA001710A3664	1742-83 Cover Plate Blind cap 1 gang(s) with Mounting plate aluminium silver - 63x63	1742-83	1	piece
2CKA001710A4080	1742-840-500 Inserts with Cover Plate Blind cap 0 pole antique brass - 63x63	1742-840-500	1	piece
2CKA001710A3751	1742-866 Cover Plate Blind cap 1 gang(s) with Mounting plate stainless steel - Pure Stainless Steel	1742-866	1	piece
2CKA001710A3873	1742-884 Cover Plate Blind cap 1 gang(s) with Mounting plate studio white matt - 63x63	1742-884	1	piece
2CKA001710A3895	1742-885 Cover Plate Blind cap 1 gang(s) with Mounting plate black matt - 63x63	1742-885	1	piece
2CKA001724A4364	1743/10-04-803 Cover Plate SAT 1 gang(s) 4 gang(s) grey metallic - 63x63	1743/10-04-803	1	piece
2CKA001724A4365	1743/10-04-81 Cover Plate SAT 1 gang(s) 4 gang (s) anthracite - 63x63	1743/10-04-81	1	piece
2CKA001724A4366	1743/10-04-82 Cover Plate SAT 1 gang(s) 4 gang (s) ivory white - 63x63	1743/10-04-82	1	piece
2CKA001724A4367	1743/10-04-83 Cover Plate SAT 1 gang(s) 4 gang (s) aluminium silver - 63x63	1743/10-04-83	1	piece
2CKA001724A4369	1743/10-04-866 Cover Plate SAT 1 gang(s) 4 gang(s) stainless steel - Pure Stainless Steel	1743/10-04-866	1	piece
2CKA001724A4370	1743/10-04-884 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) studio white matt - 63x63	1743/10-04-884	1	piece
2CKA001724A4371	1743/10-04-885 Cover Plate SAT 1 gang(s) 4 gang(s) black matt - 63x63	1743/10-04-885	1	piece
2CKA001724A4373	1743-04-803 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) grey metallic - 63x63	1743-04-803	1	piece
2CKA001724A4374	1743-04-81 Cover Plate SAT 1 gang(s) 4 gang(s) anthracite - 63x63	1743-04-81	1	piece
2CKA001724A4375	1743-04-82 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) ivory white - 63x63	1743-04-82	1	piece
2CKA001724A4376	1743-04-83 Cover Plate SAT 1 gang(s) 4 gang(s) aluminium silver - 63x63	1743-04-83	1	piece

2CKA001724A4378	1743-04-866 Cover Plate SAT 1 gang(s) 4 gang(s) stainless steel - Pure Stainless Steel	1743-04-866	1	piece
2CKA001724A4379	1743-04-884 Cover Plate TV / Radio / 2x SAT 1 gang(s) 4 gang(s) studio white matt - 63x63	1743-04-884	1	piece
2CKA001724A4380	1743-04-885 Cover Plate SAT 1 gang(s) 4 gang(s) black matt - 63x63	1743-04-885	1	piece
2CKA001724A4291	1743-803 Cover Plate SAT 1 gang(s) 3 gang(s) grey metallic - 63x63	1743-803	1	piece
2CKA001724A4252	1743-81 Cover Plate SAT 1 gang(s) 3 gang(s) anthracite - 63x63	1743-81	1	piece
2CKA001724A2758	1743-82 Cover Plate SAT 1 gang(s) 3 gang(s) ivory white - 63x63	1743-82	1	piece
2CKA001724A4262	1743-83 Cover Plate SAT 1 gang(s) 3 gang(s) aluminium silver - 63x63	1743-83	1	piece
2CKA001724A4362	1743-840-500 Cover Plate SAT 3 gang(s) antique brass - 63x63	1743-840-500	1	piece
2CKA001724A4271	1743-866 Cover Plate SAT 1 gang(s) 3 gang(s) stainless steel - Pure Stainless Steel	1743-866	1	piece
2CKA001724A4293	1743-884 Cover Plate SAT 1 gang(s) 3 gang(s) studio white matt - 63x63	1743-884	1	piece
2CKA001724A4298	1743-885 Cover Plate SAT 1 gang(s) 3 gang(s) black matt - 63x63	1743-885	1	piece
2CKA001710A3855	1745-803 Cover Plate telephone connector boxes (VDo) 1 gang(s) grey metallic - 63x63	1745-803	1	piece
2CKA001710A3624	1745-81 Cover Plate telephone connector boxes (VDo) 1 gang(s) anthracite - 63x63	1745-81	1	piece
2CKA001710A3155	1745-82 Cover Plate telephone connector boxes (VDo) 1 gang(s) ivory white - 63x63	1745-82	1	piece
2CKA001710A3675	1745-83 Cover Plate telephone connector boxes (VDo) 1 gang(s) aluminium silver - 63x63	1745-83	1	piece
2CKA001710A3766	1745-866 Cover Plate telephone connector boxes (VDo) 1 gang(s) stainless steel - Pure Stainless Steel	1745-866	1	piece
2CKA001710A3874	1745-884 Cover Plate telephone connector boxes (VDo) 1 gang(s) studio white matt - 63x63	1745-884	1	piece
2CKA001710A3896	1745-885 Cover Plate telephone connector boxes (VDo) 1 gang(s) black matt - 63x63	1745-885	1	piece
2CKA001710A3857	1746/10-803 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) grey metallic - 63x63	1746/10-803	1	piece
2CKA001710A3628	1746/10-81 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) anthracite - 63x63	1746/10-81	1	piece
2CKA001710A3521	1746/10-82 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) ivory white - 63x63	1746/10-82	1	piece
2CKA001710A3677	1746/10-83 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) aluminium silver - 63x63	1746/10-83	1	piece
2CKA001710A3768	1746/10-866 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) stainless steel - Pure Stainless Steel	1746/10-866	1	piece
2CKA001710A3875	1746/10-884 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) studio white matt - 63x63	1746/10-884	1	piece
2CKA001710A3897	1746/10-885 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) black matt - 63x63	1746/10-885	1	piece
2CKA001710A3858	1746-803 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid grey metallic - 63x63	1746-803	1	piece
2CKA001710A3618	1746-81 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid anthracite - 63x63	1746-81	1	piece
2CKA001710A3149	1746-82 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid ivory white - 63x63	1746-82	1	piece

2CKA001710A3678	1746-83 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid aluminium silver - 63x63	1746-83	1	piece
2CKA001710A4086	1746-840-500 Switch Assortments 0 pole antique brass - 63x63	1746-840-500	1	piece
2CKA001710A3769	1746-866 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid stainless steel - Pure Stainless Steel	1746-866	1	piece
2CKA001710A3876	1746-884 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid studio white matt - 63x63	1746-884	1	piece
2CKA001710A3898	1746-885 Intermediate Ring Telecommunication inserts 50 x 50 mm 1 gang(s) with Hinged Lid black matt - 63x63	1746-885	1	piece
2CKA001710A4092	1747 BSI-803 Intermediate Ring Cover plates Busch-Balance® SI grey metallic - 63x63	1747 BSI-803	1	piece
2CKA001710A4093	1747 BSI-81 Intermediate Ring Cover plates Busch-Balance® SI anthracite - 63x63	1747 BSI-81	1	piece
2CKA001710A4094	1747 BSI-82 Intermediate Ring Cover plates Busch-Balance® SI ivory white - 63x63	1747 BSI-82	1	piece
2CKA001710A4095	1747 BSI-83 Intermediate Ring Cover plates Busch-Balance® SI aluminium silver - 63x63	1747 BSI-83	1	piece
2CKA001710A4097	1747 BSI-866 Intermediate Ring Cover plates Busch-Balance® SI stainless steel - Pure Stainless Steel	1747 BSI-866	1	piece
2CKA001710A4098	1747 BSI-884 Intermediate Ring Cover plates Busch-Balance® SI studio white matt - 63x63	1747 BSI-884	1	piece
2CKA001710A4099	1747 BSI-885 Intermediate Ring Cover plates Busch-Balance® SI black matt - 63x63	1747 BSI-885	1	piece
2CKA001710A3862	1747 SI-82 Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - 63x63	1747 SI-82	1	piece
2CKA001710A4079	1747 SI-840-500 Cover Plates antique brass - 63x63	1747 SI-840-500	1	piece
2CKA001710A3860	1747-82 Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - 63x63	1747-82	1	piece
2CKA001710A3851	1748-803 Cover Plate Data connection 2 gang(s) grey metallic - 63x63	1748-803	1	piece
2CKA001710A3654	1748-81 Cover Plate Data connection 2 gang(s) anthracite - 63x63	1748-81	1	piece
2CKA001710A3655	1748-82 Cover Plate Data connection 2 gang(s) ivory white - 63x63	1748-82	1	piece
2CKA001710A3673	1748-83 Cover Plate Data connection 2 gang(s) aluminium silver - 63x63	1748-83	1	piece
2CKA001710A3760	1748-866 Cover Plate Data connection 2 gang(s) stainless steel - Pure Stainless Steel	1748-866	1	piece
2CKA001710A3877	1748-884 Cover Plate Data connection 2 gang(s) studio white matt - 63x63	1748-884	1	piece
2CKA001710A3899	1748-885 Cover Plate Data connection 2 gang(s) black matt - 63x63	1748-885	1	piece
2CKA001710A3844	1749-803 Cover Plate Cable outlet 1 gang(s) grey metallic - 63x63	1749-803	1	piece
2CKA001710A3614	1749-81 Cover Plate Cable outlet 1 gang(s) anthracite - 63x63	1749-81	1	piece
2CKA001710A3145	1749-82 Cover Plate Cable outlet 1 gang(s) ivory white - 63x63	1749-82	1	piece
2CKA001710A3665	1749-83 Cover Plate Cable outlet 1 gang(s) aluminium silver - 63x63	1749-83	1	piece
2CKA001710A4081	1749-840-500 Cover Plates Cable outlet 0 pole antique brass - 63x63	1749-840-500	1	piece
2CKA001710A3752	1749-866 Cover Plate Cable outlet 1 gang(s) stainless steel - Pure Stainless Steel	1749-866	1	piece
2CKA001710A3878	1749-884 Cover Plate Cable outlet 1 gang(s) studio white matt - 63x63	1749-884	1	piece

2CKA001710A3900	1749-885 Cover Plate Cable outlet 1 gang(s) black matt - 63x63	1749-885	1	piece
2CKA001710A3859	1750-803 Cover Plate BNC/TNC 2 gang(s) grey metallic - 63x63	1750-803	1	piece
2CKA001710A3617	1750-81 Cover Plate BNC/TNC 2 gang(s) anthracite - 63x63	1750-81	1	piece
2CKA001710A3148	1750-82 Cover Plate BNC/TNC 2 gang(s) ivory white - 63x63	1750-82	1	piece
2CKA001710A3679	1750-83 Cover Plate BNC/TNC 2 gang(s) aluminium silver - 63x63	1750-83	1	piece
2CKA001710A3770	1750-866 Cover Plate BNC/TNC 2 gang(s) stainless steel - Pure Stainless Steel	1750-866	1	piece
2CKA001710A3879	1750-884 Cover Plate BNC/TNC 2 gang(s) studio white matt - 63x63	1750-884	1	piece
2CKA001710A3901	1750-885 Cover Plate BNC/TNC 2 gang(s) black matt - 63x63	1750-885	1	piece
2CKA001723A0257	1751-803 Cover Plate Loudspeaker 2 gang(s) grey metallic - 63x63	1751-803	1	piece
2CKA001723A0253	1751-81 Cover Plate Loudspeaker 2 gang(s) anthracite - 63x63	1751-81	1	piece
2CKA001723A0239	1751-82 Cover Plate Loudspeaker 2 gang(s) ivory white - 63x63	1751-82	1	piece
2CKA001723A0254	1751-83 Cover Plate Loudspeaker 2 gang(s) aluminium silver - 63x63	1751-83	1	piece
2CKA001723A0255	1751-866 Cover Plate Loudspeaker 2 gang(s) stainless steel - Pure Stainless Steel	1751-866	1	piece
2CKA001723A0260	1751-884 Cover Plate Loudspeaker 2 gang(s) studio white matt - 63x63	1751-884	1	piece
2CKA001723A0259	1751-885 Cover Plate Loudspeaker 2 gang(s) black matt - 63x63	1751-885	1	piece
2CKA001710A3841	1755 SL/PZ-803-101 Cover Plate Venetian blind Key grey metallic - 63x63	1755 SL/PZ- 803-101	1	piece
2CKA001710A3626	1755 SL/PZ-81-101 Cover Plate Venetian blind Key anthracite - 63x63	1755 SL/PZ-81 -101	1	piece
2CKA001710A3157	1755 SL/PZ-82-101 Cover Plate Venetian blind Key ivory white - 63x63	1755 SL/PZ-82 -101	1	piece
2CKA001710A3662	1755 SL/PZ-83-101 Cover Plate Venetian blind Key aluminium silver - 63x63	1755 SL/PZ-83 -101	1	piece
2CKA001710A3749	1755 SL/PZ-866-101 Cover Plate Venetian blind Key stainless steel - Pure Stainless Steel	1755 SL/PZ- 866-101	1	piece
2CKA001710A3925	1755 SL/PZ-884-101 Cover Plate Venetian blind Key studio white matt - 63x63	1755 SL/PZ- 884-101	1	piece
2CKA001710A3902	1755 SL/PZ-885-101 Cover Plate Venetian blind Key black matt - 63x63	1755 SL/PZ- 885-101	1	piece
2CKA001753A0088	1756-803 Cover Plate Info light grey metallic - 63x63	1756-803	1	piece
2CKA001753A0089	1756-81 Cover Plate Info light anthracite - 63x63	1756-81	1	piece
2CKA001753A0091	1756-83 Cover Plate Info light aluminium silver - 63x63	1756-83	1	piece
2CKA001753A0093	1756-866 Cover Plate Info light stainless steel - Pure Stainless Steel	1756-866	1	piece
2CKA001753A0251	1756-884 Cover Plate Info light studio white matt - 63x63	1756-884	1	piece
2CKA001753A0252	1756-885 Cover Plate Info light black matt - 63x63	1756-885	1	piece
2CKA001724A4292	1758-803 Cover Plate For data connection housing 2 gang(s) grey metallic - 63x63	1758-803	1	piece
2CKA001724A4253	1758-81 Cover Plate For data connection housing 2 gang(s) anthracite - 63x63	1758-81	1	piece
2CKA001724A2759	1758-82 Cover Plate For data connection housing 2 gang(s) ivory white - 63x63	1758-82	1	piece
2CKA001724A4263	1758-83 Cover Plate For data connection housing 2 gang(s) aluminium silver - 63x63	1758-83	1	piece

2CKA001724A4272	1758-866 Cover Plate For data connection housing 2 gang(s) stainless steel - Pure Stainless Steel	1758-866	1	piece
2CKA001724A4307	1758-884 Cover Plate For data connection housing 2 gang(s) studio white matt - 63x63	1758-884	1	piece
2CKA001724A4299	1758-885 Cover Plate For data connection housing 2 gang(s) black matt - 63x63	1758-885	1	piece
2CKA001710A4103	1762-81-506 Cover Plates TDO anthracite - 63x63	1762-81-506	1	piece
2CKA001710A4104	1762-82-506 Cover Plates TDO ivory white - 63x63	1762-82-506	1	piece
2CKA001710A4105	1762-83-506 Cover Plates TDO aluminium silver - 63x63	1762-83-506	1	piece
2CKA001710A4107	1762-866-506 Cover Plates TDO stainless steel - Pure Stainless Steel	1762-866-506	1	piece
2CKA001710A4108	1762-884-506 Cover Plates TDO studio white matt - 63x63	1762-884-506	1	piece
2CKA001710A4109	1762-885-506 Cover Plates TDO black matt - 63x63	1762-885-506	1	piece
2CKA001731A3997	1764 NLI/KI-803 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp grey metallic - 63x63	1764 NLI/KI-803	1	piece
2CKA001731A3998	1764 NLI/KI-81 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp anthracite - 63x63	1764 NLI/KI-81	1	piece
2CKA001731A3999	1764 NLI/KI-82 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp ivory white - 63x63	1764 NLI/KI-82	1	piece
2CKA001731A4000	1764 NLI/KI-83 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp aluminium silver - 63x63	1764 NLI/KI-83	1	piece
2CKA001731A4003	1764 NLI/KI-866 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp stainless steel - Pure Stainless Steel	1764 NLI/KI-866	1	piece
2CKA001731A4004	1764 NLI/KI-884 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp studio white matt - 63x63	1764 NLI/KI-884	1	piece
2CKA001731A4005	1764 NLI/KI-885 Rocker Switch/push button Single push button Symbol "bell" with Pilot lamp black matt - 63x63	1764 NLI/KI-885	1	piece
2CKA001731A4011	1764 NLI-12-82-101 Rocker Switch/push button Single push button with Pilot lamp red - 63x63	1764 NLI-12-82-101	1	piece
2CKA001731A4007	1764 NLI-13-82 Rocker Switch/push button Single push button with Pilot lamp green - 63x63	1764 NLI-13-82	1	piece
2CKA001731A1975	1764 NLI-803 Rocker Switch/push button Single rocker with Pilot lamp grey metallic - 63x63	1764 NLI-803	1	piece
2CKA001731A1552	1764 NLI-81 Rocker Switch/push button Single push button with Pilot lamp anthracite - 63x63	1764 NLI-81	1	piece
2CKA001731A1876	1764 NLI-82 Rocker Switch/push button Single push button with Pilot lamp ivory white - 63x63	1764 NLI-82	1	piece
2CKA001731A1948	1764 NLI-83 Rocker Switch/push button Single push button with Pilot lamp aluminium silver - 63x63	1764 NLI-83	1	piece
2CKA001731A2024	1764 NLI-840-500 Rocker Switch/push button Single rocker Without imprint with Pilot lamp antique brass - 63x63	1764 NLI-840-500	1	piece
2CKA001731A1953	1764 NLI-866 Rocker Switch/push button Single push button with Pilot lamp stainless steel - Pure Stainless Steel	1764 NLI-866	1	piece
2CKA001731A1985	1764 NLI-884 Rocker Switch/push button Single push button with Pilot lamp studio white matt - 63x63	1764 NLI-884	1	piece
2CKA001731A1982	1764 NLI-885 Rocker Switch/push button Single push button with Pilot lamp black matt - 63x63	1764 NLI-885	1	piece
2CKA001710A3854	1766-803 Cover Plate TAE 1 gang(s) 1 gang(s) grey metallic - 63x63	1766-803	1	piece

2CKA001710A3613	1766-81 Cover Plate TAE 1 gang(s) 1 gang(s) anthracite - 63x63	1766-81	1	piece
2CKA001710A3144	1766-82 Cover Plate TAE 1 gang(s) 1 gang(s) ivory white - 63x63	1766-82	1	piece
2CKA001710A3659	1766-83 Cover Plate TAE 1 gang(s) 1 gang(s) aluminium silver - 63x63	1766-83	1	piece
2CKA001710A4084	1766-840-500 Cover Plate TAE 0 gang(s) brass - 63x63	1766-840-500	1	piece
2CKA001710A3765	1766-866 Cover Plate TAE 1 gang(s) 1 gang(s) stainless steel - Pure Stainless Steel	1766-866	1	piece
2CKA001710A3926	1766-884 Cover Plate TAE 1 gang(s) 1 gang(s) studio white matt - 63x63	1766-884	1	piece
2CKA001710A3903	1766-885 Cover Plate TAE 1 gang(s) 1 gang(s) black matt - 63x63	1766-885	1	piece
2CKA001753A0254	1770-803-103 Cover Plate Time switch Toggle grey metallic - 63x63	1770-803-103	1	piece
2CKA001753A0255	1770-81-103 Cover Plate Time switch Toggle anthracite - 63x63	1770-81-103	1	piece
2CKA001753A0256	1770-82-103 Cover Plate Time switch Toggle ivory white - 63x63	1770-82-103	1	piece
2CKA001753A0257	1770-83-103 Cover Plate Time switch Toggle aluminium silver - 63x63	1770-83-103	1	piece
2CKA001753A0259	1770-866-103 Cover Plate Time switch Toggle stainless steel - Pure Stainless Steel	1770-866-103	1	piece
2CKA001753A0260	1770-884-103 Cover Plate Time switch Toggle studio white matt - 63x63	1770-884-103	1	piece
2CKA001753A0261	1770-885-103 Cover Plate Time switch Toggle black matt - 63x63	1770-885-103	1	piece
2CKA001753A0264	1771-803-103 Cover Plate Time switch Toggle grey metallic - 63x63	1771-803-103	1	piece
2CKA001753A0265	1771-81-103 Cover Plate Time switch Toggle anthracite - 63x63	1771-81-103	1	piece
2CKA001753A0266	1771-82-103 Cover Plate Time switch Toggle ivory white - 63x63	1771-82-103	1	piece
2CKA001753A0267	1771-83-103 Cover Plate Time switch Toggle aluminium silver - 63x63	1771-83-103	1	piece
2CKA001753A0302	1771-866-103 Cover Plate Time switch Toggle stainless steel - Pure Stainless Steel	1771-866-103	1	piece
2CKA001753A0303	1771-884-103 Cover Plate Time switch Toggle studio white matt - 63x63	1771-884-103	1	piece
2CKA001753A0304	1771-885-103 Cover Plate Time switch Toggle black matt - 63x63	1771-885-103	1	piece
2CKA001751A3101	1785 JA/02-82 Rocker Venetian blind Two-part rocker Symbol "arrows" ivory white	1785 JA/02-82	1	piece
2CKA001751A3097	1785 JA/02-83 Rocker Venetian blind Two-part rocker Symbol "arrows" aluminium silver	1785 JA/02-83	1	piece
2CKA001751A3103	1785 JA/02-884 Rocker Venetian blind Two-part rocker Symbol "arrows" studio white matt	1785 JA/02-884	1	piece
2CKA001751A3105	1785 JA/02-885 Rocker Venetian blind Two-part rocker Symbol "arrows" black matt	1785 JA/02-885	1	piece
2CKA001751A3020	1785 JA-803 Rocker Venetian blind Two-part rocker Symbol "arrows" grey metallic - 63x63	1785 JA-803	1	piece
2CKA001751A2934	1785 JA-81 Rocker Venetian blind Two-part rocker Symbol "arrows" anthracite - 63x63	1785 JA-81	1	piece
2CKA001751A2748	1785 JA-82 Rocker Venetian blind Two-part rocker Symbol "arrows" ivory white - 63x63	1785 JA-82	1	piece
2CKA001751A2944	1785 JA-83 Rocker Venetian blind Two-part rocker Symbol "arrows" aluminium silver - 63x63	1785 JA-83	1	piece
2CKA001751A3120	1785 JA-840-500 Cover Plates Venetian blind Two-part rocker Symbol "arrows" antique brass - 63x63	1785 JA-840-500	1	piece
2CKA001751A2964	1785 JA-866 Rocker Venetian blind Two-part rocker Symbol "arrows" stainless steel - Pure Stainless Steel	1785 JA-866	1	piece

2CKA001751A3022	1785 JA-884 Rocker Venetian blind Two-part rocker Symbol "arrows" studio white matt - 63x63	1785 JA-884	1	piece
2CKA001751A3036	1785 JA-885 Rocker Venetian blind Two-part rocker Symbol "arrows" black matt - 63x63	1785 JA-885	1	piece
2CKA001751A3126	1785 K-83-500 Cover Plates Switch/push button Two-part rocker None aluminium silver - 63x63	1785 K-83-500	1	piece
2CKA001751A3204	1785/11-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1785/11-803	1	piece
2CKA001751A3205	1785/11-81 Rocker Switch/push button Two-part rocker anthracite - 63x63	1785/11-81	1	piece
2CKA001751A2991	1785/11-82 Rocker Switch/push button Two-part rocker ivory white - 63x63	1785/11-82	1	piece
2CKA001751A2995	1785/11-83 Rocker Switch/push button Two-part rocker aluminium silver - 63x63	1785/11-83	1	piece
2CKA001751A3119	1785/11-840-500 Cover Plates Switch/push button Two-part rocker antique brass - 63x63	1785/11-840-500	1	piece
2CKA001751A2996	1785/11-866 Rocker Switch/push button Two-part rocker stainless steel - Pure Stainless Steel	1785/11-866	1	piece
2CKA001751A3023	1785/11-884 Rocker Switch/push button Two-part rocker studio white matt - 63x63	1785/11-884	1	piece
2CKA001751A3037	1785/11-885 Rocker Switch/push button Two-part rocker black matt - 63x63	1785/11-885	1	piece
2CKA001751A3018	1785-803 Rocker Switch/push button Two-part rocker grey metallic - 63x63	1785-803	1	piece
2CKA001751A2930	1785-81 Rocker Switch/push button Two-part rocker anthracite - 63x63	1785-81	1	piece
2CKA001751A2744	1785-82 Rocker Switch/push button Two-part rocker ivory white - 63x63	1785-82	1	piece
2CKA001751A2942	1785-83 Rocker Switch/push button Two-part rocker aluminium silver - 63x63	1785-83	1	piece
2CKA001751A3092	1785-83-500 Cover Plates Switch/push button Two-part rocker Without imprint aluminium silver - 63x63	1785-83-500	1	piece
2CKA001751A3117	1785-840-500 Cover Plates Switch/push button Two-part rocker Without imprint antique brass - 63x63	1785-840-500	1	piece
2CKA001751A3087	1785-866-500 Cover Plates Switch/push button Two-part rocker Without imprint stainless steel - Pure Stainless Steel	1785-866-500	1	piece
2CKA001751A3024	1785-884 Rocker Switch/push button Two-part rocker studio white matt - 63x63	1785-884	1	piece
2CKA001751A3038	1785-885 Rocker Switch/push button Two-part rocker black matt - 63x63	1785-885	1	piece
2CKA001751A3100	1786 JA/02-82 Rocker Venetian blind Single rocker ivory white	1786 JA/02-82	1	piece
2CKA001751A3096	1786 JA/02-83 Rocker Switch/push button Symbol "arrows" aluminium silver	1786 JA/02-83	1	piece
2CKA001751A3102	1786 JA/02-884 Rocker Venetian blind Single rocker studio white matt	1786 JA/02-884	1	piece
2CKA001751A3104	1786 JA/02-885 Rocker Symbol "arrows" black matt	1786 JA/02-885	1	piece
2CKA001751A3207	1786/11-81 Rocker Switch/push button Single rocker anthracite - 63x63	1786/11-81	1	piece
2CKA001751A2997	1786/11-82 Rocker Switch/push button Single rocker ivory white - 63x63	1786/11-82	1	piece
2CKA001751A3001	1786/11-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1786/11-83	1	piece
2CKA001751A3002	1786/11-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1786/11-866	1	piece
2CKA001751A3026	1786/11-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1786/11-884	1	piece
2CKA001751A3040	1786/11-885 Rocker Switch/push button Single rocker black matt - 63x63	1786/11-885	1	piece

2CKA001751A3145	1786-12-82 Rocker Switch/push button Single rocker red - 63x63	1786-12-82	1	piece
2CKA001751A3093	1786-803-500 Cover Plates Switch/push button Single rocker Without imprint grey metallic - 63x63	1786-803-500	1	piece
2CKA001751A3079	1786-81-500 Cover Plates Switch/push button Single rocker Without imprint anthracite - 63x63	1786-81-500	1	piece
2CKA001751A3083	1786-82-500 Cover Plates Switch/push button Single rocker Without imprint ivory white - 63x63	1786-82-500	1	piece
2CKA001751A3075	1786-83-500 Cover Plates Switch/push button Single rocker Without imprint aluminium silver - 63x63	1786-83-500	1	piece
2CKA001751A3116	1786-840-500 Cover Plates Switch/push button Single rocker Without imprint antique brass - 63x63	1786-840-500	1	piece
2CKA001751A3077	1786-866-500 Cover Plates Switch/push button Single rocker Without imprint stainless steel - Pure Stainless Steel	1786-866-500	1	piece
2CKA001751A3089	1786-884-500 Cover Plates Switch/push button Single rocker Without imprint studio white matt - 63x63	1786-884-500	1	piece
2CKA001751A3094	1786-885-500 Cover Plates Switch/push button Single rocker Without imprint black matt - 63x63	1786-885-500	1	piece
2CKA001751A3017	1788-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1788-803	1	piece
2CKA001751A2927	1788-81 Rocker Switch/push button Single rocker anthracite - 63x63	1788-81	1	piece
2CKA001751A2742	1788-82 Rocker Switch/push button Single rocker ivory white - 63x63	1788-82	1	piece
2CKA001751A2954	1788-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1788-83	1	piece
2CKA001751A2961	1788-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1788-866	1	piece
2CKA001751A3028	1788-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1788-884	1	piece
2CKA001751A3042	1788-885 Rocker Switch/push button Single rocker black matt - 63x63	1788-885	1	piece
2CKA001751A3019	1789 H-803 Rocker Switch/push button Single rocker Heizung grey metallic - 63x63	1789 H-803	1	piece
2CKA001751A2929	1789 H-81 Rocker Switch/push button Single rocker Heizung anthracite - 63x63	1789 H-81	1	piece
2CKA001751A2743	1789 H-82 Rocker Switch/push button Single rocker Heizung ivory white - 63x63	1789 H-82	1	piece
2CKA001751A2955	1789 H-83 Rocker Switch/push button Single rocker Heizung aluminium silver - 63x63	1789 H-83	1	piece
2CKA001751A2963	1789 H-866 Rocker Switch/push button Single rocker Heizung stainless steel - Pure Stainless Steel	1789 H-866	1	piece
2CKA001751A3029	1789 H-884 Rocker Switch/push button Single rocker Heizung studio white matt - 63x63	1789 H-884	1	piece
2CKA001751A3043	1789 H-885 Rocker Switch/push button Single rocker Heizung black matt - 63x63	1789 H-885	1	piece
2CKA001751A3015	1789 KI-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 KI-803	1	piece
2CKA001751A2932	1789 KI-81 Rocker Switch/push button Single rocker Symbol "bell" anthracite - 63x63	1789 KI-81	1	piece
2CKA001751A2746	1789 KI-82 Rocker Switch/push button Single rocker Symbol "bell" ivory white - 63x63	1789 KI-82	1	piece
2CKA001751A2952	1789 KI-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 KI-83	1	piece
2CKA001751A2959	1789 KI-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 KI-866	1	piece
2CKA001751A3030	1789 KI-884 Rocker Switch/push button Single rocker Symbol "bell" studio white matt - 63x63	1789 KI-884	1	piece

2CKA001751A3044	1789 KI-885 Rocker Switch/push button Single rocker Symbol "bell" black matt - 63x63	1789 KI-885	1	piece
2CKA001751A3014	1789 LI-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 LI-803	1	piece
2CKA001751A2931	1789 LI-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 LI-81	1	piece
2CKA001751A2745	1789 LI-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 LI-82	1	piece
2CKA001751A2951	1789 LI-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 LI-83	1	piece
2CKA001751A2958	1789 LI-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 LI-866	1	piece
2CKA001751A3031	1789 LI-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 LI-884	1	piece
2CKA001751A3045	1789 LI-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 LI-885	1	piece
2CKA001751A3146	1789 N-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 N-803	1	piece
2CKA001751A3147	1789 N-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 N-81	1	piece
2CKA001751A3148	1789 N-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 N-82	1	piece
2CKA001751A3149	1789 N-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 N-83	1	piece
2CKA001751A3152	1789 N-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 N-866	1	piece
2CKA001751A3153	1789 N-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 N-884	1	piece
2CKA001751A3154	1789 N-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 N-885	1	piece
2CKA001751A3156	1789 ST-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 ST-803	1	piece
2CKA001751A3157	1789 ST-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 ST-81	1	piece
2CKA001751A3158	1789 ST-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 ST-82	1	piece
2CKA001751A3159	1789 ST-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 ST-83	1	piece
2CKA001751A3162	1789 ST-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 ST-866	1	piece
2CKA001751A3163	1789 ST-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 ST-884	1	piece
2CKA001751A3164	1789 ST-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 ST-885	1	piece
2CKA001751A3016	1789 TR-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 TR-803	1	piece
2CKA001751A2933	1789 TR-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 TR-81	1	piece
2CKA001751A2747	1789 TR-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 TR-82	1	piece
2CKA001751A2953	1789 TR-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 TR-83	1	piece
2CKA001751A2960	1789 TR-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 TR-866	1	piece
2CKA001751A3032	1789 TR-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 TR-884	1	piece
2CKA001751A3046	1789 TR-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 TR-885	1	piece
2CKA001751A3013	1789-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789-803	1	piece
2CKA001751A2928	1789-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789-81	1	piece

2CKA001751A2813	1789-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789-82	1	piece
2CKA001751A2945	1789-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789-83	1	piece
2CKA001751A3118	1789-840-500 Cover Plates Switch/push button Single rocker Without imprint antique brass - 63x63	1789-840-500	1	piece
2CKA001751A2957	1789-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789-866	1	piece
2CKA001751A3033	1789-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789-884	1	piece
2CKA001751A3047	1789-885 Rocker Switch/push button Single rocker black matt - 63x63	1789-885	1	piece
2CKA001710A4124	1792-803 Cover Plate Switch/push button Hotel card grey metallic - 63x63	1792-803	1	piece
2CKA001710A3639	1792-81 Cover Plate Switch/push button Hotel card anthracite - 63x63	1792-81	1	piece
2CKA001710A3640	1792-82 Cover Plate Switch/push button Hotel card ivory white - 63x63	1792-82	1	piece
2CKA001710A3670	1792-83 Cover Plate Switch/push button Hotel card aluminium silver - 63x63	1792-83	1	piece
2CKA001710A4078	1792-840-500 Cover Plates Switch/push button Hotel card antique brass - 63x63	1792-840-500	1	piece
2CKA001710A3757	1792-866 Cover Plate Switch/push button Hotel card stainless steel - Pure Stainless Steel	1792-866	1	piece
2CKA001710A3928	1792-884 Cover Plate Switch/push button Hotel card studio white matt - 63x63	1792-884	1	piece
2CKA001710A3905	1792-885 Cover Plate Switch/push button Hotel card black matt - 63x63	1792-885	1	piece
2CKA001710A3849	1794 TA-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1794 TA-803	1	piece
2CKA001710A3695	1794 TA-81 Cover Plate Thermostat Turn button anthracite - 63x63	1794 TA-81	1	piece
2CKA001710A3696	1794 TA-82 Cover Plate Thermostat Turn button ivory white - 63x63	1794 TA-82	1	piece
2CKA001710A3697	1794 TA-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1794 TA-83	1	piece
2CKA001710A3761	1794 TA-866 Cover Plate Thermostat Turn button stainless steel - Pure Stainless Steel	1794 TA-866	1	piece
2CKA001710A3883	1794 TA-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1794 TA-884	1	piece
2CKA001710A3906	1794 TA-885 Cover Plate Thermostat Turn button black matt - 63x63	1794 TA-885	1	piece
2CKA001710A3847	1794-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1794-803	1	piece
2CKA001710A3629	1794-81 Cover Plate Thermostat Turn button anthracite - 63x63	1794-81	1	piece
2CKA001710A3543	1794-82 Cover Plate Thermostat Turn button ivory white - 63x63	1794-82	1	piece
2CKA001710A3668	1794-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1794-83	1	piece
2CKA001710A4087	1794-840-500 Cover Plates antique brass - 63x63	1794-840-500	1	piece
2CKA001710A3755	1794-866 Cover Plate Thermostat stainless steel - Pure Stainless Steel	1794-866	1	piece
2CKA001710A3884	1794-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1794-884	1	piece
2CKA001710A3907	1794-885 Cover Plate Thermostat Turn button black matt - 63x63	1794-885	1	piece
2CKA001710A4012	1795 HK-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1795 HK-803	1	piece
2CKA001710A4013	1795 HK-81 Cover Plate Thermostat Turn button anthracite - 63x63	1795 HK-81	1	piece

2CKA001710A4015	1795 HK-82 Cover Plate Thermostat Turn button ivory white - 63x63	1795 HK-82	1	piece
2CKA001710A4016	1795 HK-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1795 HK-83	1	piece
2CKA001710A4018	1795 HK-866 Cover Plate Thermostat Turn button stainless steel - Pure Stainless Steel	1795 HK-866	1	piece
2CKA001710A4019	1795 HK-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1795 HK-884	1	piece
2CKA001710A4020	1795 HK-885 Cover Plate Thermostat Turn button black matt - 63x63	1795 HK-885	1	piece
2CKA001710A4044	1795 HKEA-803 Cover Plate Thermostat Turn button 1 switchover grey metallic - 63x63	1795 HKEA-803	1	piece
2CKA001710A4045	1795 HKEA-81 Cover Plate Thermostat Turn button 1 switchover anthracite - 63x63	1795 HKEA-81	1	piece
2CKA001710A4047	1795 HKEA-82 Cover Plate Thermostat Turn button 1 switchover ivory white - 63x63	1795 HKEA-82	1	piece
2CKA001710A4048	1795 HKEA-83 Cover Plate Thermostat Turn button 1 switchover aluminium silver - 63x63	1795 HKEA-83	1	piece
2CKA001710A4050	1795 HKEA-866 Cover Plate Thermostat Turn button 1 switchover stainless steel - Pure Stainless Steel	1795 HKEA-866	1	piece
2CKA001710A4051	1795 HKEA-884 Cover Plate Thermostat Turn button 1 switchover studio white matt - 63x63	1795 HKEA-884	1	piece
2CKA001710A4052	1795 HKEA-885 Cover Plate Thermostat Turn button 1 switchover black matt - 63x63	1795 HKEA-885	1	piece
2CKA001710A3850	1795 TA-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1795 TA-803	1	piece
2CKA001710A3722	1795 TA-81 Cover Plate Thermostat Turn button anthracite - 63x63	1795 TA-81	1	piece
2CKA001710A3723	1795 TA-82 Cover Plate Thermostat Turn button ivory white - 63x63	1795 TA-82	1	piece
2CKA001710A3724	1795 TA-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1795 TA-83	1	piece
2CKA001710A3762	1795 TA-866 Cover Plate Thermostat Turn button stainless steel - Pure Stainless Steel	1795 TA-866	1	piece
2CKA001710A3885	1795 TA-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1795 TA-884	1	piece
2CKA001710A3908	1795 TA-885 Cover Plate Thermostat Turn button black matt - 63x63	1795 TA-885	1	piece
2CKA001710A3848	1795-803 Cover Plate Thermostat Turn button grey metallic - 63x63	1795-803	1	piece
2CKA001710A3630	1795-81 Cover Plate Thermostat Turn button anthracite - 63x63	1795-81	1	piece
2CKA001710A3568	1795-82 Cover Plate Thermostat Turn button ivory white - 63x63	1795-82	1	piece
2CKA001710A3669	1795-83 Cover Plate Thermostat Turn button aluminium silver - 63x63	1795-83	1	piece
2CKA001710A4088	1795-840-500 Cover Plates antique brass - 63x63	1795-840-500	1	piece
2CKA001710A3756	1795-866 Cover Plate Thermostat Turn button stainless steel - Pure Stainless Steel	1795-866	1	piece
2CKA001710A3886	1795-884 Cover Plate Thermostat Turn button studio white matt - 63x63	1795-884	1	piece
2CKA001710A3909	1795-885 Cover Plate Thermostat Turn button black matt - 63x63	1795-885	1	piece
2CKA001753A0307	1796-803 Cover Plate Pull cord grey metallic - 63x63	1796-803	1	piece
2CKA001753A0308	1796-81 Cover Plate Pull cord anthracite - 63x63	1796-81	1	piece
2CKA001753A0309	1796-82 Cover Plate Pull cord ivory white - 63x63	1796-82	1	piece
2CKA001753A0310	1796-83 Cover Plate Pull cord aluminium silver - 63x63	1796-83	1	piece
2CKA001753A0312	1796-866 Cover Plate Pull cord stainless steel - Pure Stainless Steel	1796-866	1	piece

2CKA001753A0313	1796-884 Cover Plate Pull cord studio white matt - 63x63	1796-884	1	piece
2CKA001753A0314	1796-885 Cover Plate Pull cord black matt - 63x63	1796-885	1	piece
2CKA001710A3856	1800-803 Cover Plate Modular Jack 1 gang(s) 2 gang(s) grey metallic - 63x63	1800-803	1	piece
2CKA001710A3627	1800-81 Cover Plate Modular Jack 1 gang(s) 2 gang(s) anthracite - 63x63	1800-81	1	piece
2CKA001710A3158	1800-82 Cover Plate Modular Jack 1 gang(s) 2 gang(s) ivory white - 63x63	1800-82	1	piece
2CKA001710A3676	1800-83 Cover Plate Modular Jack 1 gang(s) 2 gang(s) aluminium silver - 63x63	1800-83	1	piece
2CKA001710A4085	1800-840-500 Cover Plate Modular Jack 2 gang(s) antique brass - 63x63	1800-840-500	1	piece
2CKA001710A3767	1800-866 Cover Plate Modular Jack 1 gang(s) 2 gang(s) stainless steel - Pure Stainless Steel	1800-866	1	piece
2CKA001710A3887	1800-884 Cover Plate Modular Jack 1 gang(s) 2 gang(s) studio white matt - 63x63	1800-884	1	piece
2CKA001710A3910	1800-885 Cover Plate Modular Jack 1 gang(s) 2 gang(s) black matt - 63x63	1800-885	1	piece
2CKA001710A3853	1803-02-803 Cover Plate UAE/IAE (ISDN) 2 gang(s) 2 gang(s) grey metallic - 63x63	1803-02-803	1	piece
2CKA001710A3615	1803-02-81 Cover Plate UAE/IAE (ISDN) 2 gang(s) 2 gang(s) anthracite - 63x63	1803-02-81	1	piece
2CKA001710A3146	1803-02-82 Cover Plate UAE/IAE (ISDN) 2 gang(s) 2 gang(s) ivory white - 63x63	1803-02-82	1	piece
2CKA001710A3610	1803-02-83 Cover Plate UAE/IAE (ISDN) 2 gang(s) 2 gang(s) aluminium silver - 63x63	1803-02-83	1	piece
2CKA001710A4083	1803-02-840-500 Cover Plate UAE/IAE (ISDN) 2 gang(s) antique brass - 63x63	1803-02-840-500	1	piece
2CKA001710A3764	1803-02-866 Cover Plate UAE/IAE (ISDN) 2 gang(s) 2 gang(s) stainless steel - Pure Stainless Steel	1803-02-866	1	piece
2CKA001710A3888	1803-02-884 Cover Plate UAE/IAE (ISDN) 2 gang(s) 2 gang(s) studio white matt - 63x63	1803-02-884	1	piece
2CKA001710A3911	1803-02-885 Cover Plate UAE/IAE (ISDN) 2 gang(s) 2 gang(s) black matt - 63x63	1803-02-885	1	piece
2CKA001710A3852	1803-803 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) grey metallic - 63x63	1803-803	1	piece
2CKA001710A3616	1803-81 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) anthracite - 63x63	1803-81	1	piece
2CKA001710A3147	1803-82 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) ivory white - 63x63	1803-82	1	piece
2CKA001710A3674	1803-83 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) aluminium silver - 63x63	1803-83	1	piece
2CKA001710A4082	1803-840-500 Cover Plate UAE/IAE (ISDN) 1 gang(s) antique brass - 63x63	1803-840-500	1	piece
2CKA001710A3763	1803-866 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) stainless steel - Pure Stainless Steel	1803-866	1	piece
2CKA001710A3889	1803-884 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) studio white matt - 63x63	1803-884	1	piece
2CKA001710A3912	1803-885 Cover Plate UAE/IAE (ISDN) 2 gang(s) 1 gang(s) black matt - 63x63	1803-885	1	piece
2CKA002013A5404	20 EUAB-81 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUAB-81	1	piece
2CKA002013A5405	20 EUAB-82 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUAB-82	1	piece
2CKA002013A5406	20 EUAB-83 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUAB-83	1	piece

2CKA002013A5408	20 EUAB-866 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUAB-866	1	piece
2CKA002013A5409	20 EUAB-884 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUAB-884	1	piece
2CKA002013A5410	20 EUAB-885 Socket insert Busch-Object socket outlet Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUAB-885	1	piece
2CKA002011A6260	20 EUC-13-82-101 Socket insert Protective Contact (SCHUKO) 1gang(s) green - 63x63	20 EUC-13-82-101	1	piece
2CKA002011A3723	20 EUC-14-82 Socket Protective Contact (SCHUKO) 1gang(s) orange - 63x63	20 EUC-14-82	1	piece
2CKA002011A6216	20 EUC-803-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) grey metallic - 63x63	20 EUC-803-500	1	piece
2CKA002011A6215	20 EUC-81-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) anthracite - 63x63	20 EUC-81-500	1	piece
2CKA002011A6214	20 EUC-82-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) ivory white - 63x63	20 EUC-82-500	1	piece
2CKA002011A6213	20 EUC-83-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) aluminium silver - 63x63	20 EUC-83-500	1	piece
2CKA002011A6212	20 EUC-866-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) stainless steel - Pure Stainless Steel	20 EUC-866-500	1	piece
2CKA002011A6208	20 EUC-884-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white matt - 63x63	20 EUC-884-500	1	piece
2CKA002011A6211	20 EUC-885-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) black matt - 63x63	20 EUC-885-500	1	piece
2CKA002013A5472	20 EUCB-13-82-102 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) green - 63x63	20 EUCB-13-82-102	1	piece
2CKA002013A5413	20 EUCB-14-82-10 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) orange - 63x63	20 EUCB-14-82-10	1	piece
2CKA002013A5414	20 EUCBDR-803 Socket insert Busch-Service-Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUCBDR-803	1	piece
2CKA002013A5415	20 EUCBDR-81 Socket insert Busch-Service-Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCBDR-81	1	piece
2CKA002013A5416	20 EUCBDR-82 Socket insert Busch-Service-Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUCBDR-82	1	piece
2CKA002013A5417	20 EUCBDR-83 Socket insert Busch-Service-Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUCBDR-83	1	piece
2CKA002013A5419	20 EUCBDR-866 Socket insert Busch-Service-Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUCBDR-866	1	piece
2CKA002013A5420	20 EUCBDR-884 Socket insert Busch-Service-Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUCBDR-884	1	piece
2CKA002013A5421	20 EUCBDR-885 Socket insert Busch-Service-Socket Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCBDR-885	1	piece
2CKA002013A5467	20 EUCBL-13-84-101 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) green - 63x63	20 EUCBL-13-84-101	1	piece
2CKA002013A5288	20 EUCBL-14-84 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) orange - 63x63	20 EUCBL-14-84	1	piece

2CKA002013A5456	20 EUCBL-803 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) grey metallic - 63x63	20 EUCBL-803	1	piece
2CKA002013A5457	20 EUCBL-81 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) anthracite - 63x63	20 EUCBL-81	1	piece
2CKA002013A5284	20 EUCBL-82 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) ivory white - 63x63	20 EUCBL-82	1	piece
2CKA002013A5285	20 EUCBL-83 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) aluminium silver - 63x63	20 EUCBL-83	1	piece
2CKA002013A5289	20 EUCBL-866 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) stainless steel - Pure Stainless Steel	20 EUCBL-866	1	piece
2CKA002013A5336	20 EUCBL-884 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) studio white matt - 63x63	20 EUCBL-884	1	piece
2CKA002013A5330	20 EUCBL-885 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/Green 1gang(s) black matt - 63x63	20 EUCBL-885	1	piece
2CKA002013A5458	20 EUCBLI-803 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) grey metallic - 63x63	20 EUCBLI-803	1	piece
2CKA002013A5459	20 EUCBLI-81 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) anthracite - 63x63	20 EUCBLI-81	1	piece
2CKA002013A5292	20 EUCBLI-82 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) ivory white - 63x63	20 EUCBLI-82	1	piece
2CKA002013A5293	20 EUCBLI-83 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) aluminium silver - 63x63	20 EUCBLI-83	1	piece
2CKA002013A5399	20 EUCBLI-840-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass - 63x63	20 EUCBLI-840-500	1	piece
2CKA002013A5460	20 EUCBLI-866 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) stainless steel - Pure Stainless Steel	20 EUCBLI-866	1	piece
2CKA002013A5326	20 EUCBLI-884 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) studio white matt - 63x63	20 EUCBLI-884	1	piece
2CKA002013A5331	20 EUCBLI-885 Socket insert Protective Contact (SCHUKO) Safety Shutter LED/White 1gang(s) black matt - 63x63	20 EUCBLI-885	1	piece
2CKA002013A5463	20 EUCKSDV-12-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) red - 63x63	20 EUCKSDV-12-82-101	1	piece
2CKA002013A5462	20 EUCKSDV-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUCKSDV-803	1	piece
2CKA002013A5266	20 EUCKSDV-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCKSDV-81	1	piece
2CKA002013A5267	20 EUCKSDV-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUCKSDV-82	1	piece
2CKA002013A5273	20 EUCKSDV-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUCKSDV-83	1	piece
2CKA002013A5277	20 EUCKSDV-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUCKSDV-866	1	piece
2CKA002013A5327	20 EUCKSDV-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUCKSDV-884	1	piece
2CKA002013A5332	20 EUCKSDV-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCKSDV-885	1	piece

2CKA002013A5464	20 EUCKS-12-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) red - 63x63	20 EUCKS-12-82-101	1	piece
2CKA002013A5470	20 EUCKS-13-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) green - 63x63	20 EUCKS-13-82-101	1	piece
2CKA002013A5324	20 EUCKS-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) orange - 63x63	20 EUCKS-14-82	1	piece
2CKA002013A5297	20 EUCKS-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUCKS-803	1	piece
2CKA002013A5265	20 EUCKS-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCKS-81	1	piece
2CKA002013A5376	20 EUCKS-82-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) ivory white - 63x63	20 EUCKS-82-500	1	piece
2CKA002013A5375	20 EUCKS-83-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) aluminium silver - 63x63	20 EUCKS-83-500	1	piece
2CKA002013A5401	20 EUCKS-845-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass anthracite - 63x63	20 EUCKS-845-500	1	piece
2CKA002013A5398	20 EUCKS-848-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass ivory white - 63x63	20 EUCKS-848-500	1	piece
2CKA002013A5374	20 EUCKS-866-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) stainless steel - Pure Stainless Steel	20 EUCKS-866-500	1	piece
2CKA002013A5373	20 EUCKS-884-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) studio white matt - 63x63	20 EUCKS-884-500	1	piece
2CKA002013A5333	20 EUCKS-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCKS-885	1	piece
2CKA002013A5423	20 EUCNB-12-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) red - 63x63	20 EUCNB-12-82	1	piece
2CKA002013A5424	20 EUCNB-13-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) green - 63x63	20 EUCNB-13-82	1	piece
2CKA002013A5425	20 EUCNB-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) orange - 63x63	20 EUCNB-14-82	1	piece
2CKA002013A5426	20 EUCNB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUCNB-803	1	piece
2CKA002013A5427	20 EUCNB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCNB-81	1	piece
2CKA002013A5428	20 EUCNB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUCNB-82	1	piece
2CKA002013A5429	20 EUCNB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUCNB-83	1	piece
2CKA002013A5432	20 EUCNB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUCNB-866	1	piece
2CKA002013A5433	20 EUCNB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUCNB-884	1	piece
2CKA002013A5434	20 EUCNB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCNB-885	1	piece
2CKA002013A5436	20 EUICRB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	20 EUICRB-803	1	piece

2CKA002013A5437	20 EUCRB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	20 EUCRB-81	1	piece
2CKA002013A5438	20 EUCRB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	20 EUCRB-82	1	piece
2CKA002013A5439	20 EUCRB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	20 EUCRB-83	1	piece
2CKA002013A5442	20 EUCRB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 EUCRB-866	1	piece
2CKA002013A5443	20 EUCRB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	20 EUCRB-884	1	piece
2CKA002013A5444	20 EUCRB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	20 EUCRB-885	1	piece
2CKA002018A1493	20 EUK-803 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUK-803	1	piece
2CKA002018A1486	20 EUK-81 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid anthracite - 63x63	20 EUK-81	1	piece
2CKA002018A1465	20 EUK-82 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid ivory white - 63x63	20 EUK-82	1	piece
2CKA002018A1487	20 EUK-83 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUK-83	1	piece
2CKA002018A1515	20 EUK-840-500 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) with Hinged Lid antique brass - 63x63	20 EUK-840-500	1	piece
2CKA002018A1490	20 EUK-866 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid stainless steel - Pure Stainless Steel	20 EUK-866	1	piece
2CKA002018A1494	20 EUK-884 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUK-884	1	piece
2CKA002018A1495	20 EUK-885 Socket insert Protective Contact (SCHUKO) 1gang(s) with Hinged Lid black matt - 63x63	20 EUK-885	1	piece
2CKA002018A1516	20 EUKB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUKB-803	1	piece
2CKA002018A1517	20 EUKB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKB-81	1	piece
2CKA002018A1518	20 EUKB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKB-82	1	piece
2CKA002018A1519	20 EUKB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKB-83	1	piece
2CKA002018A1521	20 EUKB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid stainless steel - Pure Stainless Steel	20 EUKB-866	1	piece
2CKA002018A1522	20 EUKB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKB-884	1	piece
2CKA002018A1523	20 EUKB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKB-885	1	piece
2CKA002018A1525	20 EUKBR-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUKBR-803	1	piece
2CKA002018A1526	20 EUKBR-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKBR-81	1	piece

2CKA002018A1527	20 EUKBR-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKBR-82	1	piece
2CKA002018A1528	20 EUKBR-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKBR-83	1	piece
2CKA002018A1530	20 EUKBR-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKBR-884	1	piece
2CKA002018A1531	20 EUKBR-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKBR-885	1	piece
2CKA002018A1533	20 EUKNB-12-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid red - 63x63	20 EUKNB-12-82	1	piece
2CKA002018A1534	20 EUKNB-13-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid green - 63x63	20 EUKNB-13-82	1	piece
2CKA002018A1535	20 EUKNB-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid orange - 63x63	20 EUKNB-14-82	1	piece
2CKA002018A1536	20 EUKNB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUKNB-803	1	piece
2CKA002018A1537	20 EUKNB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKNB-81	1	piece
2CKA002018A1538	20 EUKNB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKNB-82	1	piece
2CKA002018A1539	20 EUKNB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKNB-83	1	piece
2CKA002018A1541	20 EUKNB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKNB-884	1	piece
2CKA002018A1542	20 EUKNB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKNB-885	1	piece
2CKA002018A1544	20 EUKNBL-12-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid red - 63x63	20 EUKNBL-12-82	1	piece
2CKA002018A1545	20 EUKNBL-13-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid green - 63x63	20 EUKNBL-13-82	1	piece
2CKA002018A1546	20 EUKNBL-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid orange - 63x63	20 EUKNBL-14-82	1	piece
2CKA002018A1547	20 EUKNBL-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid grey metallic - 63x63	20 EUKNBL-803	1	piece
2CKA002018A1548	20 EUKNBL-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKNBL-81	1	piece
2CKA002018A1552	20 EUKNBL-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKNBL-884	1	piece
2CKA002018A1553	20 EUKNBL-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKNBL-885	1	piece
2CKA002018A1557	20 EUKNBSL-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKNBSL-81	1	piece
2CKA002018A1558	20 EUKNBSL-81-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid anthracite - 63x63	20 EUKNBSL-81-101	1	piece
2CKA002018A1559	20 EUKNBSL-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKNBSL-82	1	piece

2CKA002018A1560	20 EUKNBSL-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid ivory white - 63x63	20 EUKNBSL-82-101	1	piece
2CKA002018A1561	20 EUKNBSL-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKNBSL-83	1	piece
2CKA002018A1562	20 EUKNBSL-83-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid aluminium silver - 63x63	20 EUKNBSL-83-101	1	piece
2CKA002018A1565	20 EUKNBSL-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKNBSL-884	1	piece
2CKA002018A1566	20 EUKNBSL-884-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid studio white matt - 63x63	20 EUKNBSL-884-101	1	piece
2CKA002018A1567	20 EUKNBSL-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKNBSL-885	1	piece
2CKA002018A1568	20 EUKNBSL-885-101 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) with Hinged Lid black matt - 63x63	20 EUKNBSL-885-101	1	piece
2CKA002011A3876	20 EUN-803 Socket insert Protective Contact (SCHUKO) 1gang(s) grey metallic - 63x63	20 EUN-803	1	piece
2CKA002011A3802	20 EUN-81 Socket insert Protective Contact (SCHUKO) 1gang(s) anthracite - 63x63	20 EUN-81	1	piece
2CKA002011A3726	20 EUN-82 Socket insert Protective Contact (SCHUKO) 1gang(s) ivory white - 63x63	20 EUN-82	1	piece
2CKA002011A3810	20 EUN-83 Socket insert Protective Contact (SCHUKO) 1gang(s) aluminium silver - 63x63	20 EUN-83	1	piece
2CKA002011A3851	20 EUN-866 Socket insert Protective Contact (SCHUKO) 1gang(s) stainless steel - Pure Stainless Steel	20 EUN-866	1	piece
2CKA002011A3881	20 EUN-884 Socket insert Protective Contact (SCHUKO) 1gang(s) studio white matt - 63x63	20 EUN-884	1	piece
2CKA002011A3884	20 EUN-885 Socket insert Protective Contact (SCHUKO) 1gang(s) black matt - 63x63	20 EUN-885	1	piece
2CKA002017A0785	20 MUC-82-500 Socket insert Earthing Pin 1gang(s) ivory white - 63x63	20 MUC-82-500	1	piece
2CKA002017A0852	20 MUCKS-803-500 Inserts with Cover Plate 1gang(s) grey metallic - 63x63	20 MUCKS-803-500	1	piece
2CKA002017A0898	20 MUCKS-81-500 Socket insert Safety Shutter 1gang(s) anthracite - 63x63	20 MUCKS-81-500	1	piece
2CKA002017A0806	20 MUCKS-82-500 Socket insert Earthing Pin Safety Shutter 1gang(s) ivory white - 63x63	20 MUCKS-82-500	1	piece
2CKA002017A0899	20 MUCKS-83-500 Socket insert Safety Shutter 1gang(s) aluminium silver - 63x63	20 MUCKS-83-500	1	piece
2CKA002017A0900	20 MUCKS-866-500 Socket insert Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	20 MUCKS-866-500	1	piece
2CKA002017A0901	20 MUCKS-884-500 Socket insert Safety Shutter 1gang(s) studio white matt - 63x63	20 MUCKS-884-500	1	piece
2CKA002017A0902	20 MUCKS-885-500 Socket insert Safety Shutter 1gang(s) black matt - 63x63	20 MUCKS-885-500	1	piece
2CKA001510A0005	2068/11-84 Cover Reflector Ambient / orientation lightning	2068/11-84	1	piece
2CKA001510A0008	2068/14-84 Cover Reflector Ambient / orientation lightning, Infolight	2068/14-84	1	piece
2CKA001510A0017	2068/22-84 Cover Ambient lightning - 63x63	2068/22-84	1	piece
2CKA001510A0015	2069/11-84 Busch-iceLight set LED studio white - future linear	2069/11-84	1	piece
2CKA002495A0084	2095 UC-81 Socket insert Equipotential compensation anthracite - 63x63	2095 UC-81	1	piece
2CKA002495A0085	2095 UC-82 Socket insert Equipotential compensation white - 63x63	2095 UC-82	1	piece
2CKA002495A0089	2095 UC-83 Socket insert Equipotential compensation aluminium - 63x63	2095 UC-83	1	piece

2CKA002495A0090	2095 UC-866 Socket insert Equipotential compensation stainless steel - Pure Stainless Steel	2095 UC-866	1	piece
2CKA002495A0091	2095 UC-884 Socket insert Equipotential compensation white - 63x63	2095 UC-884	1	piece
2CKA002495A0092	2095 UC-885 Socket insert Equipotential compensation black - 63x63	2095 UC-885	1	piece
2CKA002190A0224	2190 EUC-803 Inserts with Cover Plate 1gang(s) grey metallic	2190 EUC-803	1	piece
2CKA002190A0216	2190 EUC-81 Inserts with Cover Plate 1gang(s) anthracite	2190 EUC-81	1	piece
2CKA002190A0213	2190 EUC-82 Inserts with Cover Plate 1gang(s) ivory	2190 EUC-82	1	piece
2CKA002190A0214	2190 EUC-83 Inserts with Cover Plate 1gang(s) aluminium silver	2190 EUC-83	1	piece
2CKA002190A0222	2190 EUC-840-500 Inserts with Cover Plate 1gang(s) antique brass - 63x63	2190 EUC-840-500	1	piece
2CKA002190A0217	2190 EUC-866 Inserts with Cover Plate 1gang(s) stainless steel - Pure Stainless Steel	2190 EUC-866	1	piece
2CKA002190A0218	2190 EUC-884 Inserts with Cover Plate 1gang(s) studio white matt	2190 EUC-884	1	piece
2CKA002013A5475	23 EUCB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	23 EUCB-82	1	piece
2CKA002013A5476	23 EUCB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	23 EUCB-83	1	piece
2CKA002013A5478	23 EUCB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	23 EUCB-866	1	piece
2CKA002013A5480	23 EUCB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	23 EUCB-885	1	piece
2CKA002011A6247	23 EUCKS-845-507 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass anthracite - 63x63	23 EUCKS-845-507	1	piece
2CKA002011A6245	23 EUCKS-848-507 Inserts with Cover Plate Protective Contact (SCHUKO) 1gang(s) antique brass ivory white - 63x63	23 EUCKS-848-507	1	piece
2CKA002017A0891	23 MUCKS-845-500 Inserts with Cover Plate 1gang(s) antique brass anthracite - 63x63	23 MUCKS-845-500	1	piece
2CKA002017A0889	23 MUCKS-848-500 Inserts with Cover Plate 1gang(s) antique brass ivory white - 63x63	23 MUCKS-848-500	1	piece
2CKA002013A5447	2300 EUCB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	2300 EUCB-803	1	piece
2CKA002013A5448	2300 EUCB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	2300 EUCB-81	1	piece
2CKA002013A5449	2300 EUCB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - 63x63	2300 EUCB-82	1	piece
2CKA002013A5450	2300 EUCB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	2300 EUCB-83	1	piece
2CKA002013A5452	2300 EUCB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	2300 EUCB-866	1	piece
2CKA002013A5453	2300 EUCB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	2300 EUCB-884	1	piece
2CKA002013A5454	2300 EUCB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	2300 EUCB-885	1	piece
2CKA002113A5339	2300 UCRKS-81-503 Inserts with Cover Plate 1gang(s) anthracite - 63x63	2300 UCRKS-81-503	1	piece

2CKA002113A0510	2300 UCRKS-82-503 Inserts with Cover Plate 1gang(s) ivory white - 63x63	2300 UCRKS-82-503	1	piece
2CKA002113A5337	2300 UCRKS-884-503 Inserts with Cover Plate 1gang(s) studio white matt - 63x63	2300 UCRKS-884-503	1	piece
2CKA002113A5340	2300 UCRKS-885-503 Inserts with Cover Plate 1gang(s) black matt - 63x63	2300 UCRKS-885-503	1	piece
2CKA002011A6257	2310 EUGL/VA-12-82-101 Socket insert Busch- Protector® Protective Contact (SCHUKO) 1gang (s) red - 63x63	2310 EUGL/VA-12-82-101	1	piece
2CKA002011A3830	2310 EUGL/VA-81-11 Socket insert Busch- Protector® Protective Contact (SCHUKO) 1gang (s) anthracite - 63x63	2310 EUGL/VA-81-11	1	piece
2CKA002011A3831	2310 EUGL/VA-82-11 Socket insert Busch- Protector® Protective Contact (SCHUKO) 1gang (s) ivory white - 63x63	2310 EUGL/VA-82-11	1	piece
2CKA002011A3832	2310 EUGL/VA-83-11 Socket insert Busch- Protector® Protective Contact (SCHUKO) 1gang (s) aluminium silver - 63x63	2310 EUGL/VA-83-11	1	piece
2CKA002011A3877	2310 EUGL/VA-803-11 Socket insert Busch- Protector® Protective Contact (SCHUKO) 1gang (s) grey metallic - 63x63	2310 EUGL/VA-803-11	1	piece
2CKA002011A3853	2310 EUGL/VA-866-11 Socket insert Busch- Protector® Protective Contact (SCHUKO) 1gang (s) stainless steel - Pure Stainless Steel	2310 EUGL/VA-866-11	1	piece
2CKA002011A3882	2310 EUGL/VA-884-11 Socket insert Busch- Protector® Protective Contact (SCHUKO) 1gang (s) studio white matt - 63x63	2310 EUGL/VA-884-11	1	piece
2CKA002011A3885	2310 EUGL/VA-885-11 Socket insert Busch- Protector® Protective Contact (SCHUKO) 1gang (s) black matt - 63x63	2310 EUGL/VA-885-11	1	piece
2CKA002099A0253	2399 UCKS-803 Inserts with Cover Plate 1gang (s) grey metallic - 63x63	2399 UCKS-803	1	piece
2CKA002099A0216	2399 UCKS-81 Inserts with Cover Plate 1gang(s) anthracite - 63x63	2399 UCKS-81	1	piece
2CKA002099A0211	2399 UCKS-82 Inserts with Cover Plate 1gang(s) ivory - 63x63	2399 UCKS-82	1	piece
2CKA002099A0191	2399 UCKS-82-505 Inserts with Cover Plate 1gang(s) ivory white - 63x63	2399 UCKS-82-505	1	piece
2CKA002099A0241	2399 UCKS-83 Inserts with Cover Plate 1gang(s) aluminium silver - 63x63	2399 UCKS-83	1	piece
2CKA002099A0193	2399 UCKS-85-505 Inserts with Cover Plate 1gang(s) manhattan/graphite	2399 UCKS-85-505	1	piece
2CKA002099A0243	2399 UCKS-866 Socket 1 gang(s) stainless steel - Pure Stainless Steel	2399 UCKS-866	1	piece
2CKA002099A0255	2399 UCKS-884 Inserts with Cover Plate 1gang (s) studio white matt - 63x63	2399 UCKS-884	1	piece
2CKA001751A3175	2520 KI-803 Rocker Switch/push button Single rocker Symbol "bell" grey metallic - 63x63	2520 KI-803	1	piece
2CKA001751A3176	2520 KI-81 Rocker Switch/push button Single rocker Symbol "bell" anthracite - 63x63	2520 KI-81	1	piece
2CKA001751A3177	2520 KI-82 Rocker Switch/push button Single rocker Symbol "bell" ivory white - 63x63	2520 KI-82	1	piece
2CKA001751A3178	2520 KI-83 Rocker Switch/push button Single rocker Symbol "bell" aluminium silver - 63x63	2520 KI-83	1	piece
2CKA001751A3181	2520 KI-866 Rocker Switch/push button Single rocker Symbol "bell" stainless steel - Pure Stainless Steel	2520 KI-866	1	piece
2CKA001751A3182	2520 KI-884 Rocker Switch/push button Single rocker Symbol "bell" studio white matt - 63x63	2520 KI-884	1	piece
2CKA001751A3183	2520 KI-885 Rocker Switch/push button Single rocker Symbol "bell" black matt - 63x63	2520 KI-885	1	piece
2CKA001751A3185	2520 LI-803 Rocker Switch/push button Single rocker grey metallic - 63x63	2520 LI-803	1	piece
2CKA001751A3186	2520 LI-81 Rocker Switch/push button Single rocker anthracite - 63x63	2520 LI-81	1	piece

2CKA001751A3187	2520 LI-82 Rocker Switch/push button Single rocker ivory white - 63x63	2520 LI-82	1	piece
2CKA001751A3188	2520 LI-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	2520 LI-83	1	piece
2CKA001751A3191	2520 LI-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	2520 LI-866	1	piece
2CKA001751A3192	2520 LI-884 Rocker Switch/push button Single rocker studio white matt - 63x63	2520 LI-884	1	piece
2CKA001751A3193	2520 LI-885 Rocker Switch/push button Single rocker black matt - 63x63	2520 LI-885	1	piece
2CKA001751A3195	2520 TR-803 Rocker Switch/push button Single rocker grey metallic - 63x63	2520 TR-803	1	piece
2CKA001751A3196	2520 TR-81 Rocker Switch/push button Single rocker anthracite - 63x63	2520 TR-81	1	piece
2CKA001751A3197	2520 TR-82 Rocker Switch/push button Single rocker ivory white - 63x63	2520 TR-82	1	piece
2CKA001751A3198	2520 TR-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	2520 TR-83	1	piece
2CKA001751A3200	2520 TR-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	2520 TR-866	1	piece
2CKA001751A3201	2520 TR-884 Rocker Switch/push button Single rocker studio white matt - 63x63	2520 TR-884	1	piece
2CKA001751A3202	2520 TR-885 Rocker Switch/push button Single rocker black matt - 63x63	2520 TR-885	1	piece
2CKA001724A4407	2533-803 Cover Plate Bore hole grey metallic - 63x63	2533-803	1	piece
2CKA001724A4254	2533-81 Cover Plate Bore hole 1 gang(s) anthracite - 63x63	2533-81	1	piece
2CKA001724A4255	2533-82 Cover Plate Bore hole 1 gang(s) ivory white - 63x63	2533-82	1	piece
2CKA001724A4382	2533-82-15 Cover Plate Bore hole 1 gang(s) 1 gang(s) yellow - 63x63	2533-82-15	1	piece
2CKA001724A4261	2533-83 Cover Plate Bore hole 1 gang(s) aluminium silver - 63x63	2533-83	1	piece
2CKA001724A4270	2533-866 Cover Plate Bore hole 1 gang(s) stainless steel - Pure Stainless Steel	2533-866	1	piece
2CKA001724A4296	2533-884 Cover Plate Bore hole 1 gang(s) studio white matt - 63x63	2533-884	1	piece
2CKA001724A4301	2533-885 Cover Plate Bore hole 1 gang(s) black matt - 63x63	2533-885	1	piece
2CKA001710A4125	2542 DR/01-803 Cover Plate Level switch Turn button Symbol "0-1-2-3" grey metallic - 63x63	2542 DR/01-803	1	piece
2CKA001710A3644	2542 DR/01-81 Cover Plate Level switch Turn button Symbol "0-1-2-3" anthracite - 63x63	2542 DR/01-81	1	piece
2CKA001710A3645	2542 DR/01-82 Cover Plate Level switch Turn button Symbol "0-1-2-3" ivory white - 63x63	2542 DR/01-82	1	piece
2CKA001710A3671	2542 DR/01-83 Cover Plate Level switch Turn button Symbol "0-1-2-3" aluminium silver - 63x63	2542 DR/01-83	1	piece
2CKA001710A3758	2542 DR/01-866 Cover Plate Level switch Turn button Symbol "0-1-2-3" stainless steel - Pure Stainless Steel	2542 DR/01-866	1	piece
2CKA001710A3890	2542 DR/01-884 Cover Plate Level switch Turn button Symbol "0-1-2-3" studio white matt - 63x63	2542 DR/01-884	1	piece
2CKA001710A3913	2542 DR/01-885 Cover Plate Level switch Turn button Symbol "0-1-2-3" black matt - 63x63	2542 DR/01-885	1	piece
2CKA001710A4126	2542 DR/02-803 Cover Plate Level switch Turn button Symbol "1-2-3" grey metallic - 63x63	2542 DR/02-803	1	piece
2CKA001710A3649	2542 DR/02-81 Cover Plate Level switch Turn button Symbol "1-2-3" anthracite - 63x63	2542 DR/02-81	1	piece
2CKA001710A3650	2542 DR/02-82 Cover Plate Level switch Turn button Symbol "1-2-3" ivory white - 63x63	2542 DR/02-82	1	piece
2CKA001710A3672	2542 DR/02-83 Cover Plate Level switch Turn button Symbol "1-2-3" aluminium silver - 63x63	2542 DR/02-83	1	piece

2CKA001710A3759	2542 DR/02-866 Cover Plate Level switch Turn button Symbol "1-2-3" stainless steel - Pure Stainless Steel	2542 DR/02-866	1	piece
2CKA001710A3891	2542 DR/02-884 Cover Plate Level switch Turn button Symbol "1-2-3" studio white matt - 63x63	2542 DR/02-884	1	piece
2CKA001710A3914	2542 DR/02-885 Cover Plate Level switch Turn button Symbol "1-2-3" black matt - 63x63	2542 DR/02-885	1	piece
2CKA001724A4398	2553-803 Cover Plate XLR grey metallic - 63x63	2553-803	1	piece
2CKA001724A4399	2553-81 Cover Plate XLR 1 gang(s) 1 gang(s) anthracite - 63x63	2553-81	1	piece
2CKA001724A4400	2553-82 Cover Plate XLR 1 gang(s) 1 gang(s) ivory white - 63x63	2553-82	1	piece
2CKA001724A4401	2553-83 Cover Plate XLR 1 gang(s) 1 gang(s) aluminium silver - 63x63	2553-83	1	piece
2CKA001724A4403	2553-866 Cover Plate XLR 1 gang(s) 1 gang(s) stainless steel - Pure Stainless Steel	2553-866	1	piece
2CKA001724A4404	2553-884 Cover Plate XLR 1 gang(s) 1 gang(s) studio white matt - 63x63	2553-884	1	piece
2CKA001724A4405	2553-885 Cover Plate XLR 1 gang(s) 1 gang(s) black matt - 63x63	2553-885	1	piece
2CKA001753A0316	2561-02-803 Cover Plate Modular Jack 1 gang(s) 2 gang(s) grey metallic - 63x63	2561-02-803	1	piece
2CKA001753A0317	2561-02-81 Cover Plate Modular Jack 1 gang(s) 2 gang(s) anthracite - 63x63	2561-02-81	1	piece
2CKA001753A0392	2561-02-82 Cover Plate Modular Jack ivory white - 63x63	2561-02-82	1	piece
2CKA001753A0393	2561-02-83 Cover Plate Modular Jack 1 gang(s) 2 gang(s) aluminium silver - 63x63	2561-02-83	1	piece
2CKA001753A0396	2561-02-884 Cover Plate Modular Jack 1 gang(s) 2 gang(s) studio white matt - 63x63	2561-02-884	1	piece
2CKA001753A0397	2561-02-885 Cover Plate Modular Jack 1 gang(s) 2 gang(s) black matt - 63x63	2561-02-885	1	piece
2CKA001753A0399	2561-803 Cover Plate Modular Jack 1 gang(s) 1 gang(s) grey metallic - 63x63	2561-803	1	piece
2CKA001753A0400	2561-81 Cover Plate Modular Jack 1 gang(s) 1 gang(s) anthracite - 63x63	2561-81	1	piece
2CKA001753A0401	2561-82 Cover Plate Modular Jack 1 gang(s) 1 gang(s) ivory white - 63x63	2561-82	1	piece
2CKA001753A0402	2561-83 Cover Plate Modular Jack 1 gang(s) 1 gang(s) aluminium silver - 63x63	2561-83	1	piece
2CKA001753A0404	2561-866 Cover Plate Modular Jack 1 gang(s) 1 gang(s) stainless steel - Pure Stainless Steel	2561-866	1	piece
2CKA001753A0405	2561-884 Cover Plate Modular Jack 1 gang(s) 1 gang(s) studio white matt - 63x63	2561-884	1	piece
2CKA001753A0406	2561-885 Cover Plate Modular Jack 1 gang(s) 1 gang(s) black matt - 63x63	2561-885	1	piece
2CKA003116A0666	3120 EUCB-803 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) grey metallic - 63x63	3120 EUCB-803	1	piece
2CKA003116A0667	3120 EUCB-81 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) anthracite - 63x63	3120 EUCB-81	1	piece
2CKA003116A0661	3120 EUCB-82 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) ivory white - solo	3120 EUCB-82	1	piece
2CKA003116A0668	3120 EUCB-83 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) aluminium silver - 63x63	3120 EUCB-83	1	piece
2CKA003116A0669	3120 EUCB-866 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) stainless steel - Pure Stainless Steel	3120 EUCB-866	1	piece
2CKA003116A0670	3120 EUCB-884 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) studio white matt - 63x63	3120 EUCB-884	1	piece

2CKA003116A0671	3120 EUCB-885 Socket insert FI-Schukomat Protective Contact (SCHUKO) Safety Shutter 1gang(s) black matt - 63x63	3120 EUCB-885	1	piece
2CKA003117A0008	3151 UC-803 RCD - Insert Buschmat 30 mA grey metallic - 63x63	3151 UC-803	1	piece
2CKA003117A0009	3151 UC-81 RCD - Insert Buschmat 30 mA anthracite - 63x63	3151 UC-81	1	piece
2CKA003117A0005	3151 UC-82 RCD - Insert Buschmat 30 mA ivory white - 63x63	3151 UC-82	1	piece
2CKA003117A0010	3151 UC-83 RCD - Insert Buschmat 30 mA aluminium silver - 63x63	3151 UC-83	1	piece
2CKA003117A0011	3151 UC-866 RCD - Insert Buschmat 30 mA stainless steel - Pure Stainless Steel	3151 UC-866	1	piece
2CKA003117A0012	3151 UC-884 RCD - Insert Buschmat 30 mA studio white matt - 63x63	3151 UC-884	1	piece
2CKA003117A0013	3151 UC-885 RCD - Insert Buschmat 30 mA black matt - 63x63	3151 UC-885	1	piece
2CKA006115A0489	6108/61-803-500 Coverplate f. CE	6108/61-803-500	1	piece
2CKA006115A0483	6108/61-81-500 Coverplate f. CE	6108/61-81-500	1	piece
2CKA006115A0484	6108/61-82-500 Coverplate f. CE	6108/61-82-500	1	piece
2CKA006115A0485	6108/61-83-500 Coverplate f. CE	6108/61-83-500	1	piece
2CKA006155A0121	6108/61-840-500 Coverplate f. CE	6108/61-840-500	1	piece
2CKA006115A0492	6108/61-866-500 Coverplate f. CE	6108/61-866-500	1	piece
2CKA006115A0487	6108/61-884-500 Coverplate f. CE	6108/61-884-500	1	piece
2CKA006115A0488	6108/61-885-500 Coverplate f. CE	6108/61-885-500	1	piece
2CKA006155A0066	6109/03-803-500 Coverplate f. RTC	6109/03-803-500	1	piece
2CKA006155A0060	6109/03-81-500 Coverplate f. RTC	6109/03-81-500	1	piece
2CKA006155A0061	6109/03-82-500 Coverplate f. RTC	6109/03-82-500	1	piece
2CKA006155A0062	6109/03-83-500 Coverplate f. RTC	6109/03-83-500	1	piece
2CKA006155A0114	6109/03-840-500 Coverplate f. RTC	6109/03-840-500	1	piece
2CKA006155A0069	6109/03-866-500 Coverplate f. RTC	6109/03-866-500	1	piece
2CKA006155A0064	6109/03-884-500 Coverplate f. RTC	6109/03-884-500	1	piece
2CKA006155A0065	6109/03-885-500 Coverplate f. RTC	6109/03-885-500	1	piece
2CKA006132A0382	6122/10-803-500 BW standard	6122/10-803-500	1	piece
2CKA006132A0376	6122/10-81-500 BW standard	6122/10-81-500	1	piece
2CKA006132A0377	6122/10-82-500 BW standard	6122/10-82-500	1	piece
2CKA006132A0378	6122/10-83-500 BW standard	6122/10-83-500	1	piece
2CKA006132A0407	6122/10-840-500 BW standard	6122/10-840-500	1	piece
2CKA006132A0385	6122/10-866-500 BW standard	6122/10-866-500	1	piece
2CKA006132A0380	6122/10-884-500 BW standard	6122/10-884-500	1	piece

2CKA006132A0381	6122/10-885-500 BW standard	6122/10-885-500	1	piece
2CKA006115A0212	6125/01-803-500 Control element 1g w. BAU	6125/01-803-500	1	piece
2CKA006115A0205	6125/01-81-500 Control element 1g w. BAU	6125/01-81-500	1	piece
2CKA006115A0206	6125/01-82-500 Control element 1g w. BAU	6125/01-82-500	1	piece
2CKA006115A0207	6125/01-83-500 Control element 1g w. BAU	6125/01-83-500	1	piece
2CKA006115A0211	6125/01-866-500 Control element 1g w. BAU	6125/01-866-500	1	piece
2CKA006115A0214	6125/01-884-500 Control element 1g w. BAU	6125/01-884-500	1	piece
2CKA006115A0215	6125/01-885-500 Control element 1g w. BAU	6125/01-885-500	1	piece
2CKA006115A0224	6125/02-803-500 Control element 1/2gang	6125/02-803-500	1	piece
2CKA006115A0216	6125/02-81-500 Control element 1/2gang	6125/02-81-500	1	piece
2CKA006115A0217	6125/02-82-500 Control element 1/2gang	6125/02-82-500	1	piece
2CKA006115A0218	6125/02-83-500 Control element 1/2gang	6125/02-83-500	1	piece
2CKA006115A0452	6125/02-840-500 cont.-element KNX 1g	6125/02-840-500	1	piece
2CKA006115A0223	6125/02-866-500 Control element 1/2gang	6125/02-866-500	1	piece
2CKA006115A0226	6125/02-884-500 Control element 1/2gang	6125/02-884-500	1	piece
2CKA006115A0227	6125/02-885-500 Control element 1/2gang	6125/02-885-500	1	piece
2CKA006116A0202	6126/01-803-500 Control element 2g w. BAU	6126/01-803-500	1	piece
2CKA006116A0195	6126/01-81-500 Control element 2g w. BAU	6126/01-81-500	1	piece
2CKA006116A0196	6126/01-82-500 Control element 2g w. BAU	6126/01-82-500	1	piece
2CKA006116A0197	6126/01-83-500 Control element 2g w. BAU	6126/01-83-500	1	piece
2CKA006116A0201	6126/01-866-500 Control element 2g w. BAU	6126/01-866-500	1	piece
2CKA006116A0204	6126/01-884-500 Control element 2g w. BAU	6126/01-884-500	1	piece
2CKA006116A0205	6126/01-885-500 Control element 2g w. BAU	6126/01-885-500	1	piece
2CKA006116A0214	6126/02-803-500 Control element 2/4gang	6126/02-803-500	1	piece
2CKA006116A0206	6126/02-81-500 Control element 2/4gang	6126/02-81-500	1	piece
2CKA006116A0207	6126/02-82-500 Control element 2/4gang	6126/02-82-500	1	piece
2CKA006116A0208	6126/02-83-500 Control element 2/4gang	6126/02-83-500	1	piece
2CKA006116A0227	6126/02-840-500 cont.-element KNX 2g	6126/02-840-500	1	piece
2CKA006116A0213	6126/02-866-500 Control element 2/4gang	6126/02-866-500	1	piece
2CKA006116A0216	6126/02-884-500 Control element 2/4gang	6126/02-884-500	1	piece
2CKA006116A0217	6126/02-885-500 Control element 2/4gang	6126/02-885-500	1	piece

2CKA006117A0228	6127/01-803-500 Control element 4g w. BAU	6127/01-803-500	1	piece
2CKA006117A0221	6127/01-81-500 Control element 4g w. BAU	6127/01-81-500	1	piece
2CKA006117A0222	6127/01-82-500 Control element 4g w. BAU	6127/01-82-500	1	piece
2CKA006117A0223	6127/01-83-500 Control element 4g w. BAU	6127/01-83-500	1	piece
2CKA006117A0227	6127/01-866-500 Control element 4g w. BAU	6127/01-866-500	1	piece
2CKA006117A0230	6127/01-884-500 Control element 4g w. BAU	6127/01-884-500	1	piece
2CKA006117A0231	6127/01-885-500 Control element 4g w. BAU	6127/01-885-500	1	piece
2CKA006117A0240	6127/02-803-500 Control element 4/8gang	6127/02-803-500	1	piece
2CKA006117A0232	6127/02-81-500 Control element 4/8gang	6127/02-81-500	1	piece
2CKA006117A0233	6127/02-82-500 Control element 4/8gang	6127/02-82-500	1	piece
2CKA006117A0234	6127/02-83-500 Control element 4/8gang	6127/02-83-500	1	piece
2CKA006117A0252	6127/02-840-500 cont.-element KNX 4g	6127/02-840-500	1	piece
2CKA006117A0239	6127/02-866-500 Control element 4/8gang	6127/02-866-500	1	piece
2CKA006117A0242	6127/02-884-500 Control element 4/8gang	6127/02-884-500	1	piece
2CKA006117A0243	6127/02-885-500 Control element 4/8gang	6127/02-885-500	1	piece
2CKA006134A0336	6128/28-803-500 RTC Control element 2/4g	6128/28-803-500	1	piece
2CKA006134A0331	6128/28-81-500 RTC Control element 2/4g	6128/28-81-500	1	piece
2CKA006134A0332	6128/28-82-500 RTC Control element 2/4g	6128/28-82-500	1	piece
2CKA006134A0333	6128/28-83-500 RTC Control element 2/4g	6128/28-83-500	1	piece
2CKA006134A0342	6128/28-840-500 RTC Control element 2/4g	6128/28-840-500	1	piece
2CKA006134A0335	6128/28-866-500 RTC Control element 2/4g	6128/28-866-500	1	piece
2CKA006134A0338	6128/28-884-500 RTC Control element 2/4g	6128/28-884-500	1	piece
2CKA006134A0339	6128/28-885-500 RTC Control element 2/4g	6128/28-885-500	1	piece
2CKA006135A0163	6129/01-803-500 Control element 3/6g w. IR	6129/01-803-500	1	piece
2CKA006135A0156	6129/01-81-500 Control element 3/6g w. IR	6129/01-81-500	1	piece
2CKA006135A0157	6129/01-82-500 Control element 3/6g w. IR	6129/01-82-500	1	piece
2CKA006135A0158	6129/01-83-500 Control element 3/6g w. IR	6129/01-83-500	1	piece
2CKA006135A0162	6129/01-866-500 Control element 3/6g w. IR	6129/01-866-500	1	piece
2CKA006135A0165	6129/01-884-500 Control element 3/6g w. IR	6129/01-884-500	1	piece
2CKA006135A0166	6129/01-885-500 Control element 3/6g w. IR	6129/01-885-500	1	piece
2CKA006430A0350	6430-803-102 Control Element Venetian blind Symbol "arrows" grey metallic - 63x63	6430-803-102	1	piece

2CKA006430A0326	6430-81-102 Control Element Venetian blind Symbol "arrows" anthracite - 63x63	6430-81-102	1	piece
2CKA006430A0327	6430-82-102 Control Element Venetian blind Symbol "arrows" ivory white - 63x63	6430-82-102	1	piece
2CKA006430A0328	6430-83-102 Control Element Venetian blind Symbol "arrows" aluminium silver - 63x63	6430-83-102	1	piece
2CKA006430A0407	6430-840-102-500 cont.-element blinds	6430-840-102-500	1	piece
2CKA006430A0343	6430-866-102 Control Element Venetian blind Symbol "arrows" stainless steel - Pure Stainless Steel	6430-866-102	1	piece
2CKA006430A0385	6430-884-102 Control Element Venetian blind Symbol "arrows" studio white matt - 63x63	6430-884-102	1	piece
2CKA006430A0386	6430-885-102 Control Element Venetian blind Symbol "arrows" black matt - 63x63	6430-885-102	1	piece
2CKA006430A0351	6435-803 Cover Plate Time switch grey metallic - 63x63	6435-803	1	piece
2CKA006430A0303	6435-81 Cover Plate Time switch anthracite - 63x63	6435-81	1	piece
2CKA006430A0304	6435-82 Cover Plate Time switch ivory white - 63x63	6435-82	1	piece
2CKA006430A0305	6435-83 Cover Plate Time switch aluminium silver - 63x63	6435-83	1	piece
2CKA006430A0405	6435-840-500 Cover Plates Time switch antique brass - 63x63	6435-840-500	1	piece
2CKA006430A0344	6435-866 Cover Plate Time switch stainless steel - Pure Stainless Steel	6435-866	1	piece
2CKA006430A0388	6435-884 Cover Plate Time switch studio white matt - 63x63	6435-884	1	piece
2CKA006430A0389	6435-885 Cover Plate Time switch black matt - 63x63	6435-885	1	piece
2CKA006470A0006	6476-803 Cover Plate Proximity switch grey metallic - 63x63	6476-803	1	piece
2CKA006470A0007	6476-81 Cover Plate Proximity switch anthracite - 63x63	6476-81	1	piece
2CKA006470A0003	6476-82 Cover Plate Proximity switch ivory white - 63x63	6476-82	1	piece
2CKA006470A0008	6476-83 Cover Plate Proximity switch aluminium silver - 63x63	6476-83	1	piece
2CKA006470A0009	6476-866 Cover Plate Proximity switch stainless steel - Pure Stainless Steel	6476-866	1	piece
2CKA006470A0010	6476-884 Cover Plate Proximity switch studio white matt - 63x63	6476-884	1	piece
2CKA006470A0011	6476-885 Cover Plate Proximity switch black matt - 63x63	6476-885	1	piece
2CKA006400A0060	6477-803 Cover Plate PowerDock 1 gang(s) grey	6477-803	1	piece
2CKA006400A0056	6477-81 Cover Plate PowerDock 1 gang(s) anthracite	6477-81	1	piece
2CKA006400A0057	6477-82 Cover Plate PowerDock 1 gang(s) white	6477-82	1	piece
2CKA006400A0058	6477-83 Cover Plate PowerDock 1 gang(s) aluminium	6477-83	1	piece
2CKA006400A0061	6477-840-500 Switch Assortments USB antique brass - 63x63	6477-840-500	1	piece
2CKA006400A0064	6477-866 Cover Plate PowerDock 1 gang(s) stainless steel - Pure Stainless Steel	6477-866	1	piece
2CKA006400A0062	6477-884 Cover Plate PowerDock 1 gang(s) white	6477-884	1	piece
2CKA006400A0063	6477-885 Cover Plate PowerDock 1 gang(s) black	6477-885	1	piece
2CKA006599A2980	6540-803-102 Cover Plate Dimmer Turn button grey metallic - 63x63	6540-803-102	1	piece
2CKA006599A2950	6540-81-102 Cover Plate Dimmer Turn button anthracite - 63x63	6540-81-102	1	piece

2CKA006599A2951	6540-82-102 Cover Plate Dimmer Turn button ivory white - 63x63	6540-82-102	1	piece
2CKA006599A2952	6540-83-102 Cover Plate Dimmer Turn button aluminium silver - 63x63	6540-83-102	1	piece
2CKA006599A3022	6540-840-102-500 Cover Plates Dimmer Turn button antique brass - 63x63	6540-840-102- 500	1	piece
2CKA006599A2959	6540-866-102 Cover Plate Dimmer Turn button stainless steel - Pure Stainless Steel	6540-866-102	1	piece
2CKA006599A2961	6540-884-102 Cover Plate Dimmer Turn button studio white matt - 63x63	6540-884-102	1	piece
2CKA006599A2966	6540-885-102 Cover Plate Dimmer Turn button black matt - 63x63	6540-885-102	1	piece
2CKA006599A2882	6541-81 Cover Plate Cooling Central cover plate anthracite - 63x63	6541-81	1	piece
2CKA006599A2832	6541-82 Cover Plate Cooling Central cover plate ivory white - 63x63	6541-82	1	piece
2CKA006599A2885	6541-83 Cover Plate Cooling Central cover plate aluminium silver - 63x63	6541-83	1	piece
2CKA006599A2924	6541-866 Cover Plate Cooling Central cover plate stainless steel - Pure Stainless Steel	6541-866	1	piece
2CKA006599A2962	6541-884 Cover Plate Cooling Central cover plate studio white matt - 63x63	6541-884	1	piece
2CKA006599A2967	6541-885 Cover Plate Cooling black matt - 63x63	6541-885	1	piece
2CKA006599A2881	6543-81-101 Control Element Switch/dimmer Single push button anthracite - 63x63	6543-81-101	1	piece
2CKA006599A2831	6543-82-101 Control Element Switch/dimmer Single push button ivory white - 63x63	6543-82-101	1	piece
2CKA006599A2887	6543-83-101 Control Element Switch/dimmer Single push button aluminium silver - 63x63	6543-83-101	1	piece
2CKA006599A3023	6543-840-101-500 Cover Plates Switch/dimmer Single push button Without imprint antique brass - 63x63	6543-840-101- 500	1	piece
2CKA006599A2926	6543-866-101 Control Element Switch/dimmer Single push button stainless steel - Pure Stainless Steel	6543-866-101	1	piece
2CKA006599A2963	6543-884-101 Control Element Switch/dimmer Single push button studio white matt - 63x63	6543-884-101	1	piece
2CKA006599A2968	6543-885-101 Control Element Switch/dimmer Single push button black matt - 63x63	6543-885-101	1	piece
2CKA006599A2943	6545-803 Control Element Dimmer Two-part button with Neon lamp grey metallic - 63x63	6545-803	1	piece
2CKA006599A2906	6545-81 Control Element Dimmer Two-part button with Neon lamp anthracite - 63x63	6545-81	1	piece
2CKA006599A2907	6545-82 Control Element Dimmer Two-part button with Neon lamp ivory white - 63x63	6545-82	1	piece
2CKA006599A2914	6545-83 Control Element Dimmer Two-part button with Neon lamp aluminium silver - 63x63	6545-83	1	piece
2CKA006599A3024	6545-840-500 Cover Plates Dimmer Two-part button Without imprint antique brass - 63x63	6545-840-500	1	piece
2CKA006599A2927	6545-866 Control Element Dimmer Two-part button with Neon lamp stainless steel - Pure Stainless Steel	6545-866	1	piece
2CKA006599A2964	6545-884 Control Element Dimmer Two-part button with Neon lamp studio white matt - 63x63	6545-884	1	piece
2CKA006599A2969	6545-885 Control Element Dimmer Two-part button with Neon lamp black matt - 63x63	6545-885	1	piece
2CKA006730A0032	6731-82-500 Cover Plates ivory white - 63x63	6731-82-500	1	piece
2CKA006730A0035	6731-83-500 Cover Plates aluminium silver - 63x63	6731-83-500	1	piece
2CKA006730A0094	6731-840-500 cont.-element WaveL 1g	6731-840-500	1	piece
2CKA006730A0041	6731-866-500 Cover Plates WaveLine stainless steel - Pure Stainless Steel	6731-866-500	1	piece
2CKA006730A0033	6732-82-500 Cover Plates ivory white - 63x63	6732-82-500	1	piece

2CKA006730A0036	6732-83-500 Cover Plates aluminium silver - 63x63	6732-83-500	1	piece
2CKA006730A0095	6732-840-500 cont.-element WaveL 2g	6732-840-500	1	piece
2CKA006730A0042	6732-866-500 Wall sensor stainless steel - Pure Stainless Steel	6732-866-500	1	piece
2CKA006730A0034	6733-82-500 Cover Plates ivory white - 63x63	6733-82-500	1	piece
2CKA006730A0037	6733-83-500 Cover Plates aluminium silver - 63x63	6733-83-500	1	piece
2CKA006730A0043	6733-866-500 Cover Plates stainless steel - Pure Stainless Steel	6733-866-500	1	piece
2CKA006730A0141	6736 FoH-885 Control Element Switch/dimmer Two-part button black	6736 FoH-885	1	piece
2CKA006800A2828	6815-81-101-500 Cover Plates Movement sensor anthracite	6815-81-101-500	1	piece
2CKA006800A2830	6815-82-101-500 Cover Plates ivory white	6815-82-101-500	1	piece
2CKA006800A2832	6815-83-101-500 Cover Plates aluminium silver	6815-83-101-500	1	piece
2CKA006800A2843	6815-866-101-500 Cover Plates stainless steel - Pure Stainless Steel	6815-866-101-500	1	piece
2CKA006800A2840	6815-885-101-500 Cover Plates Movement sensor black matt	6815-885-101-500	1	piece
2CKA008200A0115	8253-803 Cover Plate Loudspeaker grey - 63x63	8253-803	1	piece
2CKA008200A0078	8253-81 Cover Plate Loudspeaker anthracite - 63x63	8253-81	1	piece
2CKA008200A0079	8253-82 Cover Plate Loudspeaker white - 63x63	8253-82	1	piece
2CKA008200A0080	8253-83 Cover Plate Loudspeaker aluminium - 63x63	8253-83	1	piece
2CKA008200A0191	8253-840-500 Cover Plates antique brass - 63x63	8253-840-500	1	piece
2CKA008200A0087	8253-866 Cover Plate Loudspeaker stainless steel - Pure Stainless Steel	8253-866	1	piece
2CKA008200A0123	8253-884 Cover Plate Loudspeaker white - 63x63	8253-884	1	piece
2CKA008200A0126	8253-885 Cover Plate Loudspeaker black - 63x63	8253-885	1	piece
2CKA006220A0566	CP-FCC-803 C-plate Fan Coil	CP-FCC-803	1	piece
2CKA006220A0242	CP-FCC-81 C-plate Fan Coil	CP-FCC-81	1	piece
2CKA006220A0532	CP-FCC-82 C-plate Fan Coil	CP-FCC-82	1	piece
2CKA006220A0243	CP-FCC-83 C-plate Fan Coil	CP-FCC-83	1	piece
2CKA006220A0549	CP-FCC-866 C-plate Fan Coil	CP-FCC-866	1	piece
2CKA006220A0617	CP-FCC-884 C-plate Fan Coil	CP-FCC-884	1	piece
2CKA006220A0634	CP-FCC-885 C-plate Fan Coil	CP-FCC-885	1	piece
2CKA006220A0563	CP-RTC-803 C-plate RT sensor unit	CP-RTC-803	1	piece
2CKA006220A0179	CP-RTC-81 C-plate RT sensor unit	CP-RTC-81	1	piece
2CKA006220A0529	CP-RTC-82 C-plate RT sensor unit	CP-RTC-82	1	piece
2CKA006220A0180	CP-RTC-83 C-plate RT sensor unit	CP-RTC-83	1	piece
2CKA006220A0384	CP-RTC-840 c-plate temp.	CP-RTC-840	1	piece
2CKA006220A0546	CP-RTC-866 C-plate RT sensor unit	CP-RTC-866	1	piece
2CKA006220A0614	CP-RTC-884 C-plate RT sensor unit	CP-RTC-884	1	piece
2CKA006220A0631	CP-RTC-885 C-plate RT sensor unit	CP-RTC-885	1	piece
2CKA006220A0564	MD-F-1.0.1-803 Movement detector	MD-F-1.0.1-803	1	piece
2CKA006220A0212	MD-F-1.0.1-81 Movement detector	MD-F-1.0.1-81	1	piece
2CKA006220A0530	MD-F-1.0.1-82 Movement detector	MD-F-1.0.1-82	1	piece
2CKA006220A0213	MD-F-1.0.1-83 Movement detector	MD-F-1.0.1-83	1	piece
2CKA006220A0385	MD-F-1.0.1-840 WD 180 sens	MD-F-1.0.1-840	1	piece
2CKA006220A0547	MD-F-1.0.1-866 Movement detector	MD-F-1.0.1-866	1	piece

2CKA006220A0615	MD-F-1.0.1-884 Movement detector	MD-F-1.0.1-884	1	piece
2CKA006220A0632	MD-F-1.0.1-885 Movement detector	MD-F-1.0.1-885	1	piece
2CKA006220A0565	MSA-F-1.1.1-803 Mov. detector/actuator 1g	MSA-F-1.1.1-803	1	piece
2CKA006220A0215	MSA-F-1.1.1-81 Mov. detector/actuator 1g	MSA-F-1.1.1-81	1	piece
2CKA006200A0083	MSA-F-1.1.1-81-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-81-WL	1	piece
2CKA006200A0084	MSA-F-1.1.1-82-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-82-WL	1	piece
2CKA006220A0216	MSA-F-1.1.1-83 Mov. detector/actuator 1g	MSA-F-1.1.1-83	1	piece
2CKA006200A0085	MSA-F-1.1.1-83-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-83-WL	1	piece
2CKA006220A0386	MSA-F-1.1.1-840 WD 180 sens actuator	MSA-F-1.1.1-840	1	piece
2CKA006220A0548	MSA-F-1.1.1-866 Mov. detector/actuator 1g	MSA-F-1.1.1-866	1	piece
2CKA006220A0616	MSA-F-1.1.1-884 Mov. detector/actuator 1g	MSA-F-1.1.1-884	1	piece
2CKA006200A0097	MSA-F-1.1.1-884-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-884-WL	1	piece
2CKA006220A0633	MSA-F-1.1.1-885 Mov. detector/actuator 1g	MSA-F-1.1.1-885	1	piece
2CKA006200A0098	MSA-F-1.1.1-885-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-885-WL	1	piece
2CKA006220A0550	SR-1-803 rocker 1gang	SR-1-803	1	piece
2CKA006220A0137	SR-1-81 rocker 1gang	SR-1-81	1	piece
2CKA006220A0516	SR-1-82 rocker 1gang	SR-1-82	1	piece
2CKA006220A0138	SR-1-83 rocker 1gang	SR-1-83	1	piece
2CKA006220A0371	SR-1-840 rocker 1g neural	SR-1-840	1	piece
2CKA006220A0533	SR-1-866 rocker 1gang	SR-1-866	1	piece
2CKA006220A0601	SR-1-884 rocker 1gang	SR-1-884	1	piece
2CKA006220A0618	SR-1-885 rocker 1gang	SR-1-885	1	piece
2CKA006220A0555	SR-2-803 rocker 2gang	SR-2-803	1	piece
2CKA006220A0152	SR-2-81 rocker 2gang	SR-2-81	1	piece
2CKA006220A0521	SR-2-82 rocker 2gang	SR-2-82	1	piece
2CKA006220A0153	SR-2-83 rocker 2gang	SR-2-83	1	piece
2CKA006220A0376	SR-2-840 rocker 2g neutral	SR-2-840	1	piece
2CKA006220A0538	SR-2-866 rocker 2gang	SR-2-866	1	piece
2CKA006220A0606	SR-2-884 rocker 2gang	SR-2-884	1	piece
2CKA006220A0623	SR-2-885 rocker 2gang	SR-2-885	1	piece
2CKA006220A0552	SRB-1-803 rocker 1gang, blinds	SRB-1-803	1	piece
2CKA006220A0143	SRB-1-81 rocker 1gang, blinds	SRB-1-81	1	piece
2CKA006220A0518	SRB-1-82 rocker 1gang, blinds	SRB-1-82	1	piece
2CKA006220A0144	SRB-1-83 rocker 1gang, blinds	SRB-1-83	1	piece
2CKA006220A0373	SRB-1-840 rocker 1g blinds	SRB-1-840	1	piece
2CKA006220A0535	SRB-1-866 rocker 1gang, blinds	SRB-1-866	1	piece
2CKA006220A0603	SRB-1-884 rocker 1gang, blinds	SRB-1-884	1	piece
2CKA006220A0620	SRB-1-885 rocker 1gang, blinds	SRB-1-885	1	piece
2CKA006220A0557	SRB-2-803 rocker 2g, blinds	SRB-2-803	1	piece
2CKA006220A0158	SRB-2-81 rocker 2g, blinds	SRB-2-81	1	piece
2CKA006220A0523	SRB-2-82 rocker 2g, blinds	SRB-2-82	1	piece
2CKA006220A0159	SRB-2-83 rocker 2g, blinds	SRB-2-83	1	piece

2CKA006220A0378	SRB-2-840 rocker 2g blinds	SRB-2-840	1	piece
2CKA006220A0540	SRB-2-866 rocker 2g, blinds	SRB-2-866	1	piece
2CKA006220A0608	SRB-2-884 rocker 2g, blinds	SRB-2-884	1	piece
2CKA006220A0625	SRB-2-885 rocker 2g, blinds	SRB-2-885	1	piece
2CKA006220A0554	SRD-1-803 rocker 1gang, dimming	SRD-1-803	1	piece
2CKA006220A0149	SRD-1-81 rocker 1gang, dimming	SRD-1-81	1	piece
2CKA006220A0520	SRD-1-82 rocker 1gang, dimming	SRD-1-82	1	piece
2CKA006220A0150	SRD-1-83 rocker 1gang, dimming	SRD-1-83	1	piece
2CKA006220A0375	SRD-1-840 rocker 1g dimming	SRD-1-840	1	piece
2CKA006220A0537	SRD-1-866 rocker 1gang, dimming	SRD-1-866	1	piece
2CKA006220A0605	SRD-1-884 rocker 1gang, dimming	SRD-1-884	1	piece
2CKA006220A0622	SRD-1-885 rocker 1gang, dimming	SRD-1-885	1	piece
2CKA006220A0559	SRD-2-L-803 rocker 2g, left, dimming	SRD-2-L-803	1	piece
2CKA006220A0164	SRD-2-L-81 rocker 2g, left, dimming	SRD-2-L-81	1	piece
2CKA006220A0525	SRD-2-L-82 rocker 2g, left, dimming	SRD-2-L-82	1	piece
2CKA006220A0165	SRD-2-L-83 rocker 2g, left, dimming	SRD-2-L-83	1	piece
2CKA006220A0380	SRD-2-L-840 rocker 2g left dimming	SRD-2-L-840	1	piece
2CKA006220A0542	SRD-2-L-866 rocker 2g, left, dimming	SRD-2-L-866	1	piece
2CKA006220A0610	SRD-2-L-884 rocker 2g, left, dimming	SRD-2-L-884	1	piece
2CKA006220A0627	SRD-2-L-885 rocker 2g, left, dimming	SRD-2-L-885	1	piece
2CKA006220A0560	SRD-2-R-803 rocker 2g, right, dimming	SRD-2-R-803	1	piece
2CKA006220A0258	SRD-2-R-81 rocker 2g, right, dimming	SRD-2-R-81	1	piece
2CKA006220A0526	SRD-2-R-82 rocker 2g, right, dimming	SRD-2-R-82	1	piece
2CKA006220A0259	SRD-2-R-83 rocker 2g, right, dimming	SRD-2-R-83	1	piece
2CKA006220A0383	SRD-2-R-840 rocker 2g right dimming	SRD-2-R-840	1	piece
2CKA006220A0543	SRD-2-R-866 rocker 2g, right, dimming	SRD-2-R-866	1	piece
2CKA006220A0611	SRD-2-R-884 rocker 2g, right, dimming	SRD-2-R-884	1	piece
2CKA006220A0628	SRD-2-R-885 rocker 2g, right, dimming	SRD-2-R-885	1	piece
2CKA006220A0551	SRL-1-803 rocker 1gang, lighting	SRL-1-803	1	piece
2CKA006220A0140	SRL-1-81 rocker 1gang, lighting	SRL-1-81	1	piece
2CKA006220A0517	SRL-1-82 rocker 1gang, lighting	SRL-1-82	1	piece
2CKA006220A0141	SRL-1-83 rocker 1gang, lighting	SRL-1-83	1	piece
2CKA006220A0372	SRL-1-840 rocker 1g light	SRL-1-840	1	piece
2CKA006220A0534	SRL-1-866 rocker 1gang, lighting	SRL-1-866	1	piece
2CKA006220A0602	SRL-1-884 rocker 1gang, lighting	SRL-1-884	1	piece
2CKA006220A0619	SRL-1-885 rocker 1gang, lighting	SRL-1-885	1	piece
2CKA006220A0556	SRL-2-L-803 rocker 2g, left, lighting	SRL-2-L-803	1	piece
2CKA006220A0155	SRL-2-L-81 rocker 2g, left, lighting	SRL-2-L-81	1	piece
2CKA006220A0522	SRL-2-L-82 rocker 2g, left, lighting	SRL-2-L-82	1	piece
2CKA006220A0156	SRL-2-L-83 rocker 2g, left, lighting	SRL-2-L-83	1	piece
2CKA006220A0377	SRL-2-L-840 rocker 2g left light	SRL-2-L-840	1	piece
2CKA006220A0539	SRL-2-L-866 rocker 2g, left, lighting	SRL-2-L-866	1	piece
2CKA006220A0607	SRL-2-L-884 rocker 2g, left, lighting	SRL-2-L-884	1	piece
2CKA006220A0624	SRL-2-L-885 rocker 2g, left, lighting	SRL-2-L-885	1	piece
2CKA006220A0561	SRL-2-R-803 rocker 2g, right, lighting	SRL-2-R-803	1	piece
2CKA006220A0167	SRL-2-R-81 rocker 2g, right, lighting	SRL-2-R-81	1	piece
2CKA006220A0527	SRL-2-R-82 rocker 2g, right, lighting	SRL-2-R-82	1	piece
2CKA006220A0168	SRL-2-R-83 rocker 2g, right, lighting	SRL-2-R-83	1	piece
2CKA006220A0381	SRL-2-R-840 rocker2g right light	SRL-2-R-840	1	piece
2CKA006220A0544	SRL-2-R-866 rocker 2g, right, lighting	SRL-2-R-866	1	piece
2CKA006220A0612	SRL-2-R-884 rocker 2g, right, lighting	SRL-2-R-884	1	piece

2CKA006220A0629	SRL-2-R-885 rocker 2g, right, lighting	SRL-2-R-885	1	piece
2CKA006220A0553	SRS-1-803 rocker 1gang, scene	SRS-1-803	1	piece
2CKA006220A0146	SRS-1-81 rocker 1gang, scene	SRS-1-81	1	piece
2CKA006220A0519	SRS-1-82 rocker 1gang, scene	SRS-1-82	1	piece
2CKA006220A0147	SRS-1-83 rocker 1gang, scene	SRS-1-83	1	piece
2CKA006220A0374	SRS-1-840 rocker 1g scene	SRS-1-840	1	piece
2CKA006220A0536	SRS-1-866 rocker 1gang, scene	SRS-1-866	1	piece
2CKA006220A0604	SRS-1-884 rocker 1gang, scene	SRS-1-884	1	piece
2CKA006220A0621	SRS-1-885 rocker 1gang, scene	SRS-1-885	1	piece
2CKA006220A0558	SRS-2-L-803 rocker 2gang, left, scene	SRS-2-L-803	1	piece
2CKA006220A0161	SRS-2-L-81 rocker 2gang, left, scene	SRS-2-L-81	1	piece
2CKA006220A0524	SRS-2-L-82 rocker 2gang, left, scene	SRS-2-L-82	1	piece
2CKA006220A0162	SRS-2-L-83 rocker 2gang, left, scene	SRS-2-L-83	1	piece
2CKA006220A0379	SRS-2-L-840 rocker 2g left scene	SRS-2-L-840	1	piece
2CKA006220A0541	SRS-2-L-866 rocker 2gang, left, scene	SRS-2-L-866	1	piece
2CKA006220A0609	SRS-2-L-884 rocker 2gang, left, scene	SRS-2-L-884	1	piece
2CKA006220A0626	SRS-2-L-885 rocker 2gang, left, scene	SRS-2-L-885	1	piece
2CKA006220A0562	SRS-2-R-803 rocker 2g, right, scene	SRS-2-R-803	1	piece
2CKA006220A0173	SRS-2-R-81 rocker 2g, right, scene	SRS-2-R-81	1	piece
2CKA006220A0528	SRS-2-R-82 rocker 2g, right, scene	SRS-2-R-82	1	piece
2CKA006220A0174	SRS-2-R-83 rocker 2g, right, scene	SRS-2-R-83	1	piece
2CKA006220A0382	SRS-2-R-840 rocker 2g right scene	SRS-2-R-840	1	piece
2CKA006220A0545	SRS-2-R-866 rocker 2g, right, scene	SRS-2-R-866	1	piece
2CKA006220A0613	SRS-2-R-884 rocker 2g, right, scene	SRS-2-R-884	1	piece
2CKA006220A0630	SRS-2-R-885 rocker 2g, right, scene	SRS-2-R-885	1	piece

Catégories

Produits basse tension → Switch Assortments → Frames

